


Safewatch Pro® 3000 Security Manager 3000

Programming Guide



TO ENTER PROGRAMMING MODE:

Local programming requires the use of a Custom English touchpad connected to the touchpad terminals on the control.

1. POWER UP, then depress **[*] and [#]** both at once, within 50 seconds of powering up.
OR
2. Initially, key: **Installer Code (6 + 3 + 2 + 1)** plus **8 + 0 + 0**.
OR
3. If different **Installer Code** is programmed, key: **New Installer Code + 8 + 0 + 0**.
(if *98 was used to exit previously, method 1 above must be used to enter the program mode again)

Data Field Programming Procedures

Task	Procedure
Go to a Data Field	Press [*] + [Field Number] , followed by the required entry.
Entering Data	When the desired field number appears, simply make the required entry. When the last entry for a field is entered, the touchpad beeps three times and automatically displays the next data field in sequence. If the number of digits that you need to enter in a data field is less than the maximum digits available (for example, the phone number fields *41, *42), enter the desired data, then press [*] . The entry is terminated and the next data field number appears.
Review a Data Field	Press [#] + [Field Number] . Data will be displayed for that field number. No changes will be accepted in this mode.
Deleting an Entry	Press [*] + [Field Number] + [*] . (Applies only to fields *40–*43, *45, *94, and pager programming fields)

Interactive Mode Programming (*56, *57, *58, *80, *81, *82)

Press **[*] + [Interactive Mode No.]** (for example, *56). The Custom English display touchpad will display the first of a series of prompts requesting entries.

Interactive Mode	Used to Program
*56 Zone Programming	Zone characteristics, report codes, alpha descriptors, and serial numbers for 5800 RF transmitters.
*57 Function Key Programming	Unlabeled touchpad keys (known as ABCD keys) for special functions
*58 Zone Programming (Expert mode)	Same options as *56 mode, but with fewer prompts. Intended for those familiar with this type of programming, otherwise *56 mode is recommended.
*79 Output Device Mapping	Assign module addresses and map individual relays/powerline carrier devices
*80 Output Programming	4229 or 4204 Relay modules, Powerline Carrier devices, or on-board triggers
*81 Zone List Programming	Zone Lists for relay/powerline carrier activation, chime zones, pager zones, etc.
*82 Alpha Programming	Zone alpha descriptors

INITIALIZE DOWNLOAD and RESET DEFAULTS

- *96** Initializes download ID and subscriber account number.
- *97** Sets all data fields to original factory default values.

TO EXIT PROGRAMMING MODE:

- *98** Exits programming mode and *prevents* re-entry by: **Installer Code + 8 + 0 + 0**. If ***98** is used to exit programming mode, system must be powered down, and method 1 above used to enter the programming mode.
- *99** Exits programming mode and *allows* re-entry by: **Installer Code + 8 + 0 + 0** or method 1 above.

Special Messages

OC = OPEN CIRCUIT (no communication between Touchpad and Control).

EE or **ENTRY ERROR** = ERROR (invalid field number entered; re-enter valid field number).

After powering up, **AC**, **dl** (disabled) or **Busy Standby** and **NOT READY** will be displayed after approximately 4 seconds. This will revert to a **"Ready"** message in approximately 1 minute, which allows PIRS, etc. to stabilize. You can bypass this delay by pressing **[#] + [0]**.

If **E4** or **E8** appears, more zones than the expansion units can handle have been programmed. Correct the programming and then completely de-power and re-power the control to clear this indication and remove the disable indication.

PROGRAMMING FORM

Entry of a number other than one specified will give unpredictable results. Values shown in brackets are factory defaults.

Field	Function	Data Entries	Programmable Values
SYSTEM SETUP (*20–*29)			
*20	INSTALLER CODE	<input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> [6321]	4 digits, 0–9
*21	QUICK ARM ENABLE	<input type="checkbox"/> <input type="checkbox"/> [1,1] Part. 1 Part.2	0 = no; 1 = yes
*22	RF JAM OPTION	<input type="checkbox"/> [0]	0 = no RF Jam detection; 1 = send RF Jam report <u>UL: must be 1 if wireless devices are used</u>
*23	FORCED BYPASS	<input type="checkbox"/> <input type="checkbox"/> [1,1] Part. 1 Part. 2	0 = none <u>UL: must be "0"</u> 1 = bypass open zones
*24	RF HOUSE ID CODE	<input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> Part. 1 Part. 2 Common	00 = disable all wireless touchpad usage 01–31 = using 5827, 5827BD or 5804BD touchpad [00,00,00]
*26	CHIME BY ZONE	<input type="checkbox"/> [0]	0 = no; 1 = yes (select zones to chime on zone list 3, using *81 Menu mode)
*27	X–10 HOUSE CODE	<input type="checkbox"/> [0]	0 = A; 1 = B, 2 = C, 3 = D, 4 = E, 5 = F, 6 = G, 7 = H, 8 = I, 9 = J, #10 = K, #11 = L, #12 = M, #13 = N, #14 = O, #15 = P <u>UL: not for fire or UL installations</u>
28	ACCESS CODE FOR 4285/4286 PHONE MODULE	<input type="text"/> <input type="text"/> [00] (Partition 1 only)	00 = disable; 1st digit: enter 1–9; 2nd digit: enter # + 11 for "", or # + 12 for "#". <u>UL: must be "00" for UL Commercial Burg. installations</u>
*29	LONG RANGE RADIO OUTPUT	<input type="checkbox"/> [0]	0 = disable; 1 = enable
ZONE SOUNDS AND TIMING (*31 – *39)			
*31	ONE AUDIBLE ALARM PER ZONE	<input type="checkbox"/> [0]	0 = no <u>UL: must be "0"</u> ; 1 = yes
*32	FIRE ALARMSOUNDER TIMEOUT	<input type="checkbox"/> [0]	0 = sounder stops at timeout; 1 = no sounder timeout <u>UL: must be "1" for fire install.</u>
*33	ALARM SOUNDER TIMEOUT	<input type="checkbox"/> [1]	0 = none; 1 = 4 min; 2 = 8 min; 3 = 12 min; 4 = 16 min; <u>UL: minimum "1" (4 min.)</u>
*34	EXIT DELAY	<input type="text"/> <input type="text"/> [60,60] Part. 1 Part. 2	00–99 = seconds of exit delay time for each partition Common zones use same delay as partition 1.
*35	ENTRY DELAY #1 (zone type 01)	<input type="text"/> <input type="text"/> [45,45] Part. 1 Part. 2	00–99 = seconds of entry delay #1 time for each partition; <u>UL: 45 seconds max.</u> Common zones use same delay as partition 1.
*36	ENTRY DELAY #2 (zone type 02)	<input type="text"/> <input type="text"/> [90,90] Part. 1 Part. 2	00–99 = entry delay #2 time for each partition; <u>UL: 60 seconds max.</u> Common zones use same delay as partition 1.
*37	AUDIBLE EXIT WARNING	<input type="checkbox"/> <input type="checkbox"/> [1,1] Part. 1 Part. 2	0 = no; 1 = yes
*38	CONFIRMATION OF ARMING DING	<input type="checkbox"/> <input type="checkbox"/> [0,0] Part. 1 Part. 2	0 = no; 1 = yes (wired touchpads and RF) 2 = yes, RF only
*39	POWER UP IN PREVIOUS STATE	<input type="checkbox"/> [1]	0 = no; 1 = yes <u>UL: must be "1"</u>
DIALER PROGRAMMING (*40 – *42)			
Enter the number of digits shown. Do not fill unused spaces. Enter 0–9; #+11 for '*'; #+12 for '#'; #+13 for a 2-second pause.			
40	PABX ACCESS CODE	<input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/>	Enter up to 6 digits. If fewer than 6 digits are entered, exit by pressing [] and next desired field number. To clear entries from field, press *40* .
41	PRIMARY PHONE No.	<input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/>	Enter up to 20 digits; Do not fill unused spaces. If fewer than 20 digits entered, exit by pressing [] and next desired field number. To clear entries, press *41* .
42	SECOND PHONE No.	<input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/>	Enter up to 20 digits; Do not fill unused spaces. If fewer than 20 digits entered, exit by pressing [] and next desired field number. To clear entries, press *42* .

For fields *43 and *45:

Enter 0–9; #+11 for B; #+12 for C; #+13 for D; #+14 for E; [#+15 for F]. To clear entries from field, press *43* or *45*.

Examples: For Acct. **1234**, enter: ; For Acct. **B234**, enter:

- * 43** SUBSCRIBER ID # (Part.1) / Enter 4 or 10 digits, depending on selection in *48 Report Format. See box above for entries.
- * 45** SUBSCRIBER ID # (Part. 2) / Enter 4 or 10 digits, depending on selection in *48 Report Format. See box above for entries.
- *47** PHONE SYSTEM SELECT ☐ [3] If Cent. Sta. *IS NOT* on a WATS line:
0=Pulse Dial; 1=Tone Dial;
if Cent. Sta. *IS* on a WATS line:
2 = Pulse Dial ; 3 = Tone Dial
- *48** REPORT FORMAT ☐ ☐ [77]
primary secondary 5 = CID using 10-digit subscriber account (ID) no.
7 = CID using 4-digit subscriber account (ID) no.
14 = CID 4-digit account no. with shutdown (# + 14)
15 = CID 10-digit account no. with shutdown (# + 15)
UL: only 4-digit Contact ID format has been evaluated
- *49** SPLIT/DUAL REPORTING ☐ [0] 0 = Disable (Backup report only)
Primary Phone No. **Second Phone No.**
1 = Alarms, Restore, Cancel Others
2 = All except Open/Close, Test Open/Close, Test
3 = Alarms, Restore, Cancel All
4 = All except Open/Close, Test All
5 = All All
- *50** 15 SEC DIALER DELAY (BURG) ☐ [1] 0 = no **UL: must be "0"**; 1 = yes
- *53** MISC. FAULT DELAY TIME ☐ [0]
(Zone Type 25 or Configurable Zone Type) 0 = 15 seconds 6 = 2-1/2 min #+12 = 8 min
1 = 30 seconds 7 = 3 min #+13 = 10 min
2 = 45 seconds 8 = 4 min #+14 = 12 min
3 = 60 seconds 9 = 5 min #+15 = 15 min
4 = 90 seconds #+10 = 6 min
5 = 2 minutes #+11 = 7 min
UL: may only be used on non-burglar alarm/ non-fire alarm zones when used in fire and/or UL burglar alarm installation
- *54** DYNAMIC SIGNALING DELAY ☐ [0] Delay selectable from 0 to 225 secs in 15-sec increments.
0 = no delay (both signals sent), 1 = 15 secs,
2 = 30 secs, etc. **UL: must be "0"**
- *55** DYNAMIC SIGNALING PRIORITY ☐ [0] 0 = Primary Dialer first; 1 = Long Range Radio first.

TO PROGRAM SYSTEM STATUS, & RESTORE REPORT CODES (*59 – *76, & *89) FOR CONTACT ID® REPORTING:Enter any digit (other than "0") in the *first* box, to enable zone to report (entries in the *second* boxes will be ignored).**UL: see installation instructions for requirements****SYSTEM STATUS REPORT CODES (*59–* 68)**

- *59** EXIT ERROR REPORT CODE ☐ [1] Any non-zero entry enables CID report.
- *60** TROUBLE REPORT CODE ☐ ☐ [10] Any non-zero entry in first digit enables CID report.
- *61** BYPASS REPORT CODE ☐ ☐ [00] Any non-zero entry in first digit enables CID report.
- *62** AC LOSS REPORT CODE ☐ ☐ [00] Any non-zero entry in first digit enables CID report.
- *63** LOW BAT REPORT CODE ☐ ☐ [10] Any non-zero entry in first digit enables CID report.
- *64** TEST REPORT CODE ☐ ☐ [10] Any non-zero entry in first digit enables CID report.
Use Scheduling mode to schedule periodic test reports.
- *65** OPEN REPORT CODE ☐ ☐ ☐ [0,0,0] Any non-zero entry enables CID report for partition.
Part. 1 Part. 2 Common
- *66** ARM AWAY/STAY RPT CODE ☐ ☐ ☐ ☐ ☐ ☐ [0,0,0,0,0,0] Any non-zero entry enables CID report
Away Stay Away Stay Away Stay
Part. 1 Part. 2 Common
- *67** RF XMTR LOW BAT REPORT CODE ☐ ☐ [10] Any non-zero entry in first digit enables CID report.
UL: must be enabled if wireless devices are used
- *68** CANCEL REPORT CODE ☐ ☐ [10] Any non-zero entry in first digit enables CID report.

Entry of a number other than one specified will give unpredictable results.

RESTORE REPORT CODES (*70 – *76)

- *70** ALARM RESTORE RPT CODE [1]
***71** TROUBLE RESTORE RPT CODE [10]
***72** BYPASS RESTORE RPT CODE [00]
***73** AC RESTORE RPT CODE [00]
***74** LOW BAT RESTORE RPT CODE [10]
***75** RF XMTR LO BAT RST RPT CODE [10]
***76** TEST RESTORE RPT CODE [10]

Any non-zero entry enables CID report.

Any non-zero entry in first digit enables CID report.

Any non-zero entry in first digit enables CID report.

Any non-zero entry in first digit enables CID report.

Any non-zero entry in first digit enables CID report.

Any non-zero entry in first digit enables CID report.

UL: must be enabled if wireless devices are used

Any non-zero entry in first digit enables CID report.

OUTPUT AND SYSTEM SETUP (*77 – *93)

- *77** DAYLIGHT SAVINGS TIME
START\END MONTH [4][10]
***78** DAYLIGHT SAVINGS TIME
START\END WEEKEND [1][5]
***84** AUTO STAY ARM [0]
***85** CROSS ZONE TIMER [0]

This option not for use in UL installations.

0 = Disabled

1-12 = month (1 = January, 2 = February, etc)

0 = disabled, 1 = first, 2 = second, 3 = third

4 = fourth, 5 = last, 6 = next to last, 7 = third to last

0 = no, 1 = partition 1 only

2 = partition 2 only, 3 = both partitions

0 = 15 seconds 6 = 2-1/2 min ##+12 = 8 min

1 = 30 seconds 7 = 3 min ##+13 = 10 min

2 = 45 seconds 8 = 4 min ##+14 = 12 min

3 = 60 seconds 9 = 5 min ##+15 = 15 min

4 = 90 seconds ##+10 = 6 min

5 = 2 minutes ##+11 = 7 min

(assign cross zones on zone list 4, with *81 Menu mode)

0 = no, 1 = yes

- *86** CANCEL VERIFY [0]
***89** EVENT LOG FULL REPORT CODE [00]
***90** EVENT LOG ENABLES [12]

Enter any digit (other than "0") in the first box, to enable report (entries in the second box are ignored)

0 = None; 1 = Alarm/Alarm Restore

2 = Trouble/Trouble Restore;

4 = Bypass/Bypass Restore;

8 = Open/Close. *Example:* To select "Alarm/Alarm Restore", and "Open/Close", enter 9 (1 + 8); To select all, enter #15.

NOTE: System messages are logged when any non-zero selection is made.

- *91** OPTION SELECTION [8]

0 = None

1 = Bell Supervision UL: required for fire alarm install

4 = AAV UL: do not use AAV

8 = Exit Delay Restart

Multiple choice example: for AAV (4) + Exit Delay restart (8) enter # + 12; for all (1 + 4 + 8), enter # + 13.

- *92** PHONE LINE MONITOR ENABLE [0,0]

UL: see Inst. Instructions for requirements

Digit 1: 0 = disabled, 1-15 = 1 min - 15 min

Digit 2:

0 = Touchpad display when line is faulted

1 = Touchpad display plus touchpad trouble sound

2 = Same as "1", plus programmed output device

STARTS. If either partition is armed, external sounder

activates also. **NOTE:** Output Device must either be

programmed to be STOPPED in field *80 or

STOPPED by Code + # + 8 + output number.

- *93** No. OF REPORTS IN ARMED PERIOD
PER ZONE (Swinger Suppression) [0]

0 = Unlimited Reports; 1 = 1 report; 2 = 2 reports

UL: must be "0"

DOWNLOAD INFORMATION (*94, *95)

- *94** DOWNLOAD PHONE No.

Enter up to 20 digits, 0-9; ##+11 for '*'; ##+12 for '#'; ##+13 for a 2-second pause. Do not fill unused spaces. If fewer than 20 digits, exit field by pressing * (and press 95, if entering next field). To clear entries from field, press *94*. UL: downloading may be performed only if a technician is at the site.

- *95** RING COUNT FOR DOWNLOADING [15]

0 = Disable Station Initiated Download;

1-14 = number of rings (1-9, # +10 =10, # +11 =11,

+12 =12, # +13 =13, # +14 =14);

15 = answering machine defeat (# +15 =15).

NOTE: Do not enter "0" if using 4285/4286 Phone Module.

PAGER OPTIONS 160-172

*160 PAGER 1 PHONE No.

Enter up to 20 digits. 0-9; #+11 = '*'; #+12 = '#'; #+13 = 2-second pause.

*161 PAGER 1 CHARACTERS

Enter the optional prefix characters, up to 16 digits.

0-9; #+11 = '*'; #+12 = '#'; #+13 = 2-second pause.

*162 PAGER 1 REPORTING OPTIONS

☐ ☐ ☐

Part. 1 Part. 2 common
[0,0,0]

For each partition, select from the following options:

0 = no reports sent

1 = Open/closes all users

4 = All alarms and troubles

5 = All alarms / troubles, and open/closes for all users

12 = Alarms / troubles for zones entered in zone list 9

13 = Alarms / troubles for zones entered in zone list 9,
and open/closes for all users

*163 PAGER 2 PHONE No.

Enter up to 20 digits. 0-9; #+11 = '*'; #+12 = '#'; #+13 = 2-second pause.

*164 PAGER 2 CHARACTERS

Enter the optional prefix characters, up to 16 digits.

0-9; #+11 = '*'; #+12 = '#'; #+13 = 2-second pause.

*165 PAGER 2 REPORTING OPTIONS

☐ ☐ ☐ [0,0,0]

Part. 1 Part. 2 common

See field *162 for reporting options. Select for each partition (use zone list 10 if using options 12 or 13).

*166 PAGER 3 PHONE No.

Enter up to 20 digits. 0-9; #+11 = '*'; #+12 = '#'; #+13 = 2-second pause.

*167 PAGER 3 CHARACTERS

Enter the optional prefix characters, up to 16 digits.

0-9; #+11 = '*'; #+12 = '#'; #+13 = 2-second pause.

*168 PAGER 3 REPORTING OPTIONS

☐ ☐ ☐ 0,0,0]

Part. 1 Part. 2 common

See field *162 for reporting options. Select for each partition (use zone list 11 if using options 12 or 13).

*169 PAGER 4 PHONE No.

Enter up to 20 digits. 0-9; #+11 = '*'; #+12 = '#'; #+13 = 2-second pause.

*170 PAGER 4 CHARACTERS

Enter the optional prefix characters, up to 16 digits.

0-9; #+11 = '*'; #+12 = '#'; #+13 = 2-second pause.

*171 PAGER 4 REPORTING OPTIONS

☐ ☐ ☐ [0,0,0]

Part. 1 Part. 2 common

See field *162 for reporting options. Select for each partition (use zone list 12 if using options 12 or 13).

*172 PAGER DELAY OPTION FOR ALARMS

☐ [3]

0 = none, 1 = 1 minute, 2 = 2 minutes, 3 = 3 minutes
This delay is for ALL pagers in the system.

NOTE: The delay does not reset for new alarms occurring while an existing pager delay is in progress.

REPORTING OPTIONS 173-177

*173 RF REPORTING OPTIONS

☐ [3]

0 = disable all options

1 = RF Tamper reports during disarm

2 = RF button types send low battery

8 = RF low battery reports delayed (delayed 28 days)

Example: Entering "10" (8 + 2) enables button-type transmitters to send low battery reports and delay all reports for 28 days. UL: see Inst. Instr. for requirements

*174 CLEAN ME REPORTING OPTIONS (for ESL smoke detectors)

☐ [0]

0 = disable; 1 = Clean Me signal reports;

2 = Clean Me reports, 28-day enabled.

Note: If Clean Me is enabled, you must enter "3" in field *56 programming for zone 1 response time.

*175 UP AND ABOUT TIME

☐ [0]

0 = none, 1 = 1 hour, 2 = 2 hours,... 15 = 15 hours (hourly increments)

*176 LACK OF USAGE OPTION

☐ [0]

1-15 = number of weeks selected (1 week increments)
If panel is not armed within the time period selected, a report will be sent to the central station.

***177** DEVICE DURATION 1, 2
(used in *80 Menu mode-Device Actions 5/6)

<input type="checkbox"/>	<input type="checkbox"/>	[0] [0]
1	2	

0 = 15 seconds	6 = 2-1/2 min	#+11 = 7 min
1 = 30 seconds	7 = 3 min	#+12 = 8 min
2 = 45 seconds	8 = 4 min	#+13 = 10 min
3 = 60 seconds	9 = 5 min	#+14 = 12 min
4 = 90 seconds	#+10 = 6 min	#+15 = 15 min
5 = 2 minutes		

SYSTEM OPTIONS *180-*181

***180** SINGLE ZONE BYPASS

☐ [0]

0 = disable; 1 = enabled

***181** 50/60 HERTZ AC OPERATION

☐ [0]

0 = 60 Hz; 1 = 50 Hz

***182** CONFIGURABLE ZONE TYPE 90

<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
1	2	3	4	5	6	7	8	9	10

Make the appropriate entry for each digit, 1-10, based on the charts provided on the next page. Each digit's entry is the sum of the values of its selected options (0-9, #+10=10, #+11=11, #+12=12, #+13=13, #+14=14, #+15=15).

UL: Do not configure zones as a fire alarm or UL burglar alarm zone.

***183** ZONE TYPE 90 REPORT CODES

IMPORTANT: Use existing Contact ID® codes, if appropriate, or define unique codes in CID code range 750-789. See important note in installation instructions.

90 ALARM ID: XXX
TROUBLE ID: XXX

Enter the desired 3-digit Contact ID® report codes for alarms and troubles occurring on zones assigned to this zone type. Enter the codes sequentially (all 6 digits). When entering digits, [#] moves cursor back, [*] moves forward. Press [*] when done to continue.

***184** CONFIGURABLE ZONE TYPE 91

<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
1	2	3	4	5	6	7	8	9	10

Make the appropriate entry for each digit, 1-10, based on the charts provided on the next page. Each digit's entry is the sum of the values of its selected options (0-9, #+10=10, #+11=11, #+12=12, #+13=13, #+14=14, #+15=15).

UL: Do not configure zones as a fire alarm or UL burglar alarm zone.

***185** ZONE TYPE 91 REPORT CODES

IMPORTANT: Use existing Contact ID® codes, if appropriate, or define unique codes in CID code range 750-789. See important note in installation instructions.

91 ALARM ID: XXX
TROUBLE ID: XXX

Enter the desired 3-digit Contact ID® report codes for alarms and troubles occurring on zones assigned to this zone type. Enter the codes sequentially (all 6 digits). When entering digits, [#] moves cursor back, [*] moves forward. Press [*] when done to continue.

TOUCHPAD OPTIONS *190-*196 (NOTE: Options for touchpad address 16 are set by the factory and cannot be changed.)

NOTE: Each touchpad must be assigned a unique address. Touchpads programmed with the same address will give unpredictable results.

***190** TOUCHPAD 2 ADDRESS 17

<input type="checkbox"/>	<input type="checkbox"/>	[0] [0]
Part.	Sound	

Partition: 0 = keypad disabled; 1-3 = part. no. (3 = com)
Sound: 0 = no suppression
1 = suppress arm/disarm and E/E beeps
2 = Suppress chime beeps only
3 = suppress arm/disarm, E/E, and chime beeps

***191** TOUCHPAD 3 ADDRESS 18

<input type="checkbox"/>	<input type="checkbox"/>	[0] [0]
Part.	Sound	

See field *190 for entries.

***192** TOUCHPAD 4 ADDRESS 19

<input type="checkbox"/>	<input type="checkbox"/>	[0] [0]
Part.	Sound	

See field *190 for entries.

***193** TOUCHPAD 5 ADDRESS 20

<input type="checkbox"/>	<input type="checkbox"/>	[0] [0]
Part.	Sound	

See field *190 for entries.

***194** TOUCHPAD 6 ADDRESS 21

<input type="checkbox"/>	<input type="checkbox"/>	[0] [0]
Part.	Sound	

See field *190 for entries.

***195** TOUCHPAD 7 ADDRESS 22

<input type="checkbox"/>	<input type="checkbox"/>	[0] [0]
Part.	Sound	

See field *190 for entries.

***196** TOUCHPAD 8 ADDRESS 23

<input type="checkbox"/>	<input type="checkbox"/>	[0] [0]
Part.	Sound	

See field *190 for entries.

***197** EXIT TIME DISPLAY INTERVAL

☐ [0]

0 = no display; 1-5 = seconds between display refresh

***198** DISPLAY PARTITION NUMBER
(for Custom Display Touchpads)

☐ [0]

0 = no; 1 = yes (partition no. appears on Custom Display)

***199** ECP FAIL DISPLAY

☐ [0]

0 = 3-digit display ("1" + device address)
1 = 2-digit fixed-display as "91"

Configurable Zone Types Worksheets

Configurable zone types 90 and 91 can be programmed via downloader software or from a touchpad using data fields *182-*185. Configurable zone types 92 and 93 can only be programmed using the downloader software.

Programming Configurable Zone Type options involves entering 10 digits in data field *182 for zone type 90 and field *184 for zone type 91, where each digit represents the sum of the values of its various options as shown in the tables below. Use fields *183 and *185 to program Contact ID® report codes for these zone types.

RF ZONE NOTE: The “open” option in digits 1, 3, and 5 is not applicable for RF zones. Use the “intact EOL” option for normal RF zone conditions and “shorted” for off-normal RF zone conditions.

DIGIT 1		DIGIT 2		
Response when system disarmed and zone is:		Intact EOL	Open	Shorted
		RF zone normal	RF zone N/A	RF zn off-normal
0 = normal		0 = normal	0 = normal	0 = normal
1 = alarm		4 = alarm	4 = alarm	1 = alarm
2 = trouble		8 = trouble	8 = trouble	2 = trouble
3 = fault		12 = fault	12 = fault	3 = fault
Digit 1 = EOL + Open		Digit 2 = Short + auto restore + vent zone		

DIGIT 3		DIGIT 4		
Response when armed STAY and zone is:		Intact EOL	Open	Shorted
		RF zone normal	RF zone N/A	RF zn off-normal
0 = normal		0 = normal	0 = normal	0 = normal
1 = alarm		4 = alarm	4 = alarm	1 = alarm
2 = trouble		8 = trouble	8 = trouble	2 = trouble
3 = fault		12 = fault	12 = fault	3 = fault
Digit 3 = EOL + Open		Digit 4 = Short + byp. disarmed + byp. armed		

DIGIT 5		DIGIT 6		
Response when armed AWAY and zone is:		Intact EOL	Open	Shorted
		RF zone normal	RF zone N/A	RF zn off-normal
0 = normal		0 = normal	0 = normal	0 = normal
1 = alarm		4 = alarm	4 = alarm	1 = alarm
2 = trouble		8 = trouble	8 = trouble	2 = trouble
3 = fault		12 = fault	12 = fault	3 = fault
Digit 5 = EOL + Open		Digit 6 = Short + dial delay + fault delay		


DIGIT 7		DIGIT 8		
Display Faults	Power Reset/ Verification	Use Entry Delay 1/2	Use Exit Delay	Respond as Interior Type
0 = show alarms when armed & disarmed	0 = no	0 = no	0 = no	0 = no
1 = don't show alarms when armed (show alarms, trbles, faults when disarmed)	4 = power reset after fault (by code + OFF)	1 = delay 1	4 = use exit delay	8 = yes
3 = never show any alarms, trbles, faults	12 = verification (see zone type 16)	2 = delay 2		see note 2
Digit 7 = fault display + power reset/verification		Digit 8 = entry delay 1/entry delay 2 + exit delay + interior zone type		

DIGIT 9			DIGIT 10	
Alarm Sounds	Use Bell Timeout	Respond as Fire Zone	Trouble Sounds	Chime when Chime Mode On
0 = none	0 = no	0 = no	0 = none	0 = no
1 = steady touchpad	4 = yes	8 = yes	1 = periodic beep	4 = yes
2 = steady bell and touchpad	see fields *32, *33	see zone type 09; see note 4	2 = trouble beeps	
3 = pulsing bell and touchpad				
Digit 9 = alarm sounds + bell timeout + fire zone			Digit 10 = trouble sounds + chime	

Entries for Fields *182 and *184		
Digit	Zone Type 90 (field *182)	Zone Type 91 (field *184)
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		

To calculate each digit's entry:

Simply add the values of the selected options in each of the digit's columns (one option per column). For example, to program Digit 2 for “alarm response to short,” “auto restore on,” but not a “vent zone,” enter 5 (“1” for alarm short + “4” for auto restore yes + “0” for vent zone no).



NOTES:

- Do not use the “fault delay” option with a configurable zone type if it is set for an entry or exit delay, otherwise unpredictable results may occur.
- To create an interior type zone, select “respond as interior zone type” (Digit 8, interior type = yes), and set zone response to “fault” in digits 3-4 to ensure fault displays; do not set as “normal,” “alarm,” or “trouble.”
- Do not set fire zones to respond as a “fault” (digits 1-6), otherwise faults will not display unless the [*] key is pressed.
- 4219/4229 modules must use EOLRs or unpredictable results may occur.

***56 ZONE PROGRAMMING WORKSHEET [default values shown in brackets]**

Zone	Zn Type	Part.	Report	Input Type	Loop	Rsp. Time	Serial No.	Location
1	[01]	[1]		[HW]		[1]		
2	[01]	[1]		[HW]		[1]		
3	[10]	[1]		[HW]		[1]		
4	[10]	[1]		[HW]		[1]		
5	[10]	[1]		[HW]		[1]		
6	[01]	[1]		[HW]		[1]		
7	[01]	[1]		[HW]		[1]		
8	[01]	[1]		[HW]		[1]		
9								
10								
11								
12								
13								
14								
15								
16								
17								
18								
19								
20								
21								
22								
23								
24								
25								
26								
27								
28								
29								
30								
31								
32								
33								
34								
35								
36								
37								
38								
39								
40								
41								
42								
43								
44								
45								
46								
47								
48								
49		[1]		[BR]	[1]			
50		[1]		[BR]	[1]			
51		[1]		[BR]	[1]			
52		[1]		[BR]	[1]			
53		[1]		[BR]	[1]			
54		[1]		[BR]	[1]			
55		[1]		[BR]	[1]			
56		[1]		[BR]	[1]			
57		[1]		[BR]	[1]			
58		[1]		[BR]	[1]			
59		[1]		[BR]	[1]			
60		[1]		[BR]	[1]			
61		[1]		[BR]	[1]			
62		[1]		[BR]	[1]			
63		[1]		[BR]	[1]			
64		[1]		[BR]	[1]			
95	[09]			N/A	N/A	N/A	N/A	touchpad [1] / [*]
96				N/A	N/A	N/A	N/A	touchpad [3] / [#]
99	[07]			N/A	N/A	N/A	N/A	touchpad [*] / [#]

Reserved Zones

91 = addressable
device report
enable/disable
default zone
type = [05].

92 = Duress report
enable/disable

NOTES: Zone Type: see chart on page 12; Report Code: enabled if any digit entered as 1st digit; Input Type: HW (1-zones 1-8), AW (2-zones 9-48), RF (3-zones 1-48), UR (4-zones 1-48), BR (5-zones 49-64); Response Time: 0 (10msec), 1 (350msec), 2 (700msec), 3 (1.2 sec)
All zones, including duress (zone 92), are enabled for Contact ID® reporting.

*57 FUNCTION KEY PROGRAMMING

Option	Function	A	B	C	D	Comments
01	Paging					
02	Time Display					
03	Arm AWAY					
04	Arm STAY					
05	Arm NIGHT-STAY					
06	Step Arming					
07	Device Activation					Device:
08	Comm. Test					
09	Macro Key 1					
10	Macro Key 2					
11	Macro Key 3					
12	Macro Key 4					
00	Emergency Keys:					
	Personal Emergency					
	Silent Alarm					
	Audible Alarm					
	Fire					
Emergency Keys: A = [1] / [*] B = [*] / [#] C = [3] / [#]						

OUTPUT RELAYS/POWERLINE CARRIER DEVICES WORKSHEET FOR *79, *80 and *81. Applicable only if Relays and/or Powerline Carrier Devices are to be used.

*79 RELAY/POWERLINE CARRIER DEVICE MAPPING (Must program before using *80)

OUTPUT TYPE				
		Relay	X10	
Output No.	Module Addr.	Pos (1-4)	Unit No.	Description
01				
02				
03				
04				
05				
06				
07				
08				

OUTPUT TYPE				
		Relay	X10	
Output No.	Module Addr.	Pos (1-4)	Unit No.	Description
09				
10				
11				
12				
13				
14				
15				
16				
17	On-Board Trigger 1			
18	On-Board Trigger 2			

*81 ZONE LISTS FOR OUTPUT DEVICES

Fill in the required data on the worksheet below and follow the procedure in the installation manual as you enter the data during the displays and prompts that appear in sequence.

Note: Record desired zone numbers below, noting that a list may include *any* or *all* of system's zone numbers.

List No.	Used For...	Contains These Zones...
01	General Purpose (GP)	
02	General Purpose	
03	Chime-by-Zone or GP	
04	Cross Zones or GP	
05	Night-Stay Zones or GP	
06	General Purpose	
07	General Purpose	
08	General Purpose	
09	Zones activating pager 1	
10	Zones activating pager 2	
11	Zones activating pager 3	
12	Zones activating pager 4	

*80 OUTPUT DEFINITIONS

Fill in the required data on the worksheet below and follow the programming procedure in the installation manual as you enter the data during the displays and prompts that appear in sequence.

- Notes:** 1. For Relays, 4229 and 4204 devices are programmed in *79, *80, and *81 modes.
2. For Powerline Carrier devices (plcd), field *27 must be programmed with a House Code.
3. Tamperers of expansion units cannot be used to operate devices.

Output Function Number (1-48)	Activation Type and Detail				Partition Number (P) (if using ZT trig) 0 = any 1 = partition 1 2 = partition 2 3 = common	Event (for zone list/activated by)		Action 0 = off 1 = close 2 secs 2 = stay closed 3 = pulse 4 = toggle 5 = duration 1†† 6 = duration 2††	Output Number 1-18= dev	Device Type R = relay T = trigger X = X10
	Activated by 0=delete 1=zn list 2=zn type 3=zn no.	Zone List (ZL) 1-8 = list	Zone Type (ZT) (see table below)	Zone No. (ZN) 00=none 01-64		By Zone List	By Zone No. 0 = restore 1 = alarm/flt/trbl			
1										
2										
3										
4										
5										
6										
7										
8										
9										
10										
11										
12										
13										
14										
15										
16										
17										
18										
19										
20										
21										
22										
23										
24										
25										
26										
27										
28										
29										
30										
31										
32										
33										
34										
35										
36										
37										
38										
39										
40										
41										
42										
43										
44										
45										
46										
47										
48										

ZONE TYPE/SYSTEM OPERATION – Choices for Zone Types are:

00 = Not Used	05 = Trouble Day/Alarm Night	10 = Interior w/Delay	24 = Silent Burglary
01 = Entry/Exit#1	06 = 24 Hr Silent	12 = Monitor Zone	25 = 24-Hr Non-Alarm
02 = Entry/Exit#2	07 = 24 Hr Audible	14 = Carbon Monoxide	77 = Keypad
03 = Perimeter	08 = 24 Hr Aux	16 = Fire w/Verification	90-93 = Configurable
04 = Interior Follower	09 = Fire	23 = No Alarm Response	

Note: Any zone in "ZT" going into alarm, fault, or trouble will actuate device. Any zone of that type that restores will stop relay action.

Choices for System Operation are:

20 = Arming–Stay	38 = Chime	52 = Kissoff
21 = Arming–Away	39 = Any Fire Alarm	54 = Fire Zone Reset
22 = Disarming (Code + OFF)	40 = Bypassing	58 = Duress
31 = End of Exit Time	41 = **AC Power Failure	60 = AAV Trigger
32 = Start of Entry Time	42 = **System Battery Low	66 = Function key†
33 = Any Burglary Alarm	43 = Communication Failure	67 = Bell Failure
36 = **At Bell Timeout***		68 = TELCO Line Fault
		78 = keyswitch red LED†††
		79 = keyswitch green LED†††

Note: In normal operation mode:

Code + # + 7 + NN Key Entry **starts** Device
Code + # + 8 + NN Key Entry **stops** Device

** Use 0 (any) for Partition No. (P) entry.

*** Or at Disarming, whichever occurs earlier.

† Use *57 Menu mode to assign the function key.

†† Duration is set in program field *177.

††† Device action not used for these choices.

Zone Type Definitions

Type 00 Use this zone type if the zone is not used.
Zone Not Used

Type 01 Entry/Exit Burglary #1	<ul style="list-style-type: none"> Assign to zones that are used for primary entry and exit. Provides entry delay if the control is armed in the Away or Stay modes. No entry delay is provided when the panel is armed in the Instant mode. Entry delay #1 is programmable from 0 to 99 seconds for each partition. Exit delay begins whenever the control is armed, regardless of the arming mode selected, and is independently programmable from 0 to 99 seconds (field *34).
Type 02 Entry/Exit Burglary #2	<ul style="list-style-type: none"> Assign to zones that are used for entry and exit and require more time than the primary entry/exit point. Provides a secondary entry delay, in same manner as entry delay #1. Entry delay #2 is programmable from 0 to 99 seconds for each partition. Exit delay is same as described for Type 01.
Type 03 Perimeter Burglary	<ul style="list-style-type: none"> Assign to all sensors or contacts on exterior doors and windows. Provides an instant alarm if the zone is faulted when the panel is armed in the Away, Stay, or Instant modes.
Type 04 Interior Follower	<ul style="list-style-type: none"> Assign to a zone covering an area such as a foyer, lobby, or hallway through which one must pass upon entry (to and from the touchpad). Provides a delayed alarm (using the programmed entry/exit time) if the entry/exit zone is faulted first. Otherwise this zone type gives an instant alarm. Active when the panel is armed in the Away mode. Bypassed automatically when the panel is armed in the Stay or Instant modes.
Type 05 Trouble by Day/ Alarm by Night	<ul style="list-style-type: none"> Assign to a zone that contains a foil-protected door or window (such as in a store), or to a zone covering a sensitive area such as a stock room, drug supply room, etc. Can also be used on a sensor or contact in an area where immediate notification of an entry is desired. Provides an instant alarm if faulted when armed in the Away, Stay, or Instant (night) modes. During the disarmed state (day), the system will provide a latched trouble sounding from the touchpad (and a central station report, if desired).
Type 06 24-hour Silent Alarm	<ul style="list-style-type: none"> Usually assigned to a zone containing an emergency button. Sends a report to the central station but provides no touchpad display or sounding.
Type 07 24-hour Audible Alarm	<ul style="list-style-type: none"> Assign to a zone that has an emergency button. Sends a report to the central station, and provides an alarm sound at the touchpad, and an audible external alarm.
Type 08 24-hour Auxiliary Alarm	<ul style="list-style-type: none"> Assign to a zone containing an emergency button, or to a zone containing monitoring devices such as water or temperature sensors. Sends a report to the central station and provides an alarm sound at the touchpad. (No bell output is provided.)
Type 09 Fire	<ul style="list-style-type: none"> Provides a fire alarm on short circuit and a trouble condition on open circuit. A fire alarm produces a pulsing bell output. This zone type is always active and cannot be bypassed. <p>Note: Only hardwired zone 1 should be programmed as a fire zone, where 2-wire smoke detectors can be connected. However, any wireless zone can be used as a fire zone.</p>
Type 10 Interior w/Delay	<ul style="list-style-type: none"> Provides entry delay (using the programmed entry time), if tripped when the panel is armed in the Away mode. Entry Delay begins whenever sensors in this zone are violated, regardless of whether or not an entry/exit delay zone was tripped first. Bypassed when the panel is armed in the Stay or Instant modes.
Type 12 Monitor Zone	<ul style="list-style-type: none"> Works as a dynamic monitor of a zone fault/trouble. In the case of a short/open, the message, "ALARM-24 Hr. Non-Burg. -#XXX" (where XXX is the zone number) will be sent to the Central Station. The system keypad will display a "check" message indicating the appropriate zone. Upon restoral of the zone, the message, "RESTORE-24 Hr. Non-Burg. -#XXX" will be sent to the Central Station. The "check" message will automatically disappear from the keypad. The zone restores dynamically; therefore a user code + off sequence is not needed to reset the zone. Faults of this zone type are independent of the system, and can exist at the time of arming without interference. Since this is a "trouble" zone type, do not use this zone type with relays set to activate upon "alarm."
Type 14 Carbon Monoxide	<ul style="list-style-type: none"> Assigned to any zone with a carbon monoxide detector. The bell output will pulse when this zone type is alarmed. Always active and cannot be bypassed.
Type 16 Fire w/Verification	<ul style="list-style-type: none"> Provides a fire alarm when zone is shorted, but only after alarm verified. System verifies alarm by resetting zones for 12 seconds after short is detected. A subsequent short circuit within 90 seconds triggers fire alarm. Provides a trouble response when zone is open. <u>UL: may not be used on zone 1.</u>

**Type 20
Arm-Stay**

- Arms the system in Stay mode when the zone is activated.
- Pushbutton units send the user number to the central station when arming or disarming.
- User code for button must be assigned.

**Type 21
Arm-Away**

- Arms the system in Away mode when the zone is activated.
- Pushbutton units send the user number to the central station when arming or disarming.
- User code for button must be assigned.

**Type 22
Disarm**

- Disarms the system when the zone is activated.
- User code for button must be assigned.

**Type 23*
No Alarm Response**

- Can be used on a zone when an output relay action is desired, but with no accompanying alarm (e.g., lobby door access).

**Type 24
Silent Burglary**

- Usually assigned to all sensors or contacts on exterior doors and windows where bells and/or sirens are NOT desired.
- Provides an instant alarm, with NO audible indication at any touchpad or external sounder, if the zone is faulted when the system is armed in the Away, Stay, or Instant, modes.
- A report is sent to the central station.

**Type 25*
24-Hour Non-Alarm**

- For use with sensors designed to provide a trouble display (but no trouble sounding) when an oil tank is low, or other similar application for critical condition monitoring where a non-alarm response is required.
- When this zone type is faulted and remains faulted for the programmed time duration (field *53), a special event message is sent to the central monitoring station. The same holds true for restoration.

**Type 77
Keyswitch**

- Assign to zone wired to a keyswitch.

**Types 90-93
Installer Defined**

- These zone types can be programmed for various custom responses. See data fields *182-*185.

*The system can still be armed when these zone types are in a faulted condition.

Schedules (installer code + [#] + [6] [4]; *master code can only access schedules 01-16 and events 00-07*)

No.	Event (see list below)	Device No. for "01" events: enter 01-18	Group No. for "02" events: enter 1-8	Partition for "04-06" events: enter 1, 2, or 3	Start Time/ Days	Stop Time/ Days	Repeat (yes/no)	Random (yes/no)
00								
01								
02								
03								
04								
05								
06								
07								
08								
09								
10								
11								
12								
13								
14								
15								
16								
17								
18								
19								
20								
21								
22								
23								
24								
25								
26								
27								
28								
29								
30								
31								
32								

Events: Master/Installer

01 = device on/off
02 = user access
03 = latch key report
04 = forced STAY arm

05 = forced AWAY arm
06 = auto disarm
07 = display "reminder"

Installer Only

10 = display custom words 8-10
11 = periodic test report
12 = up and about (large time window within which time selected in field *175 is monitored)

ALPHA VOCABULARY LIST (For Entering Zone Descriptors)

000 (Word Space)	• 057 DOOR	– L –	– R –	– V –
– A –	• 059 DOWN	• 106 LAUNDRY	155 RADIO	209 VALVE
• 001 AIR	• 060 DOWNSTAIRS	• 107 LEFT	• 156 REAR	210 VAULT
• 002 ALARM	061 DRAWER	108 LEVEL	157 RECREATION	212 VOLTAGE
004 ALLEY	• 062 DRIVEWAY	• 109 LIBRARY	159 REFRIGERATION	– W –
005 AMBUSH	• 064 DUCT	• 110 LIGHT	160 RF	213 WALL
• 006 AREA	– E –	111 LINE	• 161 RIGHT	214 WAREHOUSE
• 007 APARTMENT	• 065 EAST	• 113 LIVING	• 162 ROOM	• 216 WEST
• 009 ATTIC	066 ELECTRIC	• 114 LOADING	163 ROOF	• 217 WINDOW
010 AUDIO	067 EMERGENCY	115 LOCK	– S –	• 219 WING
– B –	068 ENTRY	116 LOOP	164 SAFE	220 WIRELESS
• 012 BABY	• 069 EQUIPMENT	117 LOW	165 SCREEN	– X –
• 013 BACK	• 071 EXIT	• 118 LOWER	166 SENSOR	222 XMITTER
• 014 BAR	072 EXTERIOR	– M –	• 167 SERVICE	– Y –
• 016 BASEMENT	– F –	• 119 MACHINE	• 168 SHED	223 YARD
• 017 BATHROOM	• 073 FACTORY	121 MAIDS	169 SHOCK	– Z –
• 018 BED	075 FAMILY	122 MAIN	• 170 SHOP	224 ZONE (No.)
• 019 BEDROOM	• 076 FATHERS	• 123 MASTER	171 SHORT	• 225 ZONE
020 BELL	• 077 FENCE	• 125 MEDICAL	• 173 SIDE	• 226 0
• 021 BLOWER	• 079 FIRE	126 MEDICINE	174 SKYLIGHT	• 227 1
• 022 BOILER	• 080 FLOOR	128 MONEY	175 SLIDING	• 228 1ST
023 BOTTOM	081 FLOW	129 MONITOR	• 176 SMOKE	• 229 2
025 BREAK	082 FOIL	• 130 MOTHERS	• 178 SONS	• 230 2ND
• 026 BUILDING	• 083 FOYER	• 131 MOTION	• 179 SOUTH	• 231 3
– C –	084 FREEZER	132 MOTOR	180 SPRINKLER	• 232 3RD
028 CABINET	• 085 FRONT	– N –	• 182 STATION	• 233 4
• 029 CALL	– G –	• 134 NORTH	184 STORE	• 234 4TH
030 CAMERA	• 089 GARAGE	135 NURSERY	• 185 STORAGE	• 235 5
031 CAR	• 090 GAS	– O –	186 STORY	• 236 5TH
033 CASH	091 GATE	• 136 OFFICE	190 SUPERVISED	• 237 6
034 CCTV	• 092 GLASS	• 138 OPEN	191 SUPERVISION	• 238 6TH
035 CEILING	093 GUEST	139 OPENING	192 SWIMMING	• 239 7
036 CELLAR	094 GUN	• 140 OUTSIDE	193 SWITCH	• 240 7TH
• 037 CENTRAL	– H –	142 OVERHEAD	– T –	• 241 8
038 CIRCUIT	• 095 HALL	– P –	194 TAMPER	• 242 8TH
• 040 CLOSED	• 096 HEAT	143 PAINTING	196 TELCO	• 243 9
• 046 COMPUTER	098 HOLDUP	• 144 PANIC	197 TELEPHONE	• 244 9TH
047 CONTACT	099 HOUSE	145 PASSIVE	• 199 TEMPERATURE	245 Custom Word #1
– D –	100 INFRARED	• 146 PATIO	200 THERMOSTAT	246 Custom Word #2
• 048 DAUGHTERS	• 101 INSIDE	147 PERIMETER	• 201 TOOL	247 Custom Word #3
049 DELAYED	102 INTERIOR	• 148 PHONE	202 TRANSMITTER	248 Custom Word #4
• 050 DEN	103 INTRUSION	150 POINT	– U –	249 Custom Word #5
051 DESK	– J –	151 POLICE	• 205 UP	250 Custom Word #6
• 052 DETECTOR	104 JEWELRY	152 POOL	• 206 UPPER	251 Custom Word #7
• 053 DINING	– K –	• 153 POWER	• 207 UPSTAIRS	252 Custom Word #8
054 DISCRIMINATOR	• 105 KITCHEN		• 208 UTILITY	253 Custom Word #9
055 DISPLAY				254 Custom Word #10

Note: Bulleted (•) words in **boldface type** are those that are also available for use by the 4285/4286 Phone Module. If using a Phone module, and words other than these are selected for Alpha descriptors, the module will not provide annunciation of those words.

CHARACTER (ASCII) CHART (For Adding Custom Words)

32 (space)	41)	50 2	59 ;	68 D	77 M	87 W
33 !	42 *	51 3	60 <	69 E	78 N	88 X
34 "	43 +	52 4	61 =	70 F	79 O	89 Y
35 #	44 ,	53 5	62 >	71 G	80 P	90 Z
36 \$	45 –	54 6	63 ?	72 H	81 Q	
37 %	46 .	55 7	64 @	73 I	82 R	
38 &	47 /	56 8	65 A	74 J	83 S	
39 '	48 0	57 9	66 B	75 K	84 T	
40 (49 1	58 :	67 C	76 L	85 U	
					86 V	

5800 Series Transmitter Input Loop Identification

- All of the transmitters illustrated below have one or more unique factory assigned input (loop) ID codes. *Each of the inputs requires its own programming zone* (e.g., a 5804's four inputs require four programming zones).
- Transmitter inputs entered as:

"RF" (Supervised RF) Type send periodic check-in signals, as well as fault, restore and low battery signals. The transmitter must remain within the receiver's range.

"UR" (Unsupervised RF) Type send all the signals that the "RF" Type does, but the control does not supervise the check-in signals. The transmitter may, therefore, be carried off-premises.

"BR" (Unsupervised Button RF) Type only send fault signals. They do not send restore or check-in signals. They will indicate a low battery condition when tested or activated normally. The transmitter may be carried off-premises.

Note: For information on any transmitter not shown above, refer to the instructions accompanying that transmitter for details regarding loop numbers, etc.

UL NOTE: The 5802MN, 5802MN2, 5804, 5804BD, 5814, 5816TEMP, 5819, 5819WHS & BRS, 5827BD, and 5850 transmitters are not intended for use in UL installations




Table of Device Addresses

Address	Report†	Device	Programmed by...
00	100	RF Receiver	*56 zone programming: input device type entry
03	103	Long Range Radio	automatic if output to long range radio field *29 enabled
04	104	4286 Voice Module	automatic if phone module access code field *28 enabled
07	107	Zone Expanders (4219/4229):	*56 zone programming: input device type entry, then:
08	108	module 1 zones 09 - 16	
09	109	module 2 zones 17 - 24	
10	110	module 3 zones 25 - 32	
11	111	module 4 zones 33 - 40	
12	112	Relay Modules (4204):	*79 output device programming: device address prompt:
13	113	module 1	
14	114	module 2	
15	115	module 3	
16	n/a	Touchpads:	data filed programming as listed below:
17	n/a	touchpad 1	
18	n/a	touchpad 2	
19	n/a	touchpad 3	
20	n/a	touchpad 4	
21	n/a	touchpad 5	
22	n/a	touchpad 6	
23	n/a	touchpad 7	
28	n/a	5800TM Module	automatic

† Addressable devices are identified by "1" plus the device address when reporting. Enter report code for zone 91 to enable addressable device reporting (default = reports enabled). See field *199 for addressable device (ECP) 3-digit/2-digit identification touchpad display options.

