

7kg Washing Machine

L712WM20



Contents

Safety Warnings	3
Unpacking	5
Removing the Transit Bolts	6
Installing Your Washing Machine	7
Choosing the Right Location for Your Washing Machine	7
Hose and Cable Lengths.....	8
Levelling the Washing Machine	8
Water Supply Hose.....	8
Connecting to the Mains Supply	9
First time use	9
Product Overview	10
The unit	10
Control Panel	11
Preparation	12
Preparing Laundry	12
Adding Detergent and Softener	12
Selecting the Programme	13
Selecting an Energy Efficient Programme	15
Which Detergent to Use	16
Wash Setting	16
First washing operation	16
Standard Washing	16
Manual Soaking	17
Half-load detection system.....	17
Optional Functions.....	17
Washing Water Temperature Selection	17
Spin Speed.....	17
Delay Timer.....	18
How to Set the Child Lock	18
Selecting a Rapid Wash	18
Removing Laundry	18
Maintenance - Cleaning the Washing Machine	19
Cleaning the Drum	19
Cleaning the Exterior of your Washing Machine	19
Cleaning the Detergent Drawer and Siphon Plug.....	19
Cleaning the Door Seal and Window	20
Cleaning the Drain Filter.....	20
Troubleshooting	21
Error Codes	23
Energy Saving Tips	24
Specification	26

Safety Warnings

IMPORTANT SAFETY INSTRUCTIONS READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

WARNING!

- If you will not be using the washing machine for a while such as when you go on holiday, turn off the water supply to the washing machine. This is particularly important if there is no drainage around the washing machine. If the water is left on, water pressure may build up and cause a leak.

General Use

- This washing machine is for household (domestic) use only.
- Do not install your washing machine anywhere that is damp or exposed to the weather. If you do, it may cause an electric shock, fire, failure or deterioration.
- Keep flammable substances well away from the washing machine. They may cause an explosion or a fire.
- Before you start using the washing machine, turn the tap on to check that the hose is properly connected. If it's not, there may be a water leak.
- Do not put too much laundry or detergent into the washing machine. It may cause issues with the washing machine or laundry.

Power Source and Cable

- Make sure your home voltage matches the voltage displayed on the washing machine. If you are not sure, contact an electrician.
- Use an independent household dedicated mains socket, rated at 13 Amp 220V to 240V AC. If the washing machine is plugged in with other appliances, it may overheat and cause a fire.
- Make sure the mains plug is pushed firmly into the socket. A loose connection may overheat and cause electrical shock or a fire.
- Do not use a mains plug adaptor or extension cable. It may overheat and cause a fire.
- The mains plug must remain accessible to allow disconnection or an all pole switch must be incorporated in the fixed wiring in accordance with the wiring rules.
- Check the mains lead and mains plug for any damage. If the mains cable is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Unplug the mains lead when cleaning the washing machine.

- Do not touch the mains lead or mains plug with wet hands. It may cause an electric shock.
- Check the mains plug regularly for dirt. If dirt accumulates on the mains plug, it could cause a fire. To prevent this, unplug the cable and clean the mains plug with a dry cloth.
- If you disconnect the mains plug, hold onto the mains plug not the cable. Pulling the cable may cause an electric shock or a fire.

To Prevent Injury / Damage

- When opening and closing the door ensure you keep fingers away from the door hinge.
- Do not wash, rinse or spin water-proof sheets or clothing. These may cause vibration or washing machine failure during spin-drying, which could lead to injury, damage to the washing machine or damage due to water leaking.
- Be careful when draining hot water or any detergent from the washing machine.
- The glass window can become very hot when using some wash cycles, take care when touching the window. Do not allow children to touch the window when in use.
- Do not dismantle, repair or modify the washing machine. This may invalidate your guarantee and could lead to a malfunction and cause fire or injury.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Children of less than 3 years should be kept away unless continually supervised.
- The mains water pressure must be 0.1MPa - 1MPa.
- The appliance is to be connected to the water mains using the new hose-set supplied. Old hose-sets should not be reused.
- Do not connect to the hot water supply.

- The ventilation openings in the base of the washing machine must not be obstructed by a carpet.
- Ensure the transit bolts are removed before installation.



IT IS HAZARDOUS FOR ANYONE OTHER THAN AUTHORISED SERVICE PERSONNEL TO CARRY OUT SERVICING OF REPAIRS WHICH INVOLVE THE REMOVAL OF COVERS.




TO AVOID THE RISK OF AN ELECTRICAL SHOCK DO NOT ATTEMPT REPAIRS YOURSELF.


Unpacking

Remove all packaging from the unit. Retain the packaging. If you dispose of it please do so according to local regulations.


The following items are included:



The Main Unit




Transit Bolt Cover Cap x 4



Water Supply Hose x 1



U-Shape Drain Hose Holder x 1
For fixing the water drain hose.



Liquid detergent guide x1



If items are missing, or damaged please contact Partmaster (UK only).
Tel: 0344 800 3456 for assistance. Parts are available from 10 years after purchase.

INSTALLATION


Removing the Transit Bolts

Four transit bolts keep the interior of the washing machine in place while it's being moved.

They need to be removed before installation. Use a spanner (not supplied) and follow the instructions detailed below.



Don't run the washing machine without removing the transit bolts, as this can cause excessive vibrations and may damage your machine.




To remove the transit bolts:

1. Ensure the unit is fully disconnected from the mains power by unplugging it from the mains.
2. Unscrew the four (4) transit bolts.
3. They are located at the rear side of the washing machine. Use a spanner (not included) to loosen the four (4) transit bolts, then pull out the bolts horizontally. Ensure the plastic bolt guides (if any) are also removed.
4. Snap in the plastic caps to cover the transit bolt holes.



Keep the four (4) transit bolts in a safe place, in case you need to move the washing machine.



* All images are for indication only; please refer to your individual unit for actual item.

Installing Your Washing Machine

Please read and follow the instructions carefully.

- In addition to the instructions mentioned here, special regulations of the relevant water and power supply companies may apply. If in doubt, have the washing machine connected by a qualified technician.
- The washing machine is heavy - caution when lifting it. Do not lift by projecting components (e.g. washing machine door).
- Warning: Frozen hoses may tear/burst. Do not install washing machine in outdoor areas or where there is a risk of frost.
- Lay hoses and cables in such a way that there is no risk of trapping or kinking.



Additional space (approximately 60mm) is required for the rear of the washing machine. This is to allow enough space for the water hose and drain hose connections.

Choosing the Right Location for Your Washing Machine

- Make sure there's enough space for your washing machine.
- Install your washing machine on a flat, stable surface to avoid excessive vibration and noise.
- The ventilation openings in the base of the washing machine must not be obstructed by carpet.



Two or more people are required to move the washing machine.


- Start by tilting the washing machine backwards.
- One person should stand behind it, holding the rear of the top panel. The other person should grip the bottom feet at the front.
- We recommend that you entrust the installation of the washing machine to a qualified technician.

INSTALLATION

Hose and Cable Lengths


How to connect from the left side

How to connect from the right side




Levelling the Washing Machine


There are 4 levelling feet on the underside. They **MUST** be adjusted to make sure the washing machine is level.




On each foot, loosen the lock ring by turning clockwise.



Adjust all four feet by rotating each upwards or downwards.



Use a spirit level to ensure the washing machine is level.



Tighten each lock ring by turning them anti-clockwise (towards the washing machine body).

Ensure all four lock rings are tightened securely. Check the feet are still bolted to the washing machine - if they're unbolted, the washing machine will move around.

Water Supply Hose

Points to remember




- Follow the instructions in this section to avoid water leaks.
- Don't connect the hose to a combination tap.
- Don't twist, squash, modify or cut the hose.
- This machine is designed to connect to the cold water supply. Do **not** connect to the hot water supply.
- Use only the new water supply hose supplied. Old hose sets should not be reused.
- The mains water pressure must be 0.1MPa - 1MPa.
- If your washing machine is delivered in freezing weather conditions, leave it at room temperature for 24 hours after you've set it up before using it. This ensures there's no ice blocking the water supply hose. If your water supply hose freezes, add 2 or 3 litres of warm water to the drum. Then run a "Spin" only programme.

* All images are for indication only; please refer to your individual unit for actual item.

INSTALLATION


Connecting the Water Supply Hose

1. To prevent leakage from the connection joints, ensure the rubber washer seals are fitted to each end of the water supply hose. Do not use without the seals in place.
2. Fit the straight end of the water supply hose to the cold water tap.
3. Connect the angled end of the white headed hose to the water inlet valve on the machine. Hand tighten the plastic parts of the connections. If you are unsure, please call a qualified plumber.
4. Open the tap slowly and check that there are no leaks around the connection joints.




Draining to a sink or wash-basin

- Secure the drain hose in position, so it can't drop out of the basin.
- Don't block the basin's drain outlet, and make sure that the drainage through is sufficient to prevent overflowing.
- Don't let the tip of the drain hose dip into the drained water, as this can cause the water to flow back into the washing machine.



Draining to a wash-basin



Draining to a drain hose



When connecting to the drain ensure the blanking plate has been removed.

Connecting to the Mains Supply

For your safety:

- Do not use a mains plug adapter or extension cable.
- If the mains cable or mains plug are damaged, disconnect from the main, stop using them and call a qualified technician for assistance.
- Mains cord of your washing machine is equipped with an Earthed plug. This plug must always be inserted to an earthed socket capable of supplying 13 Amps. If you don't have such a socket and fuses in your house, please call a qualified electrician.

First time use

Some water may be left in your machine due to tests carried out during production. To dispose of this water, it is recommended to perform the first washing operation with the programme (Cotton 90°C) and without laundry by inserting ½ portion of detergent in the main detergent (II) compartment of the detergent drawer.




During initial start-up and use of the unit, there may be a slight smell while the motor is settling in. This is not a fault; this is normal operation.


* All images are for indication only; please refer to your individual unit for actual item.

Product Overview

The unit



Control Panel



If you want to cancel any programme running:


- Switch the programme knob to **OFF** position.
- Your machine will stop the washing operation and the programme will be cancelled. (Ensure the Child Lock is off, otherwise the original programme will continue.)
- To empty the water accumulated in the machine switch the programme knob to any programme.
- Your machine will perform the necessary discharge operation and cancel the programme.
- You can then select a new programme.

Preparation

Read the following to understand how best to prepare your laundry for washing.

Preparing Laundry

- Check that pockets do not contain any objects which may damage your clothes and the washing machine.
- To prevent any large, heavy objects (e.g., buckles, large buttons, etc.) from hitting the glass door, turn your clothing inside out, or remove the heavy objects. These could damage your laundry or the washing machine.
- For small items use a washing net.




Adding Detergent and Softener

- Add detergent into the appropriate dispenser.
- Apply softener before you start washing.
- Apply detergent and softener according to the washing amount, the soiling level, the water hardness in your area and the manufacturer's instructions of these products.
- For slightly dirty clothes, do not pre-wash and put a small amount of detergent in compartment 2 (II) of the detergent drawer.
- For excessively dirty clothes, select a programme including pre-washing, use $\frac{1}{4}$ of the detergent to be used in the detergent drawer in compartment 1 (I) of the detergent drawer and the remaining amount in compartment 2 (II).



Dilute viscous fabric softener and fabric conditioner with water. Prevent blockage of the overflow. Maximum level is 40ml.

If you are using liquid detergent insert the guide



It's recommended to use liquid detergent for the washing programmes at low temperature.

- Do not use washing machine when the detergent drawer is removed. It may cause a water leak or it may not work normally.
- If you forget to add detergent, you can drain the washing machine by running a spin only programme. Then you can add detergent and start the programme again. Detergent only reaches the drum when water flushes through the detergent drawer.
- To prevent powdered detergent staying in the drawer, dry the inside of the drawer with a cloth. Make sure the powder isn't lumpy when you add it into the drawer.
- If the rinse cycle isn't removing all the detergent from your wash, use less detergent.
- Softener should not exceed the MAX level in the compartment.
- Wash out unused softener with a splash of water or a damp cloth after the programme has finished.
- You can use your liquid detergents in all programmes without prewashing. For this, fit the liquid detergent level plate from the accessories bag into the 2nd compartment of the detergent drawer and set the amount of liquid detergent according to the levels on this plate. Remember to detach the liquid detergent plate when done.
- Do not put too much laundry or detergent into the washing machine. It may cause issues with the washing machine or laundry.
- Use detergents, softeners and other additives suitable for automatic washing machines only to prevent excessive foaming.

Selecting the Programme

Here are the available programmes, additional functions and option settings.
Spin speed can be selected separately for certain programmes.

Program			Description	 Prewash Function†		Max Temperature	Max Load (kg)	Preset Setting	
								Default Spin (rpm)	Approximate Time (Min)
Cotton	1	90°C	For average soiled cottons, household linens and work / play clothes.	Available	✓	90°C	7.0*	1200	179
	2	Prewash		Pre set	✓	60°C	7.0*	1200	164
	3	60°C		Available	✓	60°C	7.0*	1200	230
Cotton	4	20°C	For less than average soiled cottons, household linens and work / play clothes.	NOT Available	✓	20°C	3.5**	1200	96
	5	ECO 40-60	Very dirty or synthetic-mixed textiles.	Available	✓	40°C	7.0*	1200	208
	6	Wool	For machine washable woollens.	NOT Available	✓	30°C	2.5	600	39
	7	Rinse	Separate rinse procedure	NOT Available	✗	Water temp	7.0	1200	36
	8	Allergy Safe	For baby laundry	Available	✓	60°C	3.5	800	182
	9	Spin	Separate spin procedure	NOT Available	✗	-	7.0	1200	15
	10	Hand Wash delicate	Laundry recommended for hand wash or sensitive laundry	NOT Available	✓	30°C	2.5	600	90
	11	Easy care / Sport wear	Sportswear	Available	✓	40°C	3.5	1000	110
	12	Mix	Dirty cotton, synthetics, colour and flax textiles can be washed together.	Available	✓	30°C	3.5	800	81
	13	Blouses / Shirts	Dirty cotton, synthetics, and synthetic mixed shirts/blouses can be washed together.	Available	✓	60°C	3.5	600	107
	14	Fast 60'	60 minute wash	NOT Available	✓	60°C	3.0	1200	60***
	15	Rapid 15'	15 minute quick wash for lightly soiled laundry	NOT Available	✓	30°C	2.0	800	15

* Maximum of 3.5kg of towelling material. ** Maximum of 2.5kg of towelling material. *** If 2kg or less of laundry is inserted the wash time will be reduced to 30 mins.



- According to regulations 1015/2010 and 1061/2010, the programme 3 and the programme 4 are respectively the 'Standard 60°C cotton programme' and the 'Standard 40°C cotton programme'.
- The Eco 40-60 programme is able to clean normally soiled cotton laundry declared to be washable at 40°C or 60°C, together in the same cycle, and that this programme is used to access the compliance with the EU ecodesign legislation.
- For all washing programs, please following the detergent recommendations on the garment label or on the detergent's packaging.
- Washing times depend on the program type, ambient water temperature and wash load (weight and type).
- Energy and water consumption will vary according to wash load and type, extra functions, tap water and ambient temperatures.
- The actual water temperature may differ from the declared cycle temperature.
- Your washing machine will automatically detect if you have only inserted half a load or less of laundry, it will automatically reduce the washing time, water consumption and energy in some programs.
- Your washing machine has an Auto Balance feature. Washing times will be longer if the laundry in the drum needs to be balanced.

Selecting an Energy Efficient Programme

The table below will help you choose a programme that will give you the best energy efficiency, with regards to the amount of electricity used or water consumed by each cycle

Program	Max Load (kg)	Energy Consumption kWh/Cycle			Programme Duration Hours : Minutes			Water Consumption Litres/Cycle			Max Temperature °C			Remaining Moisture Content %		
		Rated Capacity	1/2 Load	1/4 Load	Rated Capacity	1/2 Load	1/4 Load	Rated Capacity	1/2 Load	1/4 Load	Rated Capacity	1/2 Load	1/4 Load	Rated Capacity	1/2 Load	1/4 Load
Cotton	90°C	7	2.22		02:59			76			81			53		
	60°C	7	1.19		03:50			52			43			53		
	20°C	3.5	0.2		01:36			43			20			53		
ECO 40-60	7	1.16	0.40	0.30	03:28	02:40	02:40	38	30	25	50	27	23	53	53	53
Easy care / Sport wear	3.5	0.49			01:50			44			42			62		
Fast 60'	3	0.99			01:00			31			58			53		

Wash times / Temperatures / Moisture Content may vary depending on the material type/quantity being washed.

Which Detergent to Use

The care label is crucial to ensure correct detergent selection, temperature and laundry treatment.

Washing and type of textile	Washing temperature	Detergent
Boil washable white washing made of linen or cotton	30°C - 90°C (Max)	Standard detergent containing bleach and optical brighteners
Coloured washing made of linen or cotton	30°C - 60°C (Max)	Colour detergent without bleach and optical brighteners
Coloured washing made of easy-care fibres, synthetic materials	30°C - 60°C (Max)	Colour/mild detergent without optical brighteners
Delicate fine textiles, silk or viscose	30°C - 40°C (Max)	Mild detergent
Wool	30°C - 40°C (Max)	Detergent for woollens

Wash Setting

First washing operation

Some water may be left in your machine due to tests carried out during production. To dispose of this water, it is recommended to perform the first washing operation with the programme (Cotton 90°C) and without laundry by inserting ½ portion of detergent in 2nd compartment of the detergent drawer.




During initial start-up and use of the unit, there may be a slight smell while the motor is settling in. This is not a fault; this is normal operation.

Standard Washing

1. Pull the door handle and put the laundry in the drum. Make sure no laundry gets caught in the door.
2. Close the door and turn the **Programme Dial** to select your wash programme and water temperature.
3. Adjust the temperature (if required). The temperature can not be set higher than the programmes set temperature.
4. Adjust the Spin Speed (if required).
5. Select any Optional Functions.
6. Add detergent into the detergent drawer. The quantity of detergent will depend on the amount of laundry, the degree of soiling and the water hardness. Use the amount of detergent suggested on the packaging of the detergent.




It's recommended to use liquid detergent for the washing programmes at low temperature.



To pause the programme you have selected, press the **Start / Pause** button. The Start/Pause symbol will blink when the machine is in pause mode.

7. Press the **Start / Pause** button to start the washing.
8. **End** will be displayed when the programme is complete.



- If the door is locked and you switched the washing machine off - or if there's a power cut - it will stay locked for 2 minutes.
- If the machine is full of water, do not open the door.

Manual Soaking

To manually soak your laundry, press the **Start / Pause** button a few minutes after the wash programme has started when the drum is full of water. The washing machine will suspend the laundry to soak it in the water. After your desired soaking time, press the **Start / Pause** button, the machine will continue the previous wash.

Half-load detection system

Your machine features a half-load detection system. In case you load machine to approximately half or less than the maximum laundry capacity, your machine will run so as to save washing time, water consumption and energy in some programmes. When half load function is active, the machine can complete the programme you have set in a shorter time.

Optional Functions

Depending on the programme you select, you can combine different optional functions.

- Press the button of the optional function you would like to select.
- If the indication of the function button remains lit it means that the function has been selected.
- If the indication of the function button is flashing it means you cannot use that additional function for the wash programme you selected.

Reason for non-activation:

- The optional function you want to use in the washing programme you have selected is not applicable.
- Your machine has passed the stage, during which the optional function you want to select would be implemented.
- It is not compatible with an optional function you have selected previously.

Washing Water Temperature Selection

You can select the washing water temperature with the **Temp** button.

You can gradually decrease the washing water temperature between the maximum temperature of the selected programme and cold washing by repeatedly pressing the **Temp** button.

If you have missed the washing water temperature you want, continue and the temperature selection will loop back around.

Temperature Cycle

90° - 60° - 40° - 30° - and -- (cold)




Spin Speed

You can adjust the spin speed by pressing the **Spin** button. Only a lower spin speed than the one of the selected program can be selected.

Spin speeds selectable are:

1200 - 1000 - 800 - 600 - 400 - or -- (no spin)




- The higher the spin speed the noisier the spin cycle will be.
- The higher the spin speed the lower the remaining moisture content in the laundry after spinning.

Delay Timer

You can set a delay timer on your wash programme. The delay timer will start then start the wash programme after the time that you set has expired. For example the time is now 4pm and you set a 2 hour delay timer, your washing programme will start at 6pm.

- Press the **Delay Timer** button to cycle through the delay times starting from 1 hour up to 23 hours.



How to Set the Child Lock

The Child Lock prevents children from stopping programmes accidentally. It only locks the control buttons not the **Programme Dial**.

Switch the washing machine on.

- When the washing machine is operating, press and hold **Delay** and **Rapid Wash** button for 3 seconds. The letters 'CL' will be displayed for a few seconds showing the child lock is active. If any button is pressed or the Programme Dial is turned the letters 'CL' will flash in the display.
- Press the buttons for 3 seconds to unlock, and switch child lock off.



Selecting a Rapid Wash

On some programmes you can select to add a Rapid Wash to the programme, this will reduce that wash time. Press the Rapid Wash button to add a Rapid Wash. The  symbol will appear in the display. If the  symbol flashes then disappears from the display its not possible to add a Rapid Wash to the selected wash programme.



- It's recommended that you only use the Rapid Wash functions when washing less than half the maximum load weight for the selected programme.
- Using Rapid wash can reduce the energy and water consumption of your washing machine.

Finishing programme

- Your machine will stop by itself as soon as the programme you have selected finishes.
- The door lock will release and the **End** show in the display.
- Turn the **Programme Dial** back to OFF.



- Never force the door open when your Washing Machine is running. You can open the door of your machine 2 minutes after the completion of a washing operation.

Removing Laundry

- Open the washing machine door and remove your laundry.
- Remove any foreign objects to avoid risk of rusting.
- Leave the door and detergent drawer open so that residual water can evaporate.
- If you have finished using the washing machine, turn off the water and mains supply.

Maintenance - Cleaning the Washing Machine



Always unplug the washing machine before cleaning.

Cleaning the Drum

- Rust left inside the drum by metal articles should be removed immediately with chlorine-free detergent.
- Never use steel wool.
- We recommend that periodic cleaning for washing machine every 2 months. For periodic cleaning please use the Cottons-90 programme. When required, use limescale removers manufactured specifically for washing machines only.




Don't put laundry in the washing machine during the drum cleaning.

Cleaning the Exterior of your Washing Machine

- Clean the outside of your washing machine with a soft cloth and mild detergent such as kitchen detergent.
- Don't splash water over the washing machine.
- Do not use cream cleansers, thinners or products containing alcohol or kerosene.

Cleaning the Detergent Drawer and Siphon Plug

1. Remove the detergent drawer by pulling and pressing gently on the rear centre part of the softener compartment.
2. Wash out old detergent from the drawer with water. (Use a cloth to clean the washing machine.) Residue detergent soon builds up if you don't clean the drawer regularly, and can develop mould.
3. Return drawer to original position.



4. Disassemble the detergent drawer. Remove the siphon plug and clean the any residual softener thoroughly. Replace the cleaned siphon plug and check that it is fitted properly.

* All images are for indication only; please refer to your individual unit for actual item.

Cleaning the Door Seal and Window

- Wipe the window and seal after each wash to remove lint and stains. If lint builds up, it can cause leaks.
- Remove any coins, buttons and other objects from the door seal after each wash.


Cleaning the Drain Filter




Be careful not to burn yourself as water in the pump may be hot after a high temperature wash.

Before cleaning the drain filter, first start the spin programme, then switch off and unplug the washing machine.

1. Gently Open the Service Flap. Place a suitable container under the service flap to catch the water.



2. Carefully loosen the drain filter. Turn anti-clockwise until the water gently begins to run out, this is normal.
3. Remove the filter once the water has stopped.
4. Remove any lint and debris before carefully replacing the filter.



5. Turn the filter clockwise and screw the filter back into place.
6. Close the service flap.

* All images are for indication only; please refer to your individual unit for actual item.

Troubleshooting

Problem	Possible Causes	Remedy
Your machine does not start.	It is not plugged in.	Plug it in and switch on at the mains.
	Fuse blown.	Replace the fuse.
	Power cut.	Check mains power.
	Start/Pause button not pressed.	Press on Start/Pause button.
	The door is not closed properly.	Close the door.
	Programme dial is in the 'stop' position.	Turn the programme dial to the desired position.
Your machine does not intake water.	Water tap is turned off.	Turn your water tap on.
	Water inlet hose may be twisted.	Check water inlet hose and untwist.
	Water inlet hose clogged.	Clean water inlet hose filters.
	Valve inlet filter clogged.	Clean the valve inlet filters.
	The door is not closed properly.	Close the door.
Your machine does not discharge water.	Discharging hose is clogged or twisted.	Check the discharging hose, then either clean or untwist it.
	Pump filter clogged.	Clean the pump filter.
Your machine vibrates.	The machine is not level.	Adjust the feet and level the machine.
	The transit bolts are still in place.	Remove the transit bolts.
	You have only loaded a very small load so the drum is unbalanced.	Add more laundry.
	Your machine is overloaded or not loaded correctly.	Remove some laundry and load the drum correctly.
Excessive foam is formed in the detergent drawer.	Excessive amount of detergent used.	Press on Start/Pause button. To eliminate foam formation, mix a spoon of softener with half a litre of water, and pour the mixture in the detergent drawer. After 5-10 minutes, press on Start/Pause button again. In your next washing operation, adjust the detergent dose accordingly.
	Wrong detergent used.	Use detergents produced only for automatic washing machines in your machine.

Problem	Possible Causes	Remedy
Unsatisfactory washing result.	Your laundry is too soiled for the wash programme you have chosen.	Choose a programme that is suitable.
	Amount of detergent used is insufficient.	- Adjust the amount of detergent based on the amount the laundry is soiled. - Check your detergent instructions, make sure you are adding the correct amount for the weight of your load.
	You're machine is overloaded.	Load the correct weight of laundry. Check the programme table. Not all programmes allow 12kgs of laundry.
	The water in your area may be very hard.	Check the detergent guidelines, you may need to increase the amount of detergent used.
	You may not have loaded your laundry evenly.	Load your laundry correctly.
You can't see water in the drum during washing.	No fault. Water is in the unseen part of the drum.	-
The laundry has detergent residue after washing.	Non-dissolving particles of some detergents may stick to your laundry and show as white spots.	Perform an extra rinse by setting your machine to "Rinse" programme, or clean the spots using a brush after your laundry is dry.
Grey spots appear on the laundry.	The reason for such spots may be oil, cream or ointment.	Apply the maximum amount of detergent instructed by the detergent manufacturer in the next washing operation.
Spinning operation is not performed or runs late.	No fault. Unbalanced load control system has been activated.	Unbalanced load control system will try to spread your laundry by tumbling for a while. Spinning operation will begin after your laundry is spread. Place the laundry in the machine in a balanced fashion the next time.

Error Codes

Your washing machine has some built-in error codes. If it stops working properly the table below shows you which lights will be illuminated and what the possible fault is.

Problem	Possible Fault	What to do
E01	The door of your machine is not shut properly.	Shut the door properly until you hear a click. If your machine persists to indicate the fault, turn off your machine, unplug it and contact the nearest authorised service agent immediately.
E02	The water pressure or the water level inside the machine is low.	Check the tap is fully turned on. Mains water may be cut-off. If the problem still continues, your machine will stop after a while automatically. Unplug the machine, turn off your tap and contact the nearest authorised service agent.
E03	The pump is faulty or pump filter is clogged or electrical connection of the pump is faulty.	Clean the pump filter. If the problem persists, contact the nearest authorised service.
E04	Your machine has excessive amount of water.	Your machine should automatically pump excess water out, if it doesn't contact the nearest authorised service.

Energy Saving Tips

- The most efficient programmes in terms of energy consumption are generally those that perform at lower temperatures and longer duration.
- Loading the household washing machine up to the capacity indicated by the manufacturer for the respective programmes will contribute to energy and water savings.
- Program duration, energy consumption and water consumption values may vary according to wash load weight and type, selected extra functions, tap water and ambient temperature.

Specification

Brand	Logik
Model	L712WM20
Product Type	Washing Machine
Rated Voltage	220 - 240V~
Rated Frequency	50 Hz
Rated Power Input	2100 W
Dimensions of the Product	597mm (W) x 497mm (D) (excluding controls and door) x 845mm (minimum) (H)
Weight of the Product	56.6 kg
Maximum Mass of Dry Cloth	7 kg (Cotton programmes only)
Pressure of Tap Water	0.1 MPa - 1 MPa

Features and specifications are subject to change without prior notice.



To view energy information about to your product scan the QR code on your Energy Label.

All the support you need.

currys.co.uk

UK: 0344 561 1234

Ireland: 1890 818 575



Visit Partmaster.co.uk today for the easiest way to buy electrical spares and accessories. With over 1 million spares and accessories available we can deliver direct to your door the very next day. Visit www.partmaster.co.uk or call **0344 800 3456** (UK customers only) Calls charged at National Rate.



The symbol on the product or its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste for recycling, please contact your local authority, or where you purchased your product.

DSG Retail Ltd. (co. no. 504877)
1 Portal Way, London, W3 6RS, UK

EU Representative
DSG Retail Ireland Ltd (259460)
3rd Floor Office Suite
Omni Park SC, Santry, Dublin 9, Republic of Ireland

IB-L712WM20-210129V2