

FRIDJA F500 PORTABLE BLENDER

Safety Warnings

Please follow these concise safety instructions for your blender to ensure its proper use and longevity:

- For domestic use only!
- Fully charge before use.
- Read all instructions and warnings before use.
- Handle the f500 Portable Blender with care and never touch the blades directly.
- Ensure the blender is fully assembled before use and do not operate with a damaged blade.
- Do not blend hot or carbonated liquids, or overfill the blending vessel.
- Although it is okay to wash the base by hand, never immerse the motor base in water.
- Always clean and dry parts before use.
- Avoid using metal scrubbers or dishwashers for cleaning to prevent damage.
- Keep the blender dry before charging and do not attempt to repair or disassemble it yourself.
- Supervise when using around children and those with reduced physical abilities.
- Use only the provided or recommended accessories and attachments.

- Never operate the appliance empty or leave it unattended while in use.
- Allow the blender to stop completely before removing the lid or vessel.

For any issues, consult the instruction manual and contact Fridja customer support as needed. Keep these instructions saved for future reference.

Do not put in the dishwasher, freezer or microwave!



Battery Safety

- The battery serves as the power source for the Fridja f500 Portable Blender. Please ensure you read and adhere to all charging instructions carefully.
- Do not burn this appliance under any circumstances, even if severely damaged. Lithium-ion batteries may explode if exposed to fire. Always recycle lithium-ion battery-powered products properly.
 - The batteries in this appliance are non-replaceable by the user.
 - To check the battery level, connect the device to USB power and observe the indicator lights. A fully green light signifies a full charge.

FRIDJA F500 PORTABLE BLENDER

How To Use



- Step 1**
Pour a drinkable liquid (water, milk, juice, etc.) into the blender, then add softer ingredients first.
- Step 2**
Add frozen ingredients and ice cubes last, then fill the liquid to approximately 80% capacity.



- Step 3**
Secure the lid and tilt the blender downward to ensure that fruit pieces are not trapped beneath the blades.
- Step 4**
To blend, press the upper button twice for clockwise mode or the lower button twice for anti-clockwise mode.

To stop the blender at any time during operation, press any button once.

Additional Tips



- Attach the bottom lid**
Savour your tasty juice or smoothies wherever you go.
- F500 Contents Include**
Cap, Jar, Detachable Filter, Base, Bottom Lid, USB-C Charging Cable, Instruction Manual, Box



- The USB port is waterproof. However, do not submerge the base in water or place it in the dishwasher, as this can lead to water damage and harm the battery.
- Do not blend hard-shelled fruits, nuts, stones, hard skin or large chunks of frozen fruits. Cut fruits and vegetables into 1-inch pieces to prevent the blades from jamming and activating the blockage protection.

FRIDJA F500 PORTABLE BLENDER

Troubleshooting and Malfunction Analysis

Issue	Explanation	Troubleshooting
Unable to operate; red and yellow lights flashing.	Battery has run out of charge.	Ensure a full charge by charging it for 3 to 4 hours.
Unable to operate; red lights flash eight times.	Setup incorrectly.	Secure the jar and base tightly, ensuring that the arrow on the bottle aligns with the power button.
Ceases operation; all indicator lights flash red for 8 seconds.	Motor overload protection activates due to thick ingredients or excessive volume.	Add liquid, blend in batches, or cut fruit into smaller pieces, then restart the blender.
Leakage.	The seal is improperly positioned; the jar or cap is cross-threaded.	Inspect seals and ensure proper thread alignment when attaching the jar or cap.
Unable to achieve full recharge within 4 hours.	The recharging cable or adapter is incompatible.	Verify the compatibility of the charging adapter or cable, ensuring it supports 5V/2A.

Guarantee

This guarantee applies to items purchased directly from Fridja. Contact us within 14 days of delivery for refunds on unused items with all accessories and packaging. Goods are your responsibility until they reach us, so pack them carefully. We offer a 12-month warranty covering defects; contact us for repairs or replacements. For damaged goods, inform us within 24 hours with photos for assessment. Securely package returns using a trackable service. Warranty void if items are misused or resold.

Contact info@fridja.com for returns.

UK REGISTERED ADDRESS
12 CELIA ROAD
LONDON
UNITED KINGDOM

EU REGISTERED ADDRESS
77 CAMDEN STREET
DUBLIN 2, D02 XE80
REPUBLIC OF IRELAND



f500 PORTABLE BLENDER



Thank you so much for purchasing a Fridja f500 Portable Blender! **Please fully charge this before your first use! It's important.**

Once fully charged (the green indicator will be full without any red showing), you are ready to blend!

Quick Guide

- Begin with a simple recipe, such as a smoothie!
- Add liquid first (water, juice, or milk), followed by softer ingredients, and then add ice or frozen fruits last. Do not overload.
 - Secure the lid tightly, make sure the blender is on a stable surface. Begin the blending program by double pressing the clockwise button (top one).
 - Once the cycle is over, enjoy! Use the bottom lid to transport.
 - After use, clean the blender promptly to maintain its optimal condition.

Brand: Fridja
Model: f500/BLK
Instruction Manual: 1.0
Capacity: 700ml
Base Material: ABS
Blending Voltage: 12V
Power: 240W
Charging Voltage/Current: 5V / 2A
Battery Type / Capacity 18650 / 2000 mAh*3
Charging Time: 4/5 Hours
Cycle Program: 30 Seconds

