



Prevent water and ice damage at home.

Ring Flood & Freeze Sensor is a smart sensor for your Ring Alarm system. Place it anywhere you want to monitor for flooding or freezing conditions.

On the bottom of the Sensor, you'll see flood sensors that can tell when water is present. Inside, a temperature sensor keeps watch for dangerously low temperatures (around 40 °F or 4.4 °C).

When either of these conditions occur, the Ring app notifies you so you can take care of the issue.

Contents

1. Diagram To add devices to your Ring Alarm, it must be disarmed. If your Ring Alarm is armed, please disarm it now.

2. In-app Setup In the Ring app, tap **Set Up a Device** and find Ring Flood & Freeze Sensor in the **Security Devices** menu.

3. Physical Installation To complete the setup process, follow the in-app instructions.

4. Additional Information

When prompted, scan the QR code or enter the PIN.

This begins the pairing process. The QR Code and PIN are on the back of your sensor and in the product packaging.

1. Diagram

2. In-app Setup

3. Physical Installation

4. Additional Information

Diagram

1.

Say hello to your Ring Flood & Freeze Sensor in the Ring app.

2.

When prompted, open the lid and pull out the clear tab.

Twist the lid to the left to unlock, then lift it to remove. Next, pull out the clear battery tab. This turns on the Sensor.

Your Base Station finds it automatically.

1.

When prompted, scan the QR code or enter the PIN.

2.

When prompted, open the lid and pull out the clear tab.

Diagram

1.

When prompted, scan the QR code or enter the PIN.

2.

When prompted, open the lid and pull out the clear tab.

Diagram

1.

When prompted, scan the QR code or enter the PIN.

2.

When prompted, open the lid and pull out the clear tab.

Can't scan the QR code?

No problem! In the app, on the scanning screen, tap **Not working? Enter number instead**.

Then, enter the 5-digit PIN code you'll see below the QR code. Next, you'll put your Sensor in manual pairing mode.


To do this, open the Sensor, then remove and reinstall the battery. Finally, press the Setup Button to begin pairing.



Watch your Sensor connect.

As your Sensor pairs to your Base Station, its LED ring blinks slowly, then quickly. Once the Sensor is paired, the LED glows blue for three seconds.

If the Sensor does not pair successfully, the LED ring glows red. To try the pairing process again, remove and reinstall the battery inside the Sensor.



Place your Ring Flood & Freeze Sensor.

Having trouble with your Sensor?

If your Flood & Freeze Sensor stops working or can't connect (even with a good battery), try a factory reset.

To do this, press and hold the Setup button for 10 seconds. When the LED ring stops blinking, the Sensor has reset.

i This process disconnects the Sensor from Ring Alarm. To begin using the Sensor again, repeat the setup process in the Ring app.

Test your Flood & Freeze Sensor.

Close the lid.

Now that your Sensor is set up, bring it to

its LED ring blinks slowly, then quickly.

Once the Sensor is paired, the LED glows

blue for three seconds.

To do this, push the Setup button inside

the Sensor. If the LED blinks blue, the

Sensor is connected and ready to place.

If it blinks red, try the test again. You may

find that repositioning the Sensor (even

just a few inches) can improve reception.

i If the Sensor cannot connect, try installing a

Ring Range Extender between your Sensor

and Base Station.

i To do this, press and hold the Setup

button for 10 seconds. When the LED

ring stops blinking, the Sensor has reset.

Place the Sensor on the ground.

How to remove this Sensor from your system:

Place the lid back on the Sensor, taking

care to line up the semi-circle on the rim

of the lid with the "open" semi-circle on

the base. Twist the lid clockwise to lock

it in.

i If the surface you're placing on is not flat, try

to place your Sensor at the lowest point.

When prompted, open the sensor and

remove and reinstall the battery to

complete the removal.

i If the Sensor cannot connect, try installing a

Ring Range Extender between your Sensor

and Base Station.

i To do this, press and hold the Setup

button for 10 seconds. When the LED

ring stops blinking, the Sensor has reset.

How to replace the battery:

4.

Twist the lid on the Sensor counter-

clockwise and lift to remove. Replace the

battery with a fresh CR123A cell.

The Sensor then reconnects to your Ring

Base Station automatically.

i If the surface you're placing on is not flat, try

to place your Sensor at the lowest point.

LED status patterns:

Water overflow or low temperature detected Blue Blink (1x)

Sensor tampered Red Blink (3x)

For more other LED patterns,

visit ring.com/help.