VOYEE

User Manual

EU REP
Name: Polaris GmbH
Add: Behrmann 38, 49378 Vechelde/
Lindenallee 13, 49356 Diepholz
Tel/Fax: 0049 (0) 2842 4996
Email: support@polaris-eu.com

UK REP
Name: Polaris Global LTD
Add: 2 Kingsway, Cardiff, Wales, Cardiff, CF24 0GZ, UK
Contact Person: Mr. Neil Bowling Ho
Tel/Fax: 0044 (0) 2380 6950
Email: uk@polaris-eu

N-S Wireless Controller

Page 1 Page 2 Page 3 Page 4 Page 5 Page 6 Page 7 Page 8 Page 9 Page 10 Page 11 Page 12 Page 13 Page 14 Page 15 Page 16 Page 17 Page 18 Page 19 Page 20 Page 21 Page 22 Page 23 Page 24 Page 25 Page 26 Page 27 Page 28 Page 29 Page 30 Page 31 Page 32 Page 33 Page 34 Page 35 Page 36 Page 37 Page 38 Page 39 Page 40 Page 41 Page 42 Page 43 Page 44 Page 45 Page 46 Page 47 Page 48 Page 49 Page 50 Page 51 Page 52 Page 53 Page 54 Page 55 Page 56 Page 57 Page 58 Page 59 Page 60

Health and Safety Information

Please read and observe the health and safety information. Failure to do so could result in:

- Electric shock, injuries, fire. Pets should supervise the use of this product by children.

WARNING > Electrical Safety

- Do not expose this product to microwaves, high temperatures or direct sunlight.
- Do not let this product come into contact with liquid and do not use it in wet conditions. If it does, do not attempt to dry it with an external source.
- Do not expose this product to excessive force. Do not pull on the USB cable or bend the cable at a sharp angle.
- Do not dismantle the product while charging. During a thunderstorm, stop using the product, take one smack of a small lightning strike.
- Do not dismantle or try to repair this product. If this product is damaged, do not use it. Do not touch damaged areas. Avoid contact with any leaking liquid.

WARNING > General

- Keep product and all parts of it away from young children as they may swallow the product. USB charging cable can cut around the neck.

CAREFUL USAGE

- If this product becomes dirty, wipe it with a soft, dry cloth. Avoid using thinner or other solvents.

Key Function

For N-S/Lite > Wireless Mode

Steps

❶ In the N-S/Lite main menu, click on Controller > Change grip/order, and enter the Controller pairing mode.

❷ Press and hold the ⓡ "Pairing" or ⓛ "Pair" button for 2-3 SECONDS to enter pairing mode. The LEDs will flash frequently. After the connection is successful the LED beam on.

❸ When the connection is successful, you can press the ⓗ HOME button, and the LEDS will flash slowly in the form of a marquee and automatic calibration.

For N-S/Lite > Wired Mode

Steps

❶ Press the ⓗ HOME key to wake up the consoles.

Note: If the controller is difficult to pair the controller, there may be two reasons: 1.The controller is out of power. Please fully charge the controller and try again. 2.The controller is paired with other consoles. Please turn off the paired consoles manually (Press Display System Setting > Controllers and Sensors > Disconnect Controller > Turn Off).

For N-S/Lite > Wired Mode

To connect the Pro Controller wirelessly, please make sure that the "Pro Controller Wired Communication" is turned on in the system settings of the N-Switch consoles.

❷ When the controller is connected to the base of N-Switch through the USB cable, the "Pro Controller Wired Communication" and the corresponding LED light of the controller will flash slowly.

❸ Unplug the USB cable, the controller turns into the wireless mode, and functionality reconnects to the console.

For PC > Wired Mode

1. Connect the controller to the computer with the USB cable. The LED flashes at the top left for a few seconds, then stay at the same time, and then it is successfully paired.

2. The controller defaults to Input mode (computer mode) - on the PC side, and the keys are not 99 360 key layout.

For PC > Blue-tooth Mode

Steps

❶ Press the ⓛ & ⓡ HOME button at the same time to turn on the controller (To prevent accidental touch, it is recommended to press and hold the ⓛ & ⓡ button first and then press the ⓛ HOME button).



❷ When the LED2 and LED3 flash frequently, the controller enters the search mode.

❸ Turn on the Blue-tooth of phone, enter the search mode, and click on the device to search for the controller of Stamepad to connect.

❹ After successfully connected, LED2 and LED3 keep on, which means the controller can be used normally.

Note: Pro Blue-tooth connection is unstable, and it is recommended to use the wired connection to play.

For Android > Blue-tooth Mode

❶ Press the ⓛ & ⓡ HOME buttons at the same time to turn on the controller (To prevent accidental touch, it is recommended to press and hold the ⓛ & ⓡ button first and then press the ⓛ HOME button).

❷ When the LED2 and LED3 flash frequently, the controller enters the search mode.

❸ Turn on the Blue-tooth of phone, enter the search mode, and click on the device to search for the controller of N-switch consoles to connect.

❹ After successfully connected, LED2 and LED3 keep on, which means the controller can be used normally.

Note: Not all N-S games are compatible with controller, please confirm that the game supports controller before use.

About TURBO Function

Press the ⓣ button and press the △ "Up" / ▽ "Down" arrow on the D-pad at the same time. Once the controller vibrates, the command is successful.

There are 3 burst speeds and auto speeds (5 shots/s, 12 shots/s, 20 shots/s. Default for first connection: 12 shots/s.

5 shots/s: The HOME light flashes slowly (slowly flash for 1 time per second).

12 shots/s: The HOME light flashes in a moderate manner (slowly flash for 2 times per second).

20 shots/s: The HOME light flashes frequently (slowly flash for 4 times per second).

3 types of bursts manual burst and auto burst

1. Manual burst: Press and hold the ⓣ button, and then press the △ button on the D-pad of the Controller buttons to turn on the manual burst.

2. Open auto burst: Press and hold the ⓣ button and then press and hold the button that has turned on the manual burst to turn on auto burst. (burst burst can be paused).

3. Close burst: Press and hold the ⓣ button, and then press and hold the button that has turned on the auto burst to turn off the current button with burst function.

5. Clear all set button burst: Press and hold the ⓣ button and the "Down" arrow on the D-pad. Once the controller vibrates, the burst function of all buttons are closed.

Adjust the burst speed

1.How to increase the burst speed?
Press and hold the ⓣ button and the △ "Up" arrow on the D-pad. Once the controller vibrates, the burst speed is successfully increased.

2.How to reduce the burst speed?
Press and hold the ⓣ button and the ▽ "Down" arrow on the D-pad. Once the controller vibrates, the burst speed is successfully reduced.

3.How to set the duration when adjusting the burst speed?
Press the ⓣ button and press the △ "Up"/ ▽ "Down" arrow on the D-pad at the same time. Once the controller vibrates, the command is successful.

6. shot/s: The HOME light flashes slowly (slowly flash for 1 time per second).



12 shots/s: The HOME light flashes in a moderate manner (slowly flash for 2 times per second).

20 shots/s: The HOME light flashes frequently (slowly flash for 4 times per second).



4. Will the burst setting be saved?
The setting will be saved when the controller is disconnected. The controller will keep the first setting when it is connected.

About Vibration

There are 4 speeds settings, in total: weak, none, medium, strong (Default: Medium, 66%, 33%).

How to set up the vibration?

Press the vibration ⓥ adjustment button at the back of the controller, and the controller will vibrate in 4 speeds in sequence

Which speed is the default for the first connection?

Medium (Default: 66%, 33%).

Note: The speed setting will be saved when the controller is disconnected. The controller will keep the last setting when it is connected.

About M1/M2 programmable function

M1 or M2 > ⓛ: Only one button value can be mapped to the back button under the Mapping Mode.
M1 or M2 > ⓛ: You can define up to 16 button values to the back button in macro definition mode.

*The default M1 and M2 have no button function value.

How to map one button to M1 or M2 key?

Press and hold M1 or M2 > ⓛ at the same time for 2-3 seconds. The controller vibrates, and the RGB lights of the left and right joysticks turn white and flash slowly, indicating that it enters the programming mode. Press the programming button ⓛ. Tap ⓛ once on the D-pad. Once the controller vibrates, the burst speed is successfully increased.

2.How to reduce the burst speed?
Press and hold the ⓛ button and the ▽ "Up" arrow on the D-pad. Once the controller vibrates, the burst speed is successfully reduced.

3.How to set the duration when adjusting the burst speed?
Press the ⓛ button and press the △ "Up"/ ▽ "Down" arrow on the D-pad at the same time. Once the controller vibrates, the command is successful.

4. Will the burst setting be saved?
The setting will be saved when the controller is disconnected. The controller will keep the first setting when it is connected.

About Vibration

There are 4 speeds settings, in total: weak, none, medium, strong (Default: Medium, 66%, 33%).

How to set up the vibration?

Press the vibration ⓛ adjustment button at the back of the controller, and the controller will vibrate in 4 speeds in sequence

Which speed is the default for the first connection?

Medium (Default: 66%, 33%).

Note: The speed setting will be saved when the controller is disconnected. The controller will keep the last setting when it is connected.

About M1/M2 programmable function

M1 or M2 > ⓛ: Only one button value can be mapped to the back button under the Mapping Mode.
M1 or M2 > ⓛ: You can define up to 16 button values to the back button in macro definition mode.

*The default M1 and M2 have no button function value.

How to map one button to M1 or M2 key?

Press and hold M1 or M2 > ⓛ at the same time for 2-3 seconds. The controller vibrates, and the RGB lights of the left and right joysticks turn white and flash slowly, indicating that it enters the programming mode