



Insignia TV Remote Codes: Universal Codes for Insignia TVs

[Home](#) » [Insignia](#) » Insignia TV Remote Codes: Universal Codes for Insignia TVs

If you have an Insignia TV and want to use a universal remote control, you'll need to know the codes to program the remote. In this post, we've compiled a list of the most common Insignia TV codes for universal remote controls. These codes will work for all Insignia TVs manufactured after January 1, 2007. We've included codes for a variety of universal remote control makes and models, as well as cable and satellite service providers. If you're having trouble finding a code for your remote control or service provider, we're here to help.

Here is a listing of the most common Insignia™ TV codes for universal remote controls (for all Insignia™ TVs manufactured after January 1, 2007):

Universal remote control makes and models:

- **Aconcagua** 0179, 0236, 0463, 1463, 0180, 0178, 0150, 0156, 0054, 0171, 0030, 0017, 0092
- **Bose** 10171, 11204, 11326, 11517, 11564, 11641, 12002
- **Clicker** 0020, 0052, 0063, 0065, 0069, 0075, 0076, 0078, 0097, 0099, 0100, 0112, 0113, 0115, 0124, 0127, 0128, 0129, 0142, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0153, 0154, 0156, 0163, 0172, 0173, 0178, 0182, 0184, 0186, 0188, 0190, 0191, 0192, 0193, 0194, 0203, 0210, 0221, 0224, 0249, 0250, 0292, 0294, 0297, 0301, 0307, 0310, 0315
- **General Electric (GE)** 1181, 1180, 1175, 1171, 0103, 0189, 0217, 0135, 0133, 0116, 0167, 1148, 0456, 0029, 0905, 1406, 1407, 1408, 2891, 0371, 2271, 0581, 0701, 0871, 09821, 1241, 1381, 2241, 2921, 3761, 3841, 4371, 4721, 4761, 5051, 5061, 5181
- **Innovage Products** (Jumbo Universal Remote) 000, 001, 004, 009, 035, 038, 045
- **Insignia™** 12049, 11780, 14487, 11641, 11564, 11326, 11892, 12002, 12184, 11423, 11385, 11660, 11963, 12751, 13227, 11463
- **Flipper** 0371, 0701, 0871, 1241, 1381, 2241, 2271, 2321, 2471, 2891, 2921

- **Living Solutions** 022, 044, 046, 050, 055, 061, 069, 071, 073, 074, 075, 078, 080, 081, 082, 083, 084, 087, 092, 091, 096, 103, 104, 105, 106, 108, 109, 112, 114, 117, 118, 119, 120, 121, 125, 126, 127, 128, 134, 139, 140, 144, 146, 153
- **Magnavox** 0103, 0120, 0130, 0040, 0069, 0074, 0089, 0091, 0094
- **MasterControl** 350
- **Momentum** 345, 354
- **Motorola** 350, 400, 052, 164, 403, 454, 457
- **One for All** 0054, 1204, 1780, 2049
- **Panasonic** 06, 07, 15, 18, 20, 0017, 0054, 0178, 0317, 0457, 1564, 0171, 1204, 1326, 1517, 1660, 2002, 2003, 2004
- **Philips** 0198, 0490, 0115
- **Potenza ST** 0171, 1204, 1326, 1517, 1963, 2002
- **RCA** 135, 12049, 11423, 11564, 10171, 10463, 11810, 11892, 11963, 12184, 12417
- **RadioShack** 038, 173, 228, 238, 252, 253, 272, 290, 307, 325, 381, 417, 420, 477, 505, 511
- **Samsung** 00, 01, 02, 03, 04, 05, 06, 07, 08, 09, 15, 16, 17, 18, 40, 43, 46, 47, 48, 49, 59, 60, 98
- **Simplicity** 564, 575
- **Sony** 068, 069, 078, 096, 100, 164, 168, 229, 026, 00171, 01204, 01423, 01564, 02049, 10675, 12428, 12596, 00171, 01517, 01710, 01780, 01892, 02002, 02049, 20288, 02417
- **Terk** 12049, 11564, 11892, 10171, 10463, 14398.
- **X10** 014, 017, 021, 022, 025, 027, 036, 037, 038, 039, 040, 043, 044, 045, 046, 047, 048, 049, 050, 051, 052, 053, 054, 055, 056, 057, 058, 059, 060, 062, 075, 081, 082, 087, 088, 089, 090, 095, 096, 101, 129, 134, 136, 137, 164, 165, 166, 167, 174, 176, 184, 189, 190, 192, 196, 197, 210

Cable and satellite service providers:

- **Armstrong** 1423, 1564, 0171, 1204, 1517, 1660, 1710, 1785, 1892, 1963, 2049, 2417
- **AT&T U-Verse** 1004, 1005, 1023, 1061, 1034, 1035, 1040, 1273, 1398, 1465, 1507
- **Bell Satellite TV** 506, 525, 526, 534, 536, 541, 566, 568, 569, 573, 590, 600, 610, 627, 636, 642, 648, 652, 653, 654, 655, 656, 658, 662, 675, 682, 683, 692, 694, 696, 699, 720, 723, 724, 729, 733, 754, 756, 764, 816, 834
- **Bell Fibe (Canada)** *Nova remote:* 1423, 1564, 0463, 0171, 2751, 2432, 2184, 2088, 2049, 2002, 1963, 1892, 1810, 1785, 1660, 1641, 1517, 1385, 1326, 1204; *Slim remote:* 0010; *MxV3 remote:* 0029, 0061, 0103, 0116, 0133, 0135, 0167, 0189, 0217, 0456, 1148
- **Blue Ridge** 167, 169, 415, 425, 450, 456, 461, 462, 482, 523, 524, 567, 577, 586
- **Buckeye CableSystem** 1326, 2049
- **Cablevision** (Optimum Online) 068, 069, 078, 096, 100, 164, 168, 229, 026
- **CenturyLink** 1423, 1564, 0463, 0171, 2751, 2432, 2184, 2088, 2049, 2002, 1963, 1892, 1810, 1785, 1660, 1641, 1517, 1385, 1326, 1204
- **Cincinnati Bell** 11564, 11710, 11326, 11641, 11785, 12002, 11423, 11204, 11517, 10463, 10171, 11963, 11463, 10842
- **Comcast/Xfinity** 10463, 10171, 11204, 11326, 11463, 11517, 11641, 11780, 11785, 11892, 11963, 12002, 01877, 00276, 01982, 01376, 00810, 01187, 01106, 00877, 00476
- **Cogeco**
- **Consolidated Communications** 0001, 0004, 0005, 0011, 0013, 0018, 0022, 0023, 0025, 0027, 0031, 0033,

0036, 0044, 0045, 0053, 0056, 0057, 0059, 0060, 0080, 0081, 0089, 0097, 0102, 0107, 0118, 0122, 0124, 0125, 0150, 0348, 0349, 0317, 0351, 0352, 0353, 0354, 0355, 0356, 0357, 0296, 0538, 0544, 1368, 02049, 01641, 01564, 01326, 02002, 01423, 01892, 01517, 00171, 00463, 01385, 01660, 01963, 02184, 02416, 02751, 03227

- [Cox](#) 1326, 1463, 33951, 12049, 2049, 1641, 1564, 1326, 1423, 1892, 1517, 0171
- [DirectTV](#) 10463, 10171, 11204, 11326, 11517, 11564, 11641, 11963, 12002, 11463, 12049
- [Dish Network](#) 834, 720, 222, 898, 365, 777, 754
- [Insight](#) 10171, 11204, 11963, 12002
- [Mediacom](#) 1206, 1134, 1118, 1080, 1202, 1059, 1102, 1184, 1110, 1007, 1012, 1093, 1139, 1196, 1245, 1423, 1364, 0171, 1204, 1326, 1517, 1641, 1710, 1780, 1892, 1963, 2002, 2049, 2088, 2417
- [RCN](#) 1892, 4049
- [Rogers](#) 12049, 11641, 1423, 1564, 0171, 1204, 1326, 15174, 1641, 1710, 1780, 1892, 1963, 2002, 2049, 2088, 2417
- [Shaw](#) 0463, 1326, 1564, 1785
- [Spectrum/Charter/Time Warner](#) 400, 450, 461, 456, 10463, 1463, 0463, 10171, 11204, 11963, 12002, 068, 069, 078, 096, 164, 168, 1196, 1017, 1116, 1155, 1189, 1251, 1267, 1271, 1275, 1182, 2002, 1204, 1423, 1517, 0171, 1963, 0463, 1463, 0842, 1326, 167, 415, 424, 450, 456, 461, 507, 523, 567, 577, 586
- [Suddenlink](#) 0171, 1204, 1326, 1564, 1517, 1963, 2002
- [Telus](#) 1807, 1312, 1475, 1809, 1772, 1695, 1883, 1881, 1756, 1755, 1638, 1476, 1375, 1174
- [Titan](#) 11564, 11710, 11326, 11641, 11785, 12002, 11423, 11204, 11517, 10463, 10171, 11963, 11463, 10842
- [TiVo](#) 0091
- [Verizon](#) 0198, 0490
- [Vidéotron](#) 450
- [WOW!](#) 12049, 11423, 10463, 10171, 11204, 11326, 11385, 11517, 11660, 11785, 11892, 11963 12417

If you're still having trouble finding a code — or your remote control is not listed above — we want to help. Please reply to this message and we'll start working to get you an answer. Here's what we need you to provide so that we can get you what you need:

- The remote control manufacturer and model number.
- The model number of your TV.
- Any additional details about your situation that might help us help you.

Contents

[[hide](#)

[1 FAQs](#)

[2 Related Posts](#)

FAQS

Does this work with insignia ns-24df310?

Yes, this replacement remote works for all Insignia and Toshiba Fire TV Edition TVs.

Does this work with second generation

This replacement remote works with Insignia and Toshiba Fire TV Edition televisions.

Do you have remote for insignia fire tv without the amazon button? mine is stuck and disrupts the watching constantly, turning tv to amazon

This remote has the Amazon Prime Video button.

You could try to control your TV over Wi-Fi using the Amazon Fire TV app on your Smartphone.

Can i program to run sony reciever how?

Nope, this is a TV controller only. You can get remotes that you can program all your devices like a Harmony.

I don't have the original remote for my toshiba fire tv, will this remote work for it ?

Yes, this will work with your Toshiba Fire TV Edition Television.

Will thar remote work after a factory reset?

yes as a basic remote and then re Pair it to the TV.

Does this remote work with any insignia TV or must you have the model # of the tv?

Yes

Will these work with any insignia television ?

Just insignia fire tvs

Alexa cannot find available channels?

I really don't know what you are asking but it works just like my original remote

Will this work with a fire tv stick plugged into a standard tv?

This replacement remote will not work with a Fire TV Stick.