Q25-TWS Stereo Headset

Product Manual



Packing list:
















Product description



@Indicator light @ Touch button area C Microspone (i) Charm the protection point

& Chamino contact

Charging case description:



USB sharping port

Wearing schematic:

Starting:

- 1. Open the charping bin end take out the two earthques:
- 2. Tear open the insulation protective film of the charging contacts of the left and right earthorner:
- 3. After charging in the bin for sen minutes, take out the left and right earthones at the same time, After the two exphones leave the charging bin, they will automatically start up. The left and right corphones are externationly paintd. After excesseful paintre, they enter the paintre mode and is promoted "Power on".
- 4. Turn on BT of mobile chone or other device and olick to search status: 5. Select *Q25* from the energh list of mobile phones or other devices and connect. After the connection is aumented, the volonile prospoted "Connected". You can now use call and audio on mobile phones or
- other devices. 6. Concet the connection voice promot "Disconnected"
- 7. Press the lough leveled of the left perchang or the right perchang for 4 seconds, and the voice promote

Remarks:

- 1. After the serotrone and the device are disconnected bearing the identification distance (20m), they will
- when in the distance rence for submedia return connections 2. If the earthone is not connected with any device within 6 minutes, 2 will enformatically shull drawn
- 3. In the connected state. The earthors can be turned off and then turned on in external critic connect the
- last connected devices 4. When the earthone is in use, but in the charging bin and close the cover to suspressively shut down and enter the charging mode

Binaural/monaural switching:

- 1. After the earthcree are connected with the device, the signal receives a double transmission mode.
- and the two earthcose are not distinct into main and mixiliary party: 2. During the tearing and use of the two earthones, either earthone can be lurned off without cutting off
- The use shallo of the other comboner 3. After any emphone is turned on, it will automatically connect the previously connected device.

Pairing Method:

- 1. Open the upper cover of the charging bin, the earthories enter sulomatic pairing, and the blue lights of the two sembones flash slowly after successful pairing:
- 2. In case of exphane creek and mismatch, but the exphane into the charging bin and close the cover, and the sembons will be automatically reset.

Key Actions:

- R L Click PlacPune Assertion to R L Triple Stree Switch on Summone Sin

R Press and hold for 4 accords

R Double-click: Next

- (When the device is not connected)
- field the right our to increase volume Press and hold the left our to decrease volume

- Double-click: Lest

Turn on the charging bin lighting mode:

1. Put the earthone into the charting bin and start charting after closing the cover. At the same time. the ballary power of the charging bin will be delegied. When the earphone is not fully charged, the charging status light turns on the rad, and when the earphone is fully charged, the light goes out 2. When the charries bit is charried with the charries line, the charries grates and electric quantity will be displayed.

The lighting mode of the charging bin is as follows:



State of low observe

Indicator status:

ingle bool paiding	The bive light fluores, and ine politry financial materializedly official down other E missions.	
thing reads of main	This self-and blow lights than priorestable before the pairing in successful, and the time lights than along other two were and recommenty points with each other	
Pewer on	The blue light Sented follow.	
Power off	The Life real light fluid on 2 things limb fluor grown cod.	
resulted to character	No Flank	
When celling in	No Plane	
Limento music	No Plants	
rangered completes	Red LED off 4.2 Pul Power	
Courging	Red LED brights	
(V & C) make applied	2:19 stems, cace away whate. Ye prompt from "though the power is insufficient"; and the set light of the industrial facilities come every 5 seconds.	

- 1, in order to ensure smooth connection, it is recommended that the distance between mobile phone and earthque should be within 20 meters (bemer-free):
- 2. If the mobile phone cannot search for the wireless device, remove all paired data stored in the mobile choose and essent for the device exacts:
- 3. If there is stuck when talking or listening to some, or if there is a graph or the combone is connected to the mobile phone but there is no cound when playing munic, put the earphone into charging bin and closed the cover.
- 4. Only one suithfore has sound. Reprostrict the two estrationes. (Delete the pairing in the phone first, then put the two earphones in the charging bin and close the cover. Take II out when the rad light is on, and wait for 15 seconds before the blue light fleshing state). 5. If the charging is wrong or cannot be charged, check whether the charging line is connected correctly or whether the europeans is installed, and out it back into the charatra
- 6. This product uses a built-in non-detechable battery. Please do not try to take the battery out of the serphone to avoid demaging the sembone.
- 7. When you do not use comphones and charging compartments for a long time, please place them in a dry and vanificited piece and chame them once a month

Safety Notes: 1. Do not use sembones in thunderstorm weather, which may lead to abnormal coveration of

- combones and increase the risk of electric abook 2. It is represented that the uniques of our case should be increased structy from exact in terms, and the
- economists volume should be selected to evold damage to ear hearing.
- 3. Please place emphones and packaging boxes in places that are not easily accessible to children to essoid exceldents.
- 4. Earphones are not suitable for operation in high temperature or humid environment:
- 5. Do not use any compaive or abrasive determent to clean earthones.
- 6. In order to reduce the poliution to the earth, please recycle it by a professional organization when it
- 7. The battery is flammable and audiosive. Plame do not disassemble it without autoximation or out it
- Into the lire, which will lead to explosion risk.
- 6. Please do not disassemble the earphone by yourself.

Maintenance Service Card

Client name	
Contact Number	
Product name	
Product Style	
Deeler	
Contact Number	

Deer upon, this warman's card in the certificate of the product Dress pugraphers. Pieese popurate with dealer to fit in it and kern it