

AirDopes 141

Get ready to immerse yourself in musical bliss with your very own pair of boAt Airdopes 141. Please consider this manual as your guiding map towards the unparalleled shores of musical bliss.

Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual; also, you may refer to the same at times when you face any sort of difficulty in future.

PACKAGE CONTENTS

- 1x Pair of TWS Earbuds 1x Charging Case 1x Type-C Charging Cable 2x Pair of Extra Earmuffs 1x User Manual 1x Warranty Card
- + 1x Catalogue

POWER ON (First Time User)

POWER ON (First Time User)

Step 1: To switch the exchads on (Smart Power On)

simply open the id of the charging case (when ourboats are inside). Courtony our IMP "clustrology, the earthoat power on automatically, get connected

Long touch the CTC on both earbuds for 8 seconds to manually power on the earbuds

Step 2: After powering on, the earbuds enter into the Connection Mode, indicated by red and white LED

CONNECTION MODE

Step 3: Turn on the Bluetooth functionality on your phone/media device and scan

Step 4: Search for 'Airdopes 141' and pair

Congratulational Your earbuds are now connected successfully via Bluetooth

- Airdopes 141 remembers previously connected devices, once switched on, the ear-buds automatically reconnect to the previously connected devices

SINGLE FARRUDUSAGE

Step 1: Please note that both the earbuds can be used in mono mode. Use Smart / Manual Power On for switching on the desired earbud

Step 2: The selected earbud will automatically enter the connection mode indicated by red and white LED flashes

Step 3: Turn on Bluetooth on your phone/media device and search for 'Airdopes 141'

QUICK GUIDE ON FUNCTIONALITIES

- 3 Seconds O Long touch either CTC for 3 seconds to activate voice assistant
- · 8 Seconds Long touch both CTCs for 8 seconds to manually power on

• 5 Seconds O Long touch both CTCs for 5 seconds to manually power off



CHARGING THE FARRLIDS

Step 1: Please insert the earbuds back inside the charging case in correct orientation. Step 2: A solid red LED on earbuds indicates that the earbuds are being charged. Once

Step 3: Once the earbuds are fully charged, the charging case automatically switches off to save power.

Before using the ear-buck for the first time, it is recommended to fully—charge the ear-buck. Also, please keep the lid of the charging case closed while charging

CHARGING THE CASE

Step: To charge the case, plug one end of the provided cable into the case and connect the other end to a computer/ wall adapter/ powerbank, etc.

White LED flashes while the case is on charging. When the charge gets full, it gets indicated by solid white LED.



Charging norms & Precautionary Guidelines:

: Standard Cable (35 Strands @0.10mm diameter/strand)

Any other accessory can be paired up with the product as long as the specifications are as per above norms.

- Answer: Single tap the CTC on either earbud to answer an incoming call - Hang Up / Reject Call: Double tap the CTC on either earbuid to end or reject call
- Play/Pause Music: Single tap on either earbud's CTC to play or pause music
- Previous Track: When playing music, double tap the left CTC to return to the previous song



Step 1: Long touch the CTC on either earbud for 3 seconds to activate the smart voice

Step 2: The respective voice assistant screen pops up and you may place your commands at ease

Tips: You may try out the following commands,

· What is the weather?

· Set a reminder

What is the weather? Play a song Set a reminder

SMART POWER OFF

Step 1: After usage, remove both the earbuds from your ears Step 2: Place the earbuds back into the charging case in correct orientation and close the lid

The earbuds automatically switch off (and enter into charging mode).





Step 1: Long touch both CTCs for 5 seconds to manually power off Step 2: Once the earbuds get turned off, place them back inside the case and close the lid





Airdopes 141 comes equipped with our cutting edge \mathbb{WP}^{n} technology along with the Auto-Reset feature, which means that you would not require to do the factory reset manually. Now, every time while the earbuds are kept inside the case and the fild gets opened, the earbuds reset automatically.

SPECIFICATIONS

Bluetooth Version	V5.0
Music Playtime	Up to 6HRS per charge; Up to 36HRS additional with Case (at 60% volume)
Standby Time	100H
Talktime	SHRS
Transmission Range	10m
Driver Size	8mm*2
Bluetooth Profiles	HFP/ HSP/ A2DP/ AVRCP
Frequency	20Hz20kHz
Battery	600mAh (Case) 30mAh*2 (Earbuds)
Charging Time	1H (Earbuds) ; 2H (Case)
Charging Interface	TypeC
Water Resistance	IPX4

· Please follow the instructions to operate

Please don't use the ear-buds in extreme temperatures

Please don't use the product near water

Don't jam the ports such as charger port, LED port, etc.

It is recommended to utilize the product below the may to protect hearing and extend the ear-buds' service life

