有线 2.4G 蓝牙



狼蛛




产品手册


SOCI 1素艾电子 Dongguan Suoai Electronice CO.,LTD 東莞市索艾電子科技有限公司 www.aulacn.com SOAI Industry Park, Huayu Street Changlong Village Huangjiang Town Dongguan City Guangdong Province. 廣東省東莞市黃江鎮長龍村華裕街 索艾產業園 執行標準: GB/T 14081-2010 Made in China

有线模式/开关机

04



F NO. 246	→	→
①切换至【有线】模式	②将标配USB线缆Type-C 一端插进键盘对应端口	③将线缆USB头一端插 入电脑USB端口即可
开关机说明		
• 将开关拨至有约对键盘供电。	线(未插USB供电),键盘即关机	1状态,内置电池停止
2.4G连接使用说明		03
2.10 <u>EJ</u> X X/IJ <i>N</i> 0-7J		
	→	→
①切换至【2.46】模式	②从键盘左上角槽位内 取出【USB接收器】	→ □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
①切换至【2.46】模式		③插至电脑USB端口
①切换至【2.4G】模式 ①切换至【2.4G】模式 4	取出【USB接收器】 快速2.4G对码 「FN+~"3秒左右,青色灯快/ 、一、读青色灯亮2秒,2.4G连接/	③插至电脑USB端口即可使用 即可使用 以进入对码状态,此时将接成功。此时即完成对码。



蓝牙连接使用说明

	1	切换灯光模式	
	H ≪ Tab →H	切换灯光颜色	
ENI.	†	灯光亮度增加	
FN+	\	灯光亮度减少	
	←	灯效速度减少	
	→	灯效速度增加	



对码

蓝牙设备1#

蓝牙设备2#

FN+

2

•	Fn+WIN WIN 键	記法使用),	换 锁左WIN窗口键(指示灯:锁WIN(左WIN/左ALT位)	建白灯	指示。		06 助指示灯常亮,
		Q	安卓系统				
	FN+	w	Windows系统				
		E	MAC系统				
				4			
F	N+W= V	Vindows	系统(W键红灯闪]3s) F	区单按功能	能与F区FN:	组合功能。
	键位	单按	Fn组合		键位	单按	Fn组合
	F1	F1	主页		F7	F7	上一曲

F8

F9

F10

F8

F9

F10

播放/暂停

下一曲

静音

邮件

转换窗口

打开资源管

理器



0

DEL

FN+

PAUSE

INS

HOME

F2

F3

F4


F3


F5	F5	灯光亮度-		F11	F11	音量-
F6	F6	灯光亮度+		F12	F12	音量+
	1	江灯闪3s),	F区单			
键位	单按	Fn组合		键位	单按	Fn组合
键位 F1	単按 屏幕亮度-		-	键位 F7	上一曲	
	1	- F1				F7
F1	屏幕亮度-	F1 F2		F7	上一曲	F7 字 F8
F1 F2	屏幕亮度- 屏幕亮度+	F1 F2 F3		F7 F8	上一曲播放/暂停	F7 字 F8
F1 F2 F3	屏幕亮度- 屏幕亮度+ 转换窗口	F1 F2 F3 F4	-	F7 F8 F9	上一曲 播放/暂停下一曲	F7 序 F8 F9



充电使用说明







邮政编码

销售日期

地 址

户信息

息

维修记录:

维修日期

电话/E-mail

销售单位

联系电话

产品型号


销售商印章


维修单位

电 话

销售单位地址

通讯地址及邮编





Constant

light

Wheel

Turn Off

raindrops

• With the driver, there is a music rhythm RGB lighting effect, under this

lighting effect, there are 10 lighting effect modes to choose from


customize

burst

Shortcut Keys for Backlight Effects Adjustment

breathing

spread



• Short press the combination key Fn + number 1, 2 or 3, the blue light flashes quickly, indicating that the keyboard enters the pairing or search

• Check the battery level of the keyboard, and it can be displayed on the

mode. In the reconnection state, the blue light is on for 3s.

• Press Fn + number key 1, 2, or 3 to switch devices.


computer when connected to Bluetooth.

• The keyboard is made of solid materials and the keys are responsive.

• A series of convenient FN+ key combinations

• Two-level kickstand, hidden independent space to storage USB receiver.

• Keyboard return rate: wired mode 1000Hz, 2.4G mode 1000Hz, Bluetooth



• In 2.4G/Bluetooth mode, press and hold FN+B to check the battery level. When fully charged, the number keys 1 to 0 will all light up in

18

FN+E=Mac system (the red light of the E key flashes for 3s),F area single

green The green light gradually decreases as the battery consumption decreases, and when the battery is low, the red light

turns on. Release to restore the light effect.


press function and F area FN combined function.

flowers

bloom

rainbow

No trace of snow



17


FN+Q=Android system (the red light of Q key flashes for 3s) F area

single press function and F area FN combined function.

MAC system


	sing l e press	Fn combination	Key position	single press	Fn combination	Key position	single press	Fn combination	Key position	single press	Fn combina
F1	Screen brightness-	F1	F7	Previous sor	ng F7	F1	Screen brightness-	F1	F7	Previous song	F7
2	Screen brightness+	E2	F8	Play/pause	e F8	F2	Screen brightness+	F2	F8	Play/pause	F8
3	Switch window	F3	F9	Next song	F9	F3	Switch window	F3	F9	Next song	F9
4	Main screen	F4	F10	Mute	F10	F4	Main screen	F4	F10	Mute	F10
5	Light brightness-	F5	F11	Volume -	F11	F5	Light brightness-	F5	F11	Volume -	F11
6	Light brightness+	. F6	F12	Volume +	F12	F6	Light brightness+	F6	F12	Volume +	F12
F1 F2 F3	F1 F2 F3	Mail Switch	position F7 F8	F7 F8 F9	Previous song Play/pause Next song	Game mo	 Dual mode switching: Long press the mode to switch between game and office modes. Game mode (WIN key & CAPS key, green light flashes 3 times) 				
3	F3	Switch window	F9	F9	Next song	Game mo	de (WIN key	& CAPS key,	green light	flashes 3 time	es)
4	F4	Open Explorer	F10	F10	Mute	F11 F12	 Short press the mode button to cycle throllighting effects Knob clockwise (light brightness +) Knob counterclockwise (light brightness -) 				
5	F5	Light brightness-	F11	F11	Volume -						
F6	F6	Light brightness+	F12	F12	Volume +	4111111		mob counter	CIOCKWISE (II	ignt brightne	33 -)
			19					2	20		
ice mod	le (WIN ke	ey & CAPS key	the blue lig	ht flashes 3	3 times)	Descrip	tion of Sma	art Sleep M	lode		
ice moc	·	ey & CAPS key Short press tl Knob clockwi Knob counte	ne mode but se = multim	tton = mult func edia functio	timedia ction (mute) on (volume +) a function	• In Blueto	ooth/2.4G mod any operation	le, it will autor	natically ent	er power savir the button to	ng mod


12




Product Parameters

• Number of keys: 80 keys • Total travel of keys: 4.0mm





the warranty certificate does not match the product in kind; 4. Failure and damage caused by abnormal use, maintenance and 5. Failure or damage caused by repair, change or disassembly of the product by non-authorized maintenance personnel of our company; 6. Failure or damage caused by accidents or other force majeure; 7. Services and additional accessories or gifts outside the product promised by the sales staff are not included in the scope of this 8. Failure or damage caused by unstable power supply or voltage.



说明书技术要求: 1.成品尺寸: 100x130mm

2.材质:120g铜版纸+打骑马钉

3.工艺: 单黑双面印刷