


Packed Party

TURN IT UP!

WIRELESS EARBUDS



LOOK!

SCAN ME WITH
YOUR SMARTPHONE
FOR EXCLUSIVE
PARTY HOW-TO TIPS,
DOWNLOADS, & MORE!




FOLLOW THE PARTY
@PACKEDPARTY

LIFE'S A PARTY
WHEN YOU MAKE IT ONE!
WWW.PACKEDPARTY.COM

QUICK START GUIDE

PKTW200

What's in the Box?



- A. 1 pair of earbuds
B. 1 charging case
C. 3 pairs of silicone earbuds
(M size installed on earbuds)
D. USB-C® charging cable
E. 1 quick start guide
F. 1 warranty card




Setting Up Your Device

Step 1: Place your earbuds into the charging case for initial activation and charge your device using the included charging cable.



Step 2: Once fully charged, open the charging case. Your earbuds will enter pairing mode automatically. On your smartphone, search for the Bluetooth® device named "Turn It Up Wireless Earbuds" and tap to connect.



Powering On/Off and Unpairing

Powering On

Removing your earbuds from the charging case will connect them to the last paired device.

Powering Off

Placing your earbuds in the charging case and closing the lid will turn off and disconnect your earbuds from the last paired device.



You may also turn off your earbuds without the charging case by pressing and holding each side of the earbuds for 5 seconds.

Pairing and Unpairing

To unpair your earbuds from the previously connected device, turn Bluetooth® off on your device. Place the earbuds in the charging case with the lid open to pair to a new device.

Functionality

In-Ear Detection

Both earbuds will auto-pause when you remove them from your ears.



Tap 2x to Play/Pause



Tap & Hold for 2 seconds for Siri® / Google Assistant™, or to reject an incoming call



Tap Left Earbuds 3x to play the previous track
Tap Right Earbuds 3x to play the next track




Tap Once to answer an incoming call or to hang up

Adjust the volume using your smartphone.

Charging Your Device

Use the included charging cable to connect your device to a power source such as a battery pack, laptop, or car charger.



The Specs

Model: PKTW200

Speaker Diameter: 0.4"

Speaker Impedance: 32 $\Omega \pm 15\%$

Sensitivity: 102 ± 3 dB at 1 KHz

Speaker Driver Rating Power: 3 mW

Charging Cable: 9.06"

Input: 5V DC ± 0.5 A

Battery: 3.7 V, 250 mAh, 1 Wh

Playback: 6 hours (at 50% volume)

Waterproof Rating: IPX5 water resistant & sweatproof
(rating applies to the earbuds – not the charging case)

FCC ID: 2AVRVPKTW200



LLW2201

WARNING: Listening to loud audio for extended periods of time may damage your hearing permanently.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications to this product not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

FCC Warning (Continued)

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Need Help?

For customer support regarding your device, please submit a request by emailing support@dpaudiovideo.zendesk.com. You will be provided a ticket number regarding your inquiry, which you can refer to when contacting us further.

You may also reach a DPAV customer service representative by calling **1-833-909-2673**. We are available **Monday - Friday, 9am - 5pm PST**, except major holidays. DPAV strongly urges customers to email their inquiry prior to calling, as this will enable us to better assist you.

Please make sure to note the model number and a description of your inquiry.

Thank you for purchasing a Packed Party product.

Designed in Austin, Texas. Made in China. All designs © 2022 Packed Party, Inc. © 2022 DP Audio Video LLC. All Rights Reserved. USB is used to solely describe the compatibility of our technology and in no way is intended to infringe on any intellectual property rights of any respective protected marks. © 2022 Bluetooth SIG, Inc. All rights reserved. The Bluetooth® trademarks—including the BLUETOOTH word mark, the figure mark (the runic "B" and oval design), and the combination mark (Bluetooth word mark and design)—are owned by the Bluetooth SIG. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. 1 year warranty from date of purchase, 90 days only on labor. Manufactured/imported by DP Audio Video LLC. Distributed by DP Audio Video LLC. Los Angeles, CA. 3205 Industrial Terrace, Suite 200, Austin, Texas 78758. Packed Party is a registered trademark of Packed Party, Inc.