


MEET YOUR ECHO SHOW 5



SET UP YOUR ECHO SHOW 5



1. HAVE YOUR WI-FI AND AMAZON PASSWORDS READY

During setup, you will connect to the internet and sign into your Amazon account.



2. PLUG ECHO SHOW 5 INTO A POWER OUTLET

Use the included power adaptor. In about a minute, the display will turn on and Alexa will greet you.



3. FOLLOW THE ON-SCREEN SETUP

Log in with an existing Amazon account username and password or create a new account.



4. DOWNLOAD THE AMAZON ALEXA APP FROM YOUR APP STORE

Installing the app on your phone or tablet helps you get more out of your Echo Show 5. It's where you set up calling and messaging, manage music, lists, settings and news.



TO CHANGE YOUR SETTINGS

Swipe down from the top edge of the screen.

For help and troubleshooting, go to Help & Feedback in the Alexa app or visit amazon.com/devicesupport.

LEARN ABOUT THE LIGHT BAR

By default, Alexa doesn't begin listening until your Echo device hears you say "Alexa."

BLUE

Alexa is now listening.

RED

Microphones and camera are off. Alexa can't hear or see you.

ORANGE

Your device is in setup mode or is trying to connect to the internet.

PURPLE

Your device is in Do Not Disturb mode. During initial device setup, purple shows if there are Wi-Fi issues.

YELLOW

You have a new notification. Say "Alexa, read my notifications" or check the Alexa app.

GREEN

A household member may be viewing the device's camera from another Echo Show or the Alexa app.

Important information about Echo Show 5 International Version: Certain services may not be available in all countries and languages, require separate subscriptions and are subject to change at any time without notice.

PRIVACY AND SUPPORT



PRIVACY CONTROLS

Turn the camera and microphones off by pressing the Microphones/Camera on/off button. Cover the camera easily with the built-in shutter. See when Alexa is recording and sending your request to Amazon's secure cloud via a blue indicator light.



MANAGE YOUR VOICE HISTORY

You can view, hear and delete the voice recordings associated with your account in the Alexa app at any time. To delete your voice recordings, try saying "Alexa, delete what I just said."

"Alexa, delete everything I've ever said."



GIVE US YOUR FEEDBACK

Alexa is always getting smarter and adding new skills. To send us feedback about your experiences with Alexa, use the Alexa app, visit amazon.com/devicesupport or say "Alexa, I have feedback."

You have control over your Alexa experience. Explore more at amazon.com/alexaprivacy or amazon.co.uk/alexaprivacy.