



<div>US UK</div> <div>Dear user</div> <div>Thank you for choosing REDRAGON product. To protect your rights and for better customer service, please read the following warranty rules carefully.</div> <div>1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.</div> <div>2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty.</div> <div>1</div>	<div>How to plug in</div> <div>Plug type C cable to USB cable with keyboard and PC, keyboard is plug and play, no need driver.</div> <div>Key Function Introduction</div> <div>How to record light on the key</div> <div>1. FN+LR1/LR2 to select the profile.</div> <div>2. FN+Home to get ready for recording.</div> <div>3. Set the desired keys.</div> <div>4. FN+End to save and quit.</div> <div>5. FN+LR1/LR2 to play recording.</div> <div>6. FN+PGUP to delete recording.</div> <div>Backlight setting</div> <div>FN + 【ALT】 -R: Switch the backlight in 9 patterns.</div> <div>FN + 【CTR】 -R: Save record setting.</div> <div>FN + 【ESC】 : Back to factory setting.</div> <div>FN + 【↑】 : Level up backlight brightness.</div> <div>FN + 【↓】 : Level down backlight brightness.</div> <div>FN + 【←→】 : Adjust light rotating speed.</div> <div>Pre-set lighting modes</div> <div>FN + 1 = FPS mode, A S D W ↑ ↓ ← → ESC keys light up.</div> <div>FN + 2 = CF mode, A S D W Ctrl Shift Alt Space R G Q E B 1-5 Tab F1-F3 PrintScreen keys light up.</div> <div>2</div>	<div>FN + 3 = COD mode, Q W E R T A S D F G C V 1-7 Ctrl Shift keys light up.</div> <div>FN + 4 = RTS mode, Q W E R A S D G X Z F K L H M N U Y T P Space 1-0 Ctrl Shift Alt keys light up.</div> <div>FN + 5 = LOL mode, Q W E R D G F B V Ctrl Alt Tab Space ~ 1-6 Esc keys light up.</div> <div>FN + 6 = Car Race mode, A S D W R ↑ ↓ ←→ Ctrl Shift Alt keys light up.</div> <div>FN + 7 = NBA mode, A F S W R E Ctrl Shift Alt Space ↑ ↓ ←→ Z X C V 1234 keys light up.</div> <div>FN + 8 = LOL mode, Q W E R D F B 1-6 keys light up.</div> <div>FN + for more functions</div> <div>FN + [{ = INS</div> <div>FN +] } = DEL</div> <div>FN + ; ' = HOME</div> <div>FN + " = END</div> <div>FN + . > = PGUP</div> <div>FN + ? / = PGDN</div> <div>Multimedia key function</div> <div>FN + F1 = Computer</div> <div>FN + F2 = Search</div> <div>FN + F3 = Calculator</div> <div>FN + F4 = CD</div> <div>FN + F5 = Prev Track</div> <div>FN + F6 = Next Track</div> <div>FN + F7 = Play/Pause</div> <div>FN + F8 = CD Stop</div> <div>3</div>
<div>FN + F9 = Mute</div> <div>FN + F10 = Volume-</div> <div>FN + F11 = Volume+</div> <div>FN + F12 = LOCK KEYBOARD</div> <div>FAQ</div> <div>1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.</div> <div>2. If you spill liquid on the keyboard, please unplug the keyboards USB cable from the computer immediately. Wipe off excess liquid and put the keyboard in a dry and ventilated place. Make sure the keyboard is dried naturally before the next use.</div> <div></div> <div>4</div>	<div>FCC Statement</div> <div>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</div> <div>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</div> <div>-- Reorient or relocate the receiving antenna.</div> <div>-- Increase the separation between the equipment and receiver.</div> <div>-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</div> <div>-- Consult the dealer or an experienced radio/TV technician for help</div> <div>This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</div> <div>5</div>	<div></div> <div>REDRAGON</div> <div>KITAVA LITE</div> <div>94 KEY WIRED MECHANICAL KEYBOARD</div> <div>Mechanical Gaming Keyboard</div> <div>Operating Instructions</div>

型号	K636LGR-R/8735		备注：尺寸：100x100mm (折页) 材质：80g书写纸 印刷：单黑色双面印刷				
名称	说明书						
日期	2023-7-12						
页码	1 OF 1		文件编号				
绘图	雷国建	审核	香敏琪	核准		版本	A.1