

FOOD PROCESSOR



Ningbo Kajafa Electric Appliance Co.,Ltd
Add:No.53,North 1 Ring Road,Zhangqi
Town ,Cixi City,Zhejiang Province,China
Post-sale service : Service@Sangcon.com


Please read this instruction manual thoroughly
before and keep it for future reference

Caution

1. Please read the instruction carefully before use.
 2. Before connecting to the appliance, make sure the local voltage shown on the rating table.
 3. Do not allow children or handicapped person to play with the machine.
 4. Please operate the machine according to the stated and interval time. Do not overload the machine.
 5. This appliance is not recommended for ice crushing. Please choose another high power rate blender for ice crushing if necessary.
 6. The blade is very sharp, pay attention not to hurt your hand when cleaning and disassembling the machine.
 7. Please add at least half to 2/3 sport bottle capacity water or other liquid for blending usage. It will go broken with the appliance to blend food directly without proper water or other liquid inside.
 8. Blade components and mixing cup should be fully tighten, do not to come off. remove the searing, otherwise, it will cause leakage or blade component
 9. Do not use the blade components working on the host directly. Also do not touch rotating components when working.
 10. Ensure the lid is covered before operating.
 11. Processing temperature of food should not exceed 60°C. Do not operate the machine continuously more than 1min, ensure that machine is cool down before repeat use.
 12. processing capacity of food should not more than 2/3 capacity.
 13. The motor is equipped with an overheat protection device, During operation, the motor will stop working due to overheating, Sometimes there may be an unpleasant smell or smoke. Please don't worry, At this time, cut off the power supply, pull the plug and wait for 20 minutes to completely cool before starting.
 14. Do not contact the machine motor with water to avoid any hazard that may cause the machine to malfunction.
 15. Machine is only suitable for home use only.
 16. This blender is not recommended for ice-crushing (without water or milk).
- Recommended ratio: 1:1 (5 oz of ice: 5 oz of water or milk)

Main Parts


Chopper cover



Chopper blade




Chopper bowl



Gear box



Motor base



Lid




Big cup cover



Filter



Pitcher's cup



Cross blade




Low cup



Flat blade



High cup



Sealing Cover



Sealing Cap



Main technical parameter

Model: SBL360ABCE
Voltage: AC120V~,60Hz
Power: 350W

Operation Method

Blending

- 1.Put the machine on a stable table
- 2.Fix the cross blade to the bottom of pitcher's cup
- 3.Inject right amount water into pitcher's cup, then put in the diced vegetable.

Attention:processing capacity of food should not more than 2/3 capacity

- 4.Put on the cover, then tighten it clockwise
- 5.Put the pitcher's cup on the main body and be sure the upper concave parts fix well to the convex parts on the bottom of the pitcher's cup, then tighten it clockwise
- 6.Plug in the machine into AC120V~.
- 7.Choose the right speed, if blending some hard food, please kindly choose the second speed. Normally, it is finished within 1 min.
- 8.After blending, turn the switch back to the zero speed. The machine stop working, then pull out plug, pour the food out.
- 9.Repeat the steps if reuse is desired.

Mango coconut juice Ingredients:

- 1 mango,280ML coconut milk, honey, amount.
2. Peel and dice mangoes.
- 3.Place the cut mango in the high cup.
- 4.Pour coconut water into the high cup.
5. Then you can start the juicer and it will be ready in about 1 minute.
6. Finally, pour the juice into the container or drink it directly, the taste is better after freezing.

Attention: If you're mixing peeled fruits and vegetables, Use the pitcher's cup with a filter for better results.

Grinding

- 1.Put the food in the low cup,making sure it does not exceed 100g.
- 2.Twist the flat blade on the bottom of low cup and fix it on the motor base.
- 3.Power the plug,choose the second speed, the machine starts to grind, it is finished within 30 seconds.

Chopper

1. Inserted "S" blade into drive shaft of container, make sure in the right place.
2. Clean the meat (pork, beef), then de-bone, peel off, muscle off. Then cut into the 2cm*2cm small pieces. Putting into the container.
Attention: processing capacity of food should not exceed 2/3 capacity.
3. Put on the cover, then tighten it clockwise
4. Fix the container components to the main machine
5. On the power, choose the second speed, the machine starts to chop, it is finished within 1 min. It is not available to chop too long, to ensure the meat fresh.
6. After chopping, turn the switch back to zero speed, also plug off, take out the container components, open cover, take out the food.
7. Repeat the steps if desired for next use.

Clean and maintain

1. In case of electric shock, you must be sure the machine is power off when cleaning the body.
2. Clean the main body using wet cloth instead of water.
3. Do not wash the machine with dish washer.
4. It can be used again once you clean up the parts and assemble them well.
5. Some parts may have discoloration over a period of usage.
6. The machine should be used often, otherwise place it in the dry and ventilated environment.

Installation Diagram

