

BT975 (英语+西班牙语) 说明书 : 26 X 10CM

SENTRY

BC

BT975



TRUE WIRELESS
EARBUDS



VERDADEROS
AUDÍFONOS
INALÁMBRICOS

WIRE-FREE EARBUDS

English

1 Using your True Wireless Earphones

Before use: Charge both earbuds by placing it inside the charging case.

STEP 1 Turn off the Bluetooth function from you music device. Eg. Mobile phone or music device.

STEP 2 Take out the earbuds from the charging case after they have charged. The earphones will be automatically on and pairing. When pairing successfully, the left earphone will flash blue and the right earphone will flash red and blue alternately.

STEP 3 When auto-pairing failed, or dual earphone disconnected. Press the power button on left and right earphone, to make the earbuds off and on again, the left and right earphone will be connected manually.
If pairing still does not work, please long press both the buttons on the earbuds for 10 seconds to force the earbuds to restart. They should then resume to pairing mode.

STEP 4 You can now turn on the Bluetooth function of your mobile phone. Search and select BT975,click it to connect.

2 Button Function

On/Off Buttons

Pairing dual earphones: Long press left and right earphone button for 3 seconds, turn on or off the earphones.

Pairing single earphone: Long press left or right earphone button for 3 seconds to turn on the earphones, enter single earphone pairing. Then long press for 3 seconds, turn off the earphones.
(When power on, the earphone will flash blue . When power off, the light is off.)

Answer / Hang Up

When coming call, click the button on the left or right earphone to answer the phone. During the call, click the button on the left or right earphone to hang up the call.

Reject / Call Back

When coming call, long press left or right earphone to refuse the call. Three-click the right earphone button to resume back to the last call, three-click the left earphone button to open the voice assistant.

Play / Pause Music

While playing music, click the button of left or right earphone to play or pause the music.
If one of the earbuds have run out of battery, the other one will continue to work until it runs out of power also.

Last / Next Song Control

When playing, double-click the left earphone button to switch to the Last song; double-click the right earphone button to switch to the next song.

3 Charging Function

Charge the Charging Box

1)There is an USB charging cable in the package, you can connect the power adapter for charging.
The blue LED lights will keep flashing when it is charging.If all 4 blue LED lights on the front turn on, that means the charging case is fully charged.

English

English

• The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sentry Industries Inc. is under license. Other trademarks and trade names are those of their respective owners.

Sentry Industries inc declares that radio equipment BT975 is in compliance with Directive 2014/53/EU. The EU declaration of conformity is available at https://sentryindustries.com/european-declaration-of-conformity/

Conformity with Directives

This product is CE marked to denote conformity with Directives 73/23/EEC (low voltage) and 89/336/EEC (Electromagnetic Compatibility), as amended.

Environmental Protection

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

Supplier's Declaration of Conformity 47 CFR 47 CFR Part 15.21, 15.105(b) Compliance Information
Sentry Bluetooth
Sentry Industries INC
ONE BRIDGE STREET, HILLBURN, NY 10931 , USA
TEL:+1 8457532910

FCC Compliance Statement

FC "This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation."
FCC ID:2ACPCABT975 Model:BT975

"NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

* Reorient or relocate the receiving antenna.

* Increase the separation between the equipment and receiver.

* Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

* Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

WIRE-FREE EARBUDS

English

2)Press charging compartment button, when the indicator light blue; it means the charging case has sufficient power. If the blue light flashes slowly, it means the battery is low. When there is no power left on the charging case, the light will be off when the button is pressed.

Charge for Earphones

Please double check and confirm the charging compartment has sufficient power, then put the earphones into the correct position for charging.
If the earbuds are not placed securely into the case, it may not charge. Please take out the earbuds and re-insert them in the case. Also make sure the lid is properly closed so that charging the earbuds can start. Some large earpads could also obstruct the closure of the case, and so may need to be removed. A red light will appear to confirm that charging has started.

4 Frequently asked questions

Why bluetooth earbuds can not turn on?

1) You can check if earbuds is with power or not ? if not, please fully charge it before turning it on.

2) Please long press the power on /off button.(the detailed operation , please refer to the manual.)

Why bluetooth earbuds signal is unstable ?

1) Restart the bluetooth earbuds

2) Please kindly check the compability and calling communication quality of the mobile phone.

3) Please confirm if the distance between earbuds and phone is too far or there are interference surrounded. If too far or there are interference, the signal will be unstable.

4) Please don't stay in the signal reflective environment.

Why the bluetooth earbuds can't hear voice ?

1) Please kindly check if the bluetooth earbuds is on mute status.

2) Please kindly check if bluetooth earbuds and phone are connected well.

3) Then confirm if the distance between earbuds and phone is too far or there are interference surrounded.

If after some time, the earbuds are not pairing correctly , please delete the earbuds from your phone by going to the phone's bluetooth settings. Then reset the earbuds by long pressing both buttons on the earbuds for 10 seconds. Then follow Steps 1-4 on the first page of this manual to repair your earbuds to your phone device.

If after some time,the earbuds stop charging,pls try use the cotton swab to clean the earbud bottom and the inductive pins to avoid any dusts and sweat.

Specifications:

*Model: BT975

*Bluetooth Version: 5.0

*Power Input: DC 5V

*Earphone Working Time: About 4 hours at 50% volume

*Earphone battery capacity: 50mAh+50mAh=100mAh

*Charging Case battery capacity: 200mAh

*Support Protocol: HSP/HFP/A2DP/AVRCP

Limited 90-Day Warranty: Sentry warrants this product to be free from defects in materials and workmanship for 90 days from the date of original purchase. This warranty does not pertain to damage resulting from accident, abnormal use, misuse or neglect. Any defective product will be replaced if returned to an authorized Sentry dealer or to Sentry directly at: P.O.Box 885, One Bridge Street, Hillburn, NY 10931. Please enclose a \$5 check for return shipping.

Spanish

Spanish

1 Uso de sus verdaderos audífonos inalámbricos

Antes de utilizar: cargue ambos auriculares colocándolos dentro del estuche de carga.

PASO 1. Apague la función Bluetooth desde su dispositivo de música. Ej. Teléfono móvil o dispositivo de música.

PASO 2. Saque los auriculares del estuche de carga después de que se hayan cargado. Los auriculares se encenderán y se emparejarán automáticamente. Cuando se emparejen con éxito, El auricular izquierdo parpadeará en azul, el auricular derecho parpadeará en rojo y azul alternativamente.

PASO 3. Cuando falle el emparejamiento automático o se desconecten los auriculares duales, presione el botón de encendido en el auricular izquierdo y derecho, para que se apaguen y enciendan los auriculares, ambos auriculares se conectarán manualmente.
Si al poner los audífonos en el estuche de carga o al tratar de emparejar los auriculares con los botones no logra emparejarse, mantenga presionados los botones durante unos 10 segundos para forzar el apagado y el encendido de los audífonos (alguna forma de solución Bluetooth admite este tipo de operación)

PASO 4. Ahora puede activar la función Bluetooth de su teléfono móvil. Busque y seleccione BT975, haga clic para conectar.

2 Funciones de Botones

Botones de encendido/apagado

Emparejamiento de auriculares duales: mantenga presionado el botón izquierdo y derecho de los auriculares durante 3 segundos, encienda o apague los auriculares.

Emparejamiento de auriculares individuales: mantenga presionado el botón izquierdo o derecho del auricular durante 3 segundos para encender los auriculares, ingrese el emparejamiento de auriculares individuales. Luego mantenga presionado durante 3 segundos, apague los audífonos.
(Cuando se enciende, los auriculares parpadearán en azul. Cuando se apagan, la luz se apagará).

Contestar/Colgar Llamadas

Cuando reciba una llamada, haga clic en el botón del auricular izquierdo o derecho para contestar el teléfono. Durante la llamada, haga clic en el botón del auricular izquierdo o derecho para colgar la llamada.

Rechazar/Devolver Llamada

Cuando reciba una llamada, mantenga presionado el auricular izquierdo o derecho para rechazar la llamada. Haga clic tres veces en el botón derecho del auricular para volver a la última llamada, haga clic tres veces en el botón izquierdo del auricular para abrir el asistente de voz.

Reproducir/Pausar Música

Mientras reproduzca música, haga clic en el botón del auricular izquierdo o derecho para reproducir o pausar la música.

Si uno de los auriculares se ha quedado sin batería, el otro continuará funcionando hasta que también se quede sin energía.

Spanish

Spanish

Control de tema anterior/siguiente

Al reproducir, haga doble clic en el botón izquierdo del auricular para regresar a la última canción; haga doble clic en el botón derecho del auricular para pasar a la siguiente canción.

3 Función de Carga

Recargar la caja de carga

1)Puede conectar el adaptador de corriente para cargar utilizando el cable USB incluido en el paquete.
Las luces LED azules seguirán parpadearando cuando se esté cargando. Si las 4 luces LED azules en el frente se encienden, significa que la caja de carga está completamente cargada.

2)Presione el botón del compartimiento de carga, cuando el indicador se ilumine en azul, significa que la caja de carga tiene suficiente energía. Si la luz azul parpadea lentamente, significa que la batería está baja. Cuando no quede energía en el estuche de carga, la luz se apagará cuando se presione el botón.

Carga de audífonos

Verifique y confirme que el compartimento de carga tenga suficiente energía para después colocar los auriculares cargados en la posición correcta para.

Si los auriculares no se colocan de forma segura en el estuche, es posible que no se cargue. Saque los auriculares y vuelva a insertarlos en el estuche. Cuando cargue sus auriculares, asegúrese siempre de que la funda de carga tenga suficiente energía. También asegúrese de que la tapa esté bien cerrada para que pueda comenzar a cargar los auriculares. Algunas almohadillas grandes también podrían obstruir el cierre del estuche, por lo que es posible que deba retirarse. Aparecerá una luz roja para confirmar que la carga ha comenzado.

4 Preguntas Frecuentes

Por qué los auriculares Bluetooth no se pueden encender?

1)Verifique si los audífonos tienen energía. En caso de no ser así, cárguelos completamente antes de encenderlos.

2)Mantenga presionado el botón de encendido/apagado (Para la operación detallada, consulte el manual)

Por qué la señal de los auriculares Bluetooth no es estable?

1)Reinicie los auriculares Bluetooth.

2)Compruebe la compatibilidad y la calidad de la comunicación de llamadas del teléfono móvil.

3)Verifique si la distancia entre los audífonos y el teléfono es demasiado grande o si existen formas de interferencia alrededor. Si estás demasiado lejos o hay interferencia, la señal será inestable.

4)Alejese del entorno reflejante de la señal.

Por qué los auriculares Bluetooth no pueden transmitir voz?

1)Compruebe si los audífonos Bluetooth están en modo de silencio.

2)Verifique si los auriculares Bluetooth y el teléfono están bien conectados.

3)Confirme si la distancia entre los auriculares y el teléfono es demasiado grande o si existe interferencia alrededor.

AURICULARES INALÁMBRICOS

Español

1 Uso de sus verdaderos audífonos inalámbricos

Antes de utilizar: cargue ambos auriculares colocándolos dentro del estuche de carga.

PASO 1. Apague la función Bluetooth desde su dispositivo de música. Ej. Teléfono móvil o dispositivo de música.

PASO 2. Saque los auriculares del estuche de carga después de que se hayan cargado. Los auriculares se encenderán y se emparejarán automáticamente. Cuando se emparejen con éxito, El auricular izquierdo parpadeará en azul, el auricular derecho parpadeará en rojo y azul alternativamente.

PASO 3. Cuando falle el emparejamiento automático o se desconecten los auriculares duales, presione el botón de encendido en el auricular izquierdo y derecho, para que se apaguen y enciendan los auriculares, ambos auriculares se conectarán manualmente.
Si al poner los audífonos en el estuche de carga o al tratar de emparejar

BT975 (法语+德语) 说明书 : 26 X 10CM

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

BC

BT975

SENTRY

<