



DIERYA

DK61SE

PRODUCT USER MANUAL

## Specifications

Product Name: DK61SE

Material : Case-ABS, Keycaps-ABS

Backlight: Blue light / Green light

Optional Mode: Wired

Key: 61 Keys

Interface Type: Type-C

Size: 292.8×102×42mm

Product Weight: 550g±20g


Package Included: Keyboard、Type-C Cable、Keycaps Puller、User Manual

If you have any problems or need assistance related to this product, please feel free to ask our customer service for help.

Email:customer@kemove.com

## Instruction for Using Fn Key

### Auxiliary Key



Fn+1 : F1  
Fn+5 : F5  
Fn+9 : F9

Fn+2 : F2  
Fn+6 : F6  
Fn+0 : F10

Fn+3 : F3  
Fn+7 : F7  
Fn+\_ : F11

Fn+4 : F4  
Fn+8 : F8  
Fn++ : F12

## Instruction for Using Fn Key

### Function




Fn+Q : Home page  
Fn+R : Multimedia player

Fn+W : My computer  
Fn+T : Calculator

Fn+E : E-Mail  
Fn+Y : Search

## Instruction for Using Fn Key

### Function



Fn+U : PrtSc  
Fn+J : Ins  
Fn+M : Del


Fn+I : ScrLK  
Fn+K : Home  
Fn+< : End

Fn+O : Pause  
Fn+L : PgUp  
Fn+> : PgDn

Fn+Z : Mac key layout  
Fn+X : Win key layout

## Instruction for Using Fn Key

### Function



Fn+/? : ↑  
Fn+R-Ctrl : →

Fn+Menu : ↓  
Fn+Esc : `

Fn+R-Alt : ←  
Fn+Shift+Esc : ~


Fn+Tab : Press long until light of the keyboard blinks, the keyboard reset to the factory default settings.

Fn+Win : Win key locked / unlocked (The backlight of Win key off when Win key is locked, it follows current light mode when Win key is unlocked.)

Fn+Spacebar : Fn key locked / unlocked (The backlight of Fn key off when Fn key is locked, it follows current light mode when Fn key is unlocked.)

## Instruction for Using Fn Key

### Multi-Media



Fn+A : Previous song  
Fn+F : Stop


Fn+S : Next song  
Fn+G : Volume up

Fn+D : Play / Pause  
Fn+H : Volume down

Fn+Backspace : Mute

## Instruction for Using Fn Key

### Lighting



Fn+[ : Weaken light brightness  
Fn+; : Speed down light effect

Fn+] : Increase light brightness  
Fn+' : Speed up light effect

Fn+\\ : Switch lighting mode  
Fn+Right Shift : Turn on / off the light