


# All-in-One Vegetable Chopper

USER MANUAL




DARTWOOD

# In the Box




1 x vegetable  
chopper




2 x square  
blades




1 x egg white  
filter




5 x rectangular  
blades




1 x cleaning  
brush



1 x basket  
strainer




1 x slicing  
safety guard



1 x blade storage  
container

# Introduction to Parts



- |                       |                             |
|-----------------------|-----------------------------|
| 1. Presser            | 7. Rectangular blades       |
| 2. Handle             | 8. Square blades            |
| 3. Dicing blade slot  | 9. Egg white filter         |
| 4. Slicing blade slot | 10. Blade storage container |
| 5. Container          | 11. Cleaning brush          |
| 6. Basket strainer    | 12. Slicing safety guard    |


# Blades



0.55 in x 0.55 in  
dicing blade



0.27 in x 0.27 in  
dicing blade



ricing  
blade



0.15 in shredding  
blade



0.11 in shredding  
blade



0.07 in slicing  
blade




potato lattice  
blade


# How to Use

**CAUTION:** Blades are sharp and can cut your finger. Use with caution.

1. Clean all parts with dish soap before use. Remove the cover and place the basket strainer inside the plastic container (optional).




2. Place the cover onto the plastic container.




3. For dicing, open the top of the cover and insert your preferred dicing blade into the square slot.



**Note:** For eggs, insert the egg white filter into the square slot.




4. Place your vegetable in the middle of the square blade and firmly close the top.




5. For slicing, remove the dicing blade and the presser from underneath the lid. Then close the top and insert your preferred blade into the rectangular slot.



6. Pull up on the top of the slicing safety guard to reveal the spikes, and press firmly into your vegetable.



7. Move your vegetable back and forth along the blade.



8. Clean all parts with dish soap after use.



## Specifications

|                    |                     |
|--------------------|---------------------|
| Capacity:          | 40.6 oz             |
| Weight:            | 1.4 lb              |
| Product dimension: | 13.0 x 4.5 x 4.5 in |
| Materials:         | plastic / metal     |

## Get More Support

Scan the QR code below or email us at  
[contact@wasserstein-home.com](mailto:contact@wasserstein-home.com)



CONTACT US

**DW** DARTWOOD

[www.wasserstein-home.com](http://www.wasserstein-home.com)

Made in China