

Dartwood Label Maker

USER MANUAL




DARTWOOD

In the Box



1 portable
label maker




1 x mini USB
charging cable




1 x roll of label stickers
(inside label maker)

Setup


1. Open the top of the label maker. Push the tab on the top and lift up.




2. Undo the roll of label stickers and pull the end out from the bottom of the roll.



3. Close the top until it clicks. Make sure the end of the sticker roll is coming out through the slot.



4. Turn the label maker ON. Press and hold the power button until the light turns green.



Note:


A green light indicates that the device is ON.
A red light indicates that the device has a problem.
A flashing red light indicates that the device has a low battery.

Connecting to the App

1. Scan the QR code to download the Le Minyun App.



2. Open the Le Minyun App. From the 'Home' page, select 'Create Label' or 'Template' to get started.



Start Printing

1. After selecting 'Create Label', check your specifications and press 'New'.

The screenshot shows a mobile application interface for creating a new label. At the top, the status bar displays the time 10:52 and signal icons. The app's header is purple with a back arrow and the title 'New Label'. The main content area is white and contains several input fields and a toggle switch. The 'Equipment model' field is set to 'L11'. The 'Template Name' field is set to 'New Label'. The 'Label width' field is set to '30mm'. The 'Label height' field is set to '12mm'. The 'Type' field has four radio buttons: 'Gap' (selected), 'Black', 'Continuous', and 'Transparent'. The 'Rotation' field has four buttons: '0°', '90°' (selected), '180°', and '270°'. At the bottom of the form is a 'Cable labels' toggle switch, which is currently turned off. Below the form is a large blue button labeled 'New'.

10:52

< New Label

Equipment model L11

Template Name New Label

Label width 30mm

Label height 12mm


Type ☒ Gap ☐ Black ☐ Continuous ☐ Transparent

Rotation



Cable labels ☐

New

2. Select 'Text' and draft your sticker content.
 - 2a. When you are finished, select 'Print' at the bottom of the page.



- 2b. Enable Bluetooth on your device. On the 'Print Setup' page, press 'Equipment model'. Then, on the 'My device' page, select 'Lseries'.




- 2c. Once connected to your device, select 'Print' and check your printed label.




Choosing a Template


1. Select the 'Template' option on the 'Home' page.



2. Select your preferred template from the available options.



3. After choosing your template, select 'Edit' to add your label content. Follow steps 3 - 5 in the above section.



Charging the Label Maker

To charge your label maker, plug the mini USB cable into the bottom and plug the other end into a USB adapter/wall outlet.

Specifications

Print speed:	3.15 in / s (80 mm / s)
Printing method:	Thermal printing
Paper type:	Thermal roll paper
Sticker size:	1.2 in x 0.5 in (30 mm x 12 mm)
Interface:	mini USB
Battery (standby):	60 days
Battery (continuous):	3 - 4 hours
Weight:	0.55 lb

Get More Support

Scan the QR code below or email us at
contact@wasserstein-home.com



CONTACT US



DARTWOOD

www.wasserstein-home.com

Made in China