


Bike lock Reset Password Steps

The initial password of the lock is "00000"

- 1 Open the lock with default password "00000"




- 2 Turn the knob forward 90° from the default position



- 3 Turn the digital to set your new password




- 4 Rotate the "REST"knob 90° to the original position



- 5 Remember new password and scramble cipher bits



- 6 Dial back new pwd and insert the lock tongue to complete




WARM TIPS

- Only by setting the gear dial to the password that is currently in effect (the initial password is 00000, if you change it, it is the password set by yourself) you can turn the "RESET" knob to change the password.
- You should set a password that can be remembered easily and write it down in your notebook or take a photo of it using your phone.
- Note: Be sure to put your password from left to right as order is important.
- If you forget the password after the successful reset, you will not be able to open the lock!

Fahrradschloss Passwort zurücksetzen Schritte

Der voreingestellte Code ist "00000".

- 1 Öffnen Sie das Schloss mit Standard-Passwort "00000"




- 2 Drehen Sie den Drehknopf um 90° nach vorne aus der Standardposition



- 3 Drehen Sie den Schalter, um Ihr neues Passwort einzustellen.



- 4 4. Drehen Sie den "REST"-Knopf um 90° in die ursprüngliche Position



- 5 Neues Passwort merken und verschlüsseln Sie die Schlüsselbits



- 6 Neue Pwd zurückwählen und den Sperrknopf ein, um die



WARME TIPPS

- Nur wenn Sie das Zahnrad auf das aktuell gültige Passwort stellen (das anfängliche Passwort ist 00000, wenn Sie es ändern, ist es das von Ihnen eingestellte Passwort), können Sie den "RESET"-Knopf drehen, um das Passwort zu ändern.
- Legen Sie ein Passwort fest, das Sie sich leicht merken können, und notieren Sie es in Ihrem Notizbuch oder machen Sie ein Foto davon mit Ihrem Handy. Hinweis: Achten Sie darauf, dass Sie Ihr Passwort von links nach rechts eingeben, da die Reihenfolge wichtig ist.
- Wenn Sie das Passwort nach dem erfolgreichen Zurücksetzen vergessen, können Sie das Schloss nicht mehr öffnen!