FCPS-24(E) 24 Volt, 6 Amp Remote Power Supply

Section: Power Supplies/Accessories

GENERAL

The NOTIFIER FCPS-24 (120 VAC model) and FCPS-24E (220/240 VAC model) are compact, cost-effective, 6-amp remote power supplies with built-in battery charger. The FCPS-24(E) may be connected to any 12- or 24-volt Fire Alarm Control Panel (FACP) or may stand alone. Primary applications include Notification Appliance (bell) Circuit (NAC) expansion (to support ADA requirements) or auxiliary power to support 24-volt system accessories. The FCPS provides regulated and filtered 24 VDC power to four Notification Appliance Circuits (two Class A [Style Z] and two Class B [Style Y] or four Class B only). Alternately, the four outputs may be configured as any combination of resettable/non-resettable power outputs (optimal for powering four-wire smoke detectors). The FCPS-24(E) also contains a battery charger capable of charging up to 7.0 Amp Hour batteries.

FEATURES

- Requires input trigger voltage of 9.0 32 VDC.
- · Contains two, fully-isolated input/control circuits (triggered from FACP Notification Appliance Circuit [NAC expander mode] or jumpered permanently on [standalone mode]).
- Two Class A (Style Z) or Class B (Style Y) Notification Appliance Circuits (circuits 1 & 3).
- Two additional NACs that may be individually configured for Class B (Style Y) operation only (circuits 2 & 4).
- · 6 Amp full load output (3 amps max./ckt.) in NAC expander mode (UL 864).
- 4 Amp continuous output in stand-alone mode (UL 1481).
- In stand-alone mode, output power circuits may be configured as resettable (reset line from FACP required) or non-resettable.
- · Fully regulated and filtered power output (optimal for powering four-wire smoke detectors, annunciators and other system peripherals requiring regulated/filtered
- · Fuseless, power-limited technology meets new UL powerlimiting requirements, effective May 1, 1995.
- Normally closed trouble contact.
- · Fully supervised power supply, battery and Notification Appliance Circuits.
- · Selectable earth fault detection.
- AC trouble report selectable for immediate, 8- or 16- hour delay.
- · Optional ammeter/voltmeter.
- · Works with virtually any UL 864 fire alarm control which utilizes an industry-standard reverse-polarity notification circuit.










California State Fire Marshal





MEA 387-94-E (FCPS-24 only)



- Self-contained in compact, lockable cabinet (15" [381 mm] high x 14.5" [368 mm] wide x 2.75" [70 mm] deep).
- · Includes integral battery charger capable of charging up to 7.0 AH batteries.
- Fixed, clamp-type terminal blocks accommodate up to 12 AWG (3.25 mm²) wire.

STANDARDS and CODES

The FCPS-24 complies with the following standards:

- NFPA 72-1996 National Fire Alarm Code.
- UL 864 Standard for Control Units for Fire Alarm Systems (NAC expander mode).
- UL 1481 Power Supplies for Fire Alarm Systems (stand-alone mode).

This document is not intended to be used for installation purposes. We try to keep our product information up-to-date and accurate. We cannot cover all specific applications or anticipate all requirements. All specifications are subject to change without notice. For more information, contact NOTIFIER. Phone: (203) 484-7161 FAX: (203) 484-7118



12 Clintonville Road, Northford, Connecticut 06472





SPECIFICATIONS

Primary (AC) Power

- FCPS-24: 120 VAC 50/60 Hz, 2.0 A max.
- FCPS-24E: 220/240 VAC 50/60 Hz, 1.0 A max.
- Wire size: min. 14 AWG (2.0 mm²) with 600V insulation.

Control Input Circuit

Trigger input voltage: 9.0 to 32 VDC.
 Trigger current: 2.0 mA (16 - 32 V). (per input) 1.0 mA (9 - 16 V).

Trouble Contact Rating

5 amps at 24 VDC.

Auxiliary Power Output

• Specific application power - 45 mA short circuit.


Output Circuits

- Output voltage: 24 VDC filtered regulated (under primary AC mains) under secondary power source 19.1 to 26.4 VDC
- 3.0 amps maximum for any one circuit.
- 4.0 amps maximum total continuous current for all outputs (stand-alone mode).
- 6.0 amps maximum total short-term current for all outputs (NAC expander mode).

Secondary Power (Battery) Charging Circuit

- · Supports lead-acid batteries only.
- · Float charge voltage: 27.6V.
- · Maximum charge current: 250 mA.
- · Maximum battery capacity: 7.0 AH.

TERMINAL DESIGNATIONS



FCPS-24 Remote charger power supply (120 VAC). Includes main printed circuit board, transformers, surface-mount backbox, and installation instructions.

FCPS-24E Remote charger power supply (220/240 VAC). Includes main printed circuit board, transformers, surface-mount backbox, and installation instructions.

A77-716B 12/24 VDC end-of-line relay for monitoring four-wire smoke detector power.


PS-1270 Battery, 12 volt, 7.0 AH (two required).MPM-4 Optional ammeter/voltmeter. Mounts in FCPS backbox.

Page 2 of 3 — DN-5132 • 08/03/01

APPLICATION EXAMPLES


Example 1: Expand notification appliance power an additional 6.0 amps.

Use up to 4 Class B (Style Y) outputs *or* 2 Class A (Style Z) and 2 Class B (Style Y) outputs.




In this example, the FACP notification appliance circuits will activate the FCPS when reverse polarity activation occurs. Trouble conditions on the FCPS are sensed by the FACP through Notification Appliance Circuit #1.

Example 2: Use the FCPS to expand auxiliary regulated 24-volt system power up to 4 amps. Both non-resettable and resettable power options are available.



Resettable outputs are created by connecting the resettable output from the FACP to one or both of the FCPS inputs. Non-resettable outputs are created simply by cutting on board resistors. For addressable panel applications, use a monitor module to sense the trouble status of the FCPS via the trouble relay contacts.

Example 3: Use addressable control modules to activate the FCPS versus the FACP Notification Appliance Circuits. This typically allows for mounting the FCPS at greater distances away from the FACP while expanding system architecture in various applications.



In this example, an addressable control module is used to activate the FCPS and an addressable monitor module is used to sense FCPS trouble conditions. Local auxiliary power output from the FCPS provides power to the addressable control module.