

80g书写纸 377x115mm 手折风琴页



Make your gaming experience convenient with the PS5 controller charging station from Wasserstein.


Table of Contents

Package Includes	2
Safety Information	2
Features	2
Introduction	3
Installation	3
Charging your controllers	3
Troubleshooting	4
Specification	4

Need help? Send us an email at: contact@wasserstein-home.com Page 1 - 4

Package Includes

- 1 x Charging Station with attached charging cable
- 2 x 2 x Adapters
- 1 x User Manual



Safety Information

- Do not disassemble or put this charging station into water or fire.
- Do not use it in severe damp or corrosive environments to avoid circuit damage.
- Do not use unauthorized or incompatible power adapters to avoid damage to this charging station.
- If the charger output is short-circuited, the charger indicator flashes quickly.

Feature



Compatible with
PS5 controllers



Fast charging for your controllers



Easy to use



Thoughtful design
to save space



Built-in chip to protect against overcharging

Need help? Send us an email at: contact@wasserstein-home.com Page 2 - 4

Introduction

This charging station consists of 2 pieces of adapters that can charge two PSS controllers at the same time. The charging indicators located at the front of the charging dock, light up in red when charging the controllers and in blue when the controllers are fully charged.

Installation

1. Plug the attached USB cable's Type-A connector of the cable into a power supply. (Note: Wall charger not included)
2. Once you finish connecting, the two indicator lights of the charging dock will light up at the same time. The indicators will turn red first and blue. The two lights will then switch off at the same time to complete the self-check. This ensures that the charging dock is connected normally to the power supply.



Charging your controllers

1. Insert the included adapters into the PS5 controllers by attaching the adapter into the controller's Type C charging port.

2. Place the PS5 controller (attached with the adapter) into the charging slot of the charging dock, and the corresponding charging indicator will light up in red, indicating that it is charging normally.
(Note: Make sure that the adapter is aligned with the receptor pins of the charging dock when you place your PS5 controller as shown below in the picture.)



Need help? Send us an email at: contact@wasserstein-home.com Page 3 - 4

3. The indicator lights remain red when charging the controllers and when the battery of the controller is full, the indicator lights will change to blue.
4. Remove the adapter from the PS5 controller after the charging is completed to start playing your favorite games with your controller.

Troubleshooting

1. The charging indicator flashes quickly.
The charger output is short-circuited. Please check if there is something shorting the charging pins.
2. The charging indicator does not light up initially the same way as described above.
Please ensure that the power supply and connection are stable.
3. How many controllers can I charge at the same time?
You can charge up to 2 controllers simultaneously.

Specification

Input Voltage	: DC5V±0.25V
Max Charging Current	: 750mA (max) (one controller) : 1500mA (max) (two controller)

For more information, visit:
www.wasserstein-home.com
or contact us at:
contact@wasserstein-home.com



Wasserstein is not affiliated with Sony Inc.
Wasserstein Controller Charging Station is a trademark of Dropcases Ltd.
Play Station 5 is a trademark of Sony Inc.

Made in China

Need help? Send us an email at: contact@wasserstein-home.com Page 4 - 4

