

Open this card to get started.

It's time to experience whole-home, uninterrupted WiFi coverage.

We're glad you're here.

WYZE

FCC RADIATION EXPOSURE STATEMENT:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC WARNING:
Any change or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Your Wyze product is covered by a one-year limited warranty. You can view the limited warranty terms at <https://wyze.com/return-warranty-policy> or request a copy by contacting Wyze at +1 (206) 339-9666.

NEED HELP?
Contact our Support Team:
<https://wyze.com/support>
Join the Community:
<https://wyze.com/community>
Wyze and Wyze Mesh Router are trademarks of Wyze Labs, Inc.

ISED RADIATION EXPOSURE STATEMENT:
This equipment complies with ISED RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Only use the power supply provided. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

ISED RSS WARNING:
This device complies with ISED licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. This device is restricted to indoor use.

DÉCLARATION D'EXPOSITION AUX RADIATIONS DE L'ISED:
Cet équipement est conforme aux limites d'exposition aux rayonnements RF édictées par l'ISED pour un environnement non contrôlé. Cet émetteur ne doit pas être installé ou utilisé en conjonction avec une autre antenne ou un autre émetteur. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps. Utilisez uniquement l'alimentation électrique fournie.

AVERTISSEMENT RSS DE L'ISED:
Cet appareil est conforme à la ou aux normes RSS exemplaires de licence de l'ISED. Son fonctionnement est soumis aux deux conditions suivantes : (1) Ce dispositif ne doit pas causer d'interférences, et (2) ce dispositif doit accepter toute interférence, y compris les interférences qui peuvent causer un fonctionnement indésirable du dispositif. Utilisation limitée à l'intérieur seulement.

BESOIN D'AIDE?
Contactez notre service d'assistance:
<https://wyze.com/support>
Rejoignez la communauté:
<https://wyze.com/community>
Wyze et Wyze Mesh Router sont des marques déposées de Wyze Labs, Inc.

Scan the QR code to learn more

Scannez le code QR pour en savoir plus

SETUP

➤ Download the Wyze app and sign in or create an account.

Download on the **App Store** GET IT ON **Google Play**

Apple logo and App Store are trademarks of Apple Inc., registered in the U.S. and other countries and regions. * Google Play and the Google Play logo are trademarks of Google LLC.

➤ Open the Wyze app and tap the + plus sign on the top left corner of the Home screen. Tap Add Device > Home > Wyze Mesh Router.

➤ Follow the in-app instructions to finish setup.

IN THE BOX

Wyze Mesh Router × 1
3' Ethernet Cable × 1
Power Adapter × 1
Quick Start Guide × 1

STATUS LIGHT GUIDE

1 Solid white light
Power is on and functioning correctly

2 Flashing white light
In pairing mode

3 Flashing blue light
Connecting to Bluetooth

4 Solid orange light
Internet connection lost

5 Flashing orange light
Router is performing a booting sequence

CONFIGURATION

➤ Téléchargez l'application Wyze et connectez-vous ou créez un compte.

Download on the **App Store** GET IT ON **Google Play**

Le logo d'App Store et d'App Store sont des marques d'Apple Inc., déposées aux États-Unis et dans d'autres pays et régions. * Google et Google Play sont des marques de Google LLC.

➤ Ouvrez l'application Wyze et appuyez sur le signe + plus dans le coin supérieur gauche de l'écran d'accueil. Appuyez sur Add Device > Home > Wyze Mesh Router.

➤ Suivez les instructions de l'application pour terminer la configuration.

DANS LA BOÎTE

Wyze Mesh Router × 1
Câble Ethernet 3' × 1
Adaptateur secteur × 1
Guide de démarrage rapide × 1

GUIDE DES VOYANTS D'ÉTAT

1 Lumière blanc fixe
L'alimentation est sous tension et fonctionne correctement

2 Lumière blanc clignotante
En mode d'appairage

3 Lumière bleue clignotante
Connexion à Bluetooth

4 Lumière orange solide
Connexion Internet perdue

5 Lumière orange clignotante
Le routeur effectue une séquence d'amorçage