

QUICK START GUIDE

GET BETTER SECURITY WITH  **Cam Plus**

Record Full-Length Videos
Get unlimited full-length video recordings.

Smart A.I. Detection
Detect people, packages, vehicles, and more.

Back-to-Back Event Recording
Capture everything without 5-minute gaps.

Exclusive Discounts
Get exclusive discounts on Wyze products.

Subscribe or learn more at services.wyze.com.

IN THE BOX

Wyze Wireless Video Doorbell Pro × 1	Bracket Screws × 3
Wyze Chime × 1	Extension Wires × 2
Back Plate For Screw × 1	Expansion Tubes × 3
Back Plate For 3M Tape × 1	3M Tape × 1
USB Charging Cable × 1	T8 Screwdriver × 1
Wire Nuts × 3	Quick Start Guide × 1




Back Plate For Screw




Back Plate For 3M





Wedge Kit



Corner Kit



Wyze Chime



SETUP

1 Download the Wyze app and sign in or create an account.




2 Open the Wyze app and tap the + plus sign on the top left corner of the Home screen. Tap **Add Device** > **Cameras** > **Wyze Wireless Video Doorbell Pro**. Follow the in-app instructions to finish installation.


3 To add Wyze Chime, either (1) tap **Continue to add chime** after installing the doorbell, or (2) select an installed doorbell, then tap the settings gear > **Extended Devices** > **Add Device**. Follow the instructions to finish installation.

INSTALLATION


Doorbell without wedge installed with screw.




Doorbell without wedge installed with 3M tape.




Doorbell with wedge installed with screw.



Doorbell with wedge installed with 3M tape.



WHERE TO PLACE YOUR DOORBELL AND CHIME



- (1) The ideal location to place the chime is half-way between your router and your doorbell.
- (2) Heavy-duty walls and floors made of materials like concrete, brick or metal can weaken your doorbell signal strength.

OPTIONAL CHOICES FOR WEDGE KIT OR CORNER KIT USERS

Use Corner Kit to change the horizontal angle



Angle (without Corner Kit) Angle (with Corner Kit)

Use Wedge Kit to change the vertical angle



Angle (without Wedge Kit) Angle (with Wedge Kit)

STATUS LIGHT

Wyze Wireless Video Doorbell Pro

 **Solid Yellow Light**

The device is charging

 **Solid Blue Light**

The device is fully charged

Wyze Chime

 **Flashing Red Light**

Connecting to doorbell

 **Flashing Yellow Light**

Waiting for connection

 **Flashing Blue Light**

Connecting to network

 **Solid Blue Light**

Connected

Wyze Wireless Video Doorbell Pro

FCC Warning

Any change or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED RSS warning

This device complies with ISED licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may

not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

ISED Radiation Exposure Statement

This equipment complies with ISED RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

Cet appareil est conforme aux limites d'exposition de rayonnement RF ISED établies pour un environnement non contrôlé. Cet émetteur ne doit pas être co-implanté ou fonctionner en conjonction avec toute autre antenne ou transmetteur. Cet émetteur ne doit pas être co-implanté ou fonctionner en conjonction avec toute autre antenne ou transmetteur.

Industrial cellular router doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur & votre corps.

Wyze Chime

FCC Warning

Any change or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED RSS warning

This device complies with ISED licence-exempt RSS standard (s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

ISED Radiation Exposure Statement

This equipment complies with ISED RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

Cet émetteur ne doit pas être co-implanté ou fonctionner en conjonction avec toute autre antenne ou transmetteur. Industrial cellular router doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur & votre corps.

NEED HELP?

Contact our Support Team at:
<https://wyze.com/support>

Join the Community:
<https://wyze.com/community>



Scan the QR code
to learn more