


**vtech**<sup>®</sup>  
Baby

# User's Manual

## Toot-Toot Drivers<sup>®</sup>

### Garage



© 2015 VTech  
Printed in China  
91-003022-001 

**VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...**

## **vtech** Baby

**Toys that will stimulate their interest in different textures, sounds and colours**

### **I am...**

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

*Birth-36 months*



## **Pre-School**

**Interactive toys to develop their imagination and encourage language development**

### **I want...**

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

*3-6 years*



## **Electronic Learning Computers**

**Cool, aspirational and inspiring computers for curriculum related learning**

### **I need...**

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school


*4-10 years*



To learn more about this and other VTech® products, visit [www.vtech.co.uk](http://www.vtech.co.uk)

# INTRODUCTION

Thank you for purchasing the **VTech® Toot-Toot Drivers® Garage!** Park, play and learn with the **Toot-Toot Drivers® Garage**. This interactive garage features three floors of pretend play and learning fun.



# INCLUDED IN THIS PACKAGE



One **SmartPoint®**  
tow truck



One lift tower



One vehicle lift



One fuel accessory



One welcome gate



One **SmartPoint®**  
car wash




One curved ramp track



One straight ramp track



One ground floor  
**SmartPoint®** platform




One first floor  
**SmartPoint®** platform




One second floor  
**SmartPoint®** platform



- One snap-in large support
- One medium support
- One snap-in small support
- One mini support
- Two snap-in mini supports



- Two male/female connector tracks
- Two male connector tracks
- One 90-degree female track
- One 90-degree male track
- One lift support piece



- Two label sheets
- One user's manual

## WARNING:

All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.

## NOTE:


Please keep this user's manual as it contains important information.



## CAUTION:

**Adult assembly required. For your child's safety, do not let your child play with the toy until it is fully assembled.**

Unlock the packaging locks:




- ① Turn the packaging lock counter-clockwise several times.
- ② Pull out and discard the packaging lock.

# GETTING STARTED


## BATTERY INSTALLATION – TOW TRUCK

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the bottom of the tow truck. Use a coin or a screwdriver to loosen the screw.
3. Install 2 new “AAA” (AM-4/LR03) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure.



## BATTERY INSTALLATION - GARAGE

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the top platform of the **Garage**. Use a coin or a screwdriver to loosen the screw.
3. Install 2 new 'AA' (AM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure.



## BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

## Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005.


Help protect the environment by disposing of your product or batteries responsibly.


For more information, please visit:

[www.recycle-more.co.uk](http://www.recycle-more.co.uk)

[www.recyclenow.com](http://www.recyclenow.com)

**Please stick the labels to the play set securely as indicated on the following page:**








# ASSEMBLY INSTRUCTIONS

With the **VTech® Toot-Toot Drivers® Garage** safety comes first. To ensure your child's safety, adult assembly is required.



1. With the ground floor platform right-side up, insert the two snap-in mini supports into the slots on the ground floor platform as shown. The snap-in mini supports will fit in the slots snugly. The teeth on the snap-in mini supports will grip to the ground floor platform.




2. With the first floor platform upside-down, insert the snap-in small support into the slot on the first floor platform as shown. The snap-in small support will fit in the slot snugly. The tooth on the small support will grip to the first floor platform.




3. Turn the first floor platform right-side up. Next, connect the open first floor platform support slots to the snap-in mini supports attached to the ground floor platform as shown. Press down to make sure the pieces are securely connected.




4. Insert the bottom of the vehicle lift into the first floor platform as shown. You will hear a click sound to indicate the vehicle lift is secure. Once the vehicle lift is connected to the first floor platform, it cannot be detached.





5. Insert either side of the mini support into the slot on the first floor platform as shown.




- With the second floor platform upside-down, insert the snap-in large support into the largest slot on the second floor platform as shown. The snap-in large support will fit in the slot snugly. The tooth on the snap-in large support will grip to the second floor platform.





- Turn the second floor platform right-side up. Next, line-up the vehicle lift and mini support with the second floor platform slot openings as shown. Then, press down on the second floor platform to secure it to the vehicle lift and mini support.





- Attach the curved ramp track to the first floor platform and second floor platform as shown.





9. Insert the medium support into the slot on the bottom of the curved ramp track as shown.



10. Attach the straight ramp track into the first floor platform as shown.




11. Attach the lift tower to the second floor platform. First, connect the track portion of the second floor platform to the back of the lift tower as shown. Next, connect the open slot on the lift tower to the connector piece on the second floor platform as shown. You will hear a click sound to indicate the lift tower is secured to the second floor platform. Once the lift tower is connected to the second floor platform, it cannot be detached.



12. Attach the fuel accessory to the second floor platform as shown. You will hear a click sound to indicate the fuel accessory is secured to the second floor platform. Once the fuel accessory is connected to the second floor platform, it cannot be detached.




13. Attach the welcome gate to the second floor platform as shown.



14. With the lift/launcher at the base of the lift tower, attach the lift support piece to the lift tower as shown. You will hear a click sound to indicate the lift support piece is secured to the lift tower. Once the lift support piece is connected to the lift tower, it cannot be detached.




Once you've completed the above steps, you are ready to play! You can connect these pieces to the other included track pieces or you can connect this play set to other **Toot-Toot Drivers®** play sets (each sold separately).



## EXPAND & EXPLORE


Connect to the **Toot-Toot Drivers® Deluxe Track Set** (as shown below) or other **Toot-Toot Drivers®** play sets (each sold separately) to expand the Toot-Toot Drivers Garage and inspire creativity.



## PRODUCT FEATURES – TOW TRUCK

### 1. ON/OFF SWITCH

To turn the tow truck **ON**, slide the **ON/OFF SWITCH** on the tow truck to the **ON (⏻)** position. To turn the tow truck **OFF**, slide the **ON/OFF SWITCH** to the **OFF (●)** position.




## 2. AUTOMATIC SHUT-OFF

To preserve battery life, the tow truck included with the **VTech® Toot-Toot Drivers® Garage** will automatically power-down after approximately 65 seconds without input. The unit can be turned on again by pressing the light-up face button or pushing the tow truck quickly.

**Note:** This product is in try-me mode in the packaging. After opening the package, turn the vehicle off and on again to proceed with normal play.

## ACTIVITIES – TOW TRUCK


1. Slide the **ON/OFF SWITCH** to the **ON** position to turn the unit **ON**. You will hear a song, a phrase and sounds. The light will flash with the sounds.



2. Press the light-up face button to hear tow truck sounds, songs and phrases. The light will flash with the sounds.



3. Push the tow truck to hear fun sounds, and melodies. While the melody is playing, push the vehicle again to add in fun sounds on top of the melody. The light will flash with the sounds.




4. For added fun, the tow truck interacts with the **Toot-Toot Drivers® Garage**. Simply roll or place the tow truck on one of the play set's **SmartPoint®** locations to hear the tow truck play fun sounds, short tunes and sing-along songs. The tow truck even interacts with other **Toot-Toot Drivers®** play sets (each sold separately).

## PRODUCT FEATURES - GARAGE

### 1. ON/OFF/VOLUME CONTROL SWITCH

To turn the unit **ON**, slide the **ON/OFF/ VOLUME CONTROL SWITCH** to the low volume (  ) or high volume (  ) position. To turn the unit **OFF**, slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **OFF** (  ) position.



### 2. SMARTPOINT® LOCATIONS

The **Garage** includes 9 **SmartPoint®** locations that interact with the included tow truck or any other **Toot-Toot Drivers® SmartPoint®** vehicle (each sold separately). Simply roll or place the vehicle over a **SmartPoint®** location to hear fun sounds, phrases and music.





### 3. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech® Toot-Toot Drivers® Garage** will automatically power-down after approximately 55 seconds without input. To wake up the unit, activate any of the electronic features on the play set.

# ACTIVITIES - GARAGE


1. Slide the **ON/OFF/VOLUME CONTROL SWITCH** to either volume setting to turn the unit on. You will hear a song, phrase and fun sounds. The lights will flash with the sounds.
2. Press the **LIGHT-UP BUTTONS** to hear fun phrases, sounds, songs and melodies. While a melody is playing, press any of the 3 **LIGHT-UP BUTTONS** to add in fun sounds on top of the melody. The lights will flash with the sounds.
3. Place a vehicle on the **LIFT/LAUNCHER**, and rotate the **HELICOPTER PAD** clockwise or counter-clockwise. Based on the way the **HELICOPTER PAD** is rotated, the **LIFT/LAUNCHER** will go up or down the **LIFT TOWER**. As the **LIFT/LAUNCHER** reaches each floor you will hear fun sounds and phrases. When the **LIFT/LAUNCHER** reaches the second floor, it will trigger the launcher button.



4. Raise the **VEHICLE LIFT** up to hear fun sounds. The lights will flash with the sounds.



5. Raise the **ELECTRONIC GATE** up or down to hear fun sounds and a phrase. The lights will flash with the sounds.



## SING-ALONG SONG LYRICS

### Garage

#### SONG 1

Here's your parking ticket,  
Drive on through.  
Enjoy your stay.  
There is so much to do!

#### SONG 2

Ride the lift floor to floor.  
There are so many fun things to explore.

#### SONG 3

Fill up here,  
Parking there,  
Thanks for visiting and please take care!

## MELODY LIST

### Garage

1. Alexander's Ragtime Band
2. Green Grass Grew All Around
3. Bicycle Built for Two
4. Chicken Reel
5. Farmer in the Dell
6. It's Raining, It's Pouring
7. Muffin Man
8. Where Has My Little Dog Gone
9. One, Two, Buckle My Shoe
10. Polly Wolly Doodle
11. Shoo Fly
12. Ten Little Indians

## CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

# TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit sit for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK) and a service representative will be happy to help you.

## IMPORTANT NOTE:

Creating and developing **VTech®** products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK), with any problems and/or suggestions that you might have. A service representative will be happy to help you.

CLASS 1  
LED PRODUCT



## PRODUCT WARRANTY



Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.

1. The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
2. The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
3. VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
5. This warranty is personal to the original purchaser and is not transferable.
6. Breakages to the LCD screen are not covered by the warranty.
7. Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging.
8. Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor).  
Please include details of the fault together with your name and address.

VTech Electronics Europe plc, c/o Tablogix Limited, 200 Milton Park, Abingdon, Oxon OX14 4TA

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.

