




GETTING STARTED

– CREATIVE PEBBLE V3

POWERING THE PEBBLE V3




To power up the Creative Pebble V3, connect it to your PC or Mac via the USB-C cable.



If your PC or Mac does not have a USB-C port, we've included a USB-C to USB-A converter that you can use if necessary.



Alternatively, you can also power the Creative Pebble V3 with a wall adapter* and connect your MP3 player or other analog devices via an AUX-in cable*.



*Wall adapter and AUX-in cable not included. For the wall adapter, you can check out the [Creative 30W PD Adapter](#) at the Creative Store.

SWITCHING ON / VOLUME



To switch on the Creative Pebble V3, simply turn the volume knob clockwise.

The LED indicator will be in blue color when the speaker is switched on.

If the Creative Pebble V3's volume remains low even when the speakers are at maximum volume:

1. Ensure that your device's (e.g. laptop, desktop or mobile phone) volume is turned up. The Creative Pebble V3's volume is independent of your device—both will need to be turned up to an acceptable level.
2. If the audio level remains low, the Creative Pebble V3 is most likely not receiving sufficient power from your device. This is a common occurrence found in older computers and laptops. We recommend you to connect the speakers directly to a wall adapter and use an AUX-in cable for the audio output.


CONNECTIVITY

USB AUDIO MODE

Connecting to PC

Your PC will automatically detect the Creative Pebble V3 when you plug in the USB cable.

If you do not hear any audio playing from the speaker, check the output device list from the 'Sound' setting and set Creative Pebble V3 as the default output speaker.



Connecting to Mac

For Mac users, you will need to adjust your audio settings.

Choose **Apple Menu > System Preferences**, click 'Sound', then click 'Output' to select 'Pebble V3'.



BLUETOOTH MODE

For wireless audio streaming*, pair the Creative Pebble V3 to your mobile device via Bluetooth.

*Do note that the Creative Pebble V3 still has to be powered via USB

Pairing your device with Creative Pebble V3 via Bluetooth



Step 1: Press the Bluetooth button for 2 seconds.



Step 2: Select 'Pebble V3' from the list of discovered Bluetooth devices on your mobile device to pair.

Upon successful pairing, the LED will pulse in blue.

SWITCHING BETWEEN SOURCES

Press the Bluetooth button once to switch between audio sources.



When plugged into a PC / Mac for the first time, the Creative Pebble V3 will be in **USB Audio Mode** by default. When plugged into a power source that does not support USB Audio, the Creative Pebble V3 will be in **Bluetooth Pairing Mode** by default.

*When AUX-in cable is detected / connected

HIGH / LOW GAIN SWITCH



The Creative Pebble V3 is set to High Gain Mode out of the box.

When plugged into a 10W USB-C or USB-A port, the built-in gain switch located at the bottom of the Creative Pebble V3 will activate the High Gain Mode that delivers acoustic power of up to 8W RMS and peak power of up to 16W, giving you louder, powerful audio.


LED INDICATORS

USB Audio / Bluetooth Mode

USB Connected



Bluetooth Pairing



Flashing LED

Bluetooth Connected



Pulsing LED



High Gain



Low Gain

AUX-in Mode

Detected / Connected



MORE QUESTIONS?

If you require more assistance, please do not hesitate to contact us directly on Amazon. Alternatively, you can also find our support materials and help resources online easily.