

Performance Built For Business



f1600

## **Commercial Clothes Steamer**

**INSTRUCTION MANUAL**

**FRIDJA**



# F1600 COMMERCIAL CLOTHES STEAMER

## 1. INTRODUCTION

Thank you for choosing the Fridja f1600 Commercial Clothes Steamer.

Engineered for high-demand environments like retail, hospitality, and tailoring, the f1600 delivers powerful, continuous steam to keep garments looking fresh, fast. Whether you're steaming all day or just tackling a full rail, this commercial-grade machine is designed for consistent performance and easy operation.

**Fridja – Performance built for business.**



For a step-by-step assembly video, scan the QR code or visit: [www.fridja.com/f-1600-assemble-video](http://www.fridja.com/f-1600-assemble-video)

## 2. SPECIFICATIONS

**Model: f1600 Commercial Clothes Steamer**

**Power Output: 2200W**

**Input Voltage: 240–110 V, 60/50 Hz**

**Water Tank Capacity: 4.0 Litres**

**Steam Settings: 2 levels**

**Steam Output: 47 g/min**

**Heating Time: Approx. 45 seconds**

**Pole: Adjustable**

**Drainage Valve: Yes**

**Cord Length: 2.0 m**

**Weight: Net: 7.5 kg | Gross: 9.0 kg**

**Housing Material: ABS with copper heater**

## 3. SAFETY INSTRUCTIONS


For best results and long-term performance, always use distilled, demineralised, or filtered water in your steamer. Hard tap water can cause limescale buildup, reduce steam output, and leave mineral residue on clothing. Filtered water helps reduce maintenance and prolongs the life of the machine.

### Important Safety Precautions:

- Use only on a flat, stable, heat-resistant surface.
- Never operate the steamer without water in the tank.
- Only fill with clean water – do not add detergents, oils, or fragrances.
- Do not tilt, shake, or move the steamer while in use.
- Keep the steam head away from skin, eyes, and delicate fabrics – the metal plate becomes extremely hot.
- Always unplug before filling, draining, cleaning, or moving the steamer.
- Allow the unit to fully cool before storage or refilling.
- Never immerse any part of the appliance in water.
- Keep the power cord away from heat sources and sharp edges.
- Do not pull or lift the steamer by the hose.
- Allow all attachments to cool before handling.
- Do not use on steam-sensitive fabrics like suede, velvet, leather, vinyl, or plastic. Test on a hidden area if unsure.

## 4. WHAT'S IN THE BOX

- |                      |                                 |
|----------------------|---------------------------------|
| 1. Steamer Base Unit | 7. Drainage Cap                 |
| 2. Telescopic Pole   | 8. Heatproof Glove              |
| 3. Steam Hose        | 9. Fabric Brush Attachment      |
| 4. Steam Head        | 10. Clasp Attachment            |
| 5. Steam Head Hook   | 11. Descaling Crystals (1 pack) |
| 6. Water Tank        |                                 |



## 5. ASSEMBLY INSTRUCTIONS

### 1. Extend the Telescopic Pole

Twist to unlock and adjust height. Lock in place.

### 2. Attach the Pole to the Base Unit

Insert into the base and twist clockwise to secure.

### 3. Connect the Steam Hose

Screw the hose into the base firmly.

### 4. Attach the Steam Head Hook

Fix the hook to the top of the pole.

### 5. Hang the Steam Head

Place the head on the hook when not in use.

### 6. Insert the Water Tank

Fill with water and insert into the base.

### 7. Fit Accessories (Optional)

Add the brush, clasp, or glove if needed.



Scan the QR code or visit  
[www.fridja.com/f-1600assemble-video](http://www.fridja.com/f-1600assemble-video)  
 to watch the full setup video.

## 6. HOW TO USE

### 1. Fill the Water Tank

Remove the tank, unscrew the cap, fill with clean water, and reinsert.

### 2. Plug In and Switch On

Connect to power and press the on button. Wait around 45 seconds.

### 3. Select Steam Level

Choose low or high depending on fabric type.

### 4. Start Steaming

Hang the garment on your own hanger and glide the steam head slowly down the fabric.

### 5. After Use

Switch off and unplug. Let it cool before emptying the tank or storing.

**Important: Always hang the steam head on the hook when not in use. Never twist, bend, or pull the hose forcefully.**

## F1600 COMMERCIAL CLOTHES STEAMER

### 7. TIPS FOR STEAMING

- **Use your own hanger:** The f1600 comes with a hook, not a hanger.
- **Keep fabric taut:** Hold the garment with one hand while steaming with the other.
- **Let steam flow:** Hover or lightly touch fabric with the top curve of the steam head.
- **Work from top to bottom:** Glide slowly for best results.
- **Thicker fabrics:** Go over areas multiple times as needed.
- **Let it rest:** Allow garments to hang and dry after steaming.



Watch Our Tips Video

**Scan the QR code** or search YouTube:

Top 5 Tips on How To Use A Clothes Steamer (1M+ views)

### 8. CLEANING AND DESCALING

Descale regularly to keep your steamer in peak condition — especially in hard water areas.

#### Steps:

1. Unplug and allow the unit to cool fully.
2. Remove the tank and hose.
3. Open the drainage cap and empty water.
4. Add a small pinch of descaling crystals to 200 ml of water and pour into the tank space.
5. Gently tilt the steamer to loosen mineral build-up.
6. Drain the solution. Rinse with clean water and repeat until clear.

**Tip: Descale monthly or when steam output reduces.**

#### SCAN THE QR CODES

Check out our social media channels now.



## 9. TROUBLESHOOTING

---

**Problem:** Unit fails to steam, light does not turn on

**Reason:** Not plugged in

**Solution:** Check power socket and switch on.

**Problem:** No steam

**Reason:** Water tank is empty

**Solution:** Fill the tank.

**Problem:** Gurgling sound from hose or base

**Reason:** Condensation in hose

**Solution:** This is normal. If excessive, extend the hose to let water drain.

**Problem:** Weak or intermittent steam

**Reason:** Mineral build-up

**Solution:** Descale the unit.

## 10. STORAGE TIPS

---

Let the steamer cool completely before storing. Empty the tank to prevent mineral build-up.

Avoid pressure on the hose. Store in a clean, dry area, ideally in the original box, away from direct sunlight and dust.

Regular, careful storage will extend the steamer's life and performance.

## 11. WARRANTY

---

Your f1600 is covered by a -12month warranty against manufacturing faults.

**To register, go to:**

<https://fridja.com/pages/product-registration>

Keep your proof of purchase.

**For full terms visit:**

<https://fridja.com/pages/terms-conditions>

To contact us please email [info@fridja.com](mailto:info@fridja.com) or visit <https://fridja.com/help>

## 12. PLUG SAFETY (UK ONLY)

---

This steamer comes with a 13A plug. If replacing the fuse, use only a 13A ASTA-approved (BS 1362) fuse.

If the plug or cord is damaged, it must be replaced by a qualified technician. Never connect wires incorrectly.

Do not use a damaged or repaired plug.

## 13. DISPOSAL & RECYCLING

---

This product and packaging should not be disposed of with household waste. Please take it to an authorised recycling facility.



# FRIDJA



**UK REGISTERED ADDRESS**

12 CELIA ROAD  
LONDON, N5 19ET  
UNITED KINGDOM

**EU REGISTERED ADDRESS**

77 CAMDEN STREET,  
DUBLIN 2, D02 XE80  
REPUBLIC OF IRELAND

[www.fridja.com](http://www.fridja.com)