

FN Key combination Function list

WIN:
FN+ESC Reset
FN+F1 Multimedia
FN+F2 Volume ↓
FN+F3 Volume ↑
FN+F4 Volume mute
FN+F5 Last song
FN+F6 Next song

FN+E7 Pause playback
FN+F8 CD Stop
FN+F9 Email
FN+E10 IE
FN+F11 My Computer
FN+F12 Calculator

MAC:
FN+ESC Reset
FN+F1 CD Stop
FN+F2 Email
FN+F3 IE
FN+F4 My Computer
FN+F5 Calculator

WIN/MAC:
F7 FN+1 Bluetooth 1
F8 FN+2 Bluetooth 2
F9 FN+3 Bluetooth 3
F10 FN+4 2.4G mode
F11 FN+5 Wired mode
F12 FN+ENTER Switch backlight
F6 FN+、 Light mode switch
FN+< Monochrome light switch
FN+↑ Backlight brightness ↑
FN+↓ Backlight brightness ↓
FN+← Backlight speed reduction
FN+→ Backlight speed plus
FN+Y Parts
FN+U Scrlk
EN+H Pause
FN+J Ins
FN+N Home
FN+M End



02

Keyboard connection

Bluetooth mode: Press and hold the FN+1/2/3 key combination for 3S to make the keyboard enter pairing mode, the 1/2/3 indicator flashes quickly, and the 1/2/3 indicator stays on for 3S after connecting to the device, if not connected device, lights off, keyboard goes to sleep.



2.4G Mode: Press and hold the FN+4 key combination for 3S to make the keyboard enter 2.4G mode, the indicator light flashes quickly, insert the 2.4G dongle, exit the pairing after successful pairing, and exit the pairing mode after 30s if the paired device is not found, the indicator light is off, the keyboard go to sleep.



Wired mode: Press and hold the FN+5 key combination for 3S to make the keyboard enter wired mode.



03

Model:GK75

10

Keyboard lighting settings



- FN+、: Keyboard lighting mode change
- FN+<: Monochrome light switch
- FN+←: Backlight speed reduction
- FN+→: Backlight speed plus

- FN+↓: Backlight brightness ↓
- FN+↑: Backlight brightness ↑