

Smart glasses



Switch on/off

Right touch



Left touch

Power on: After wearing glasses, the induction will automatically turn on.

Power off: take off the glasses, 15 seconds after the automatic power off or wear state. Long press the left or right touch button for 8 seconds to force power off.

(**Note:** If it doesn't turn on when you wear it, please take it off and wear it again. Wearing Please keep the lens legs dry and tidy when wearing, if sweat will affect the switching off effect.

If the power is lower than 3.1V, it will turn off automatically.)



Pairing of both arms




After the smart glasses are turned on, open the Bluetooth of your cell phone, search for the device name G06 and connect it

(**Note:** Smart glasses charging automatically shut down; Android devices Bluetooth search when the Individual icons are not the same, please refer to the model number)



Pairing



Wear detection



Music is played automatically when the glasses are worn and paused when the glasses are removed.

Wear Sensor Mode: When the glasses are connected to the cell phone and the music is playing, take off the glasses and

play the music automatically. music playback when the glasses are connected to the cell phone, take off the glasses


and automatically pause the music playback, put on the glasses and automatically play the music until the phone is

turned off.



Phone

Right touch



x1

Left touch

Incoming call answer/hang up: touch key (left or right) 1 click

Rejecting a call: Long press the touch key (left or right) for 1.5 seconds

(**Note:** In music mode, priority is given to incoming calls. Adjustable during a call


Volume Press and hold the right slide bar to slide forward to adjust the volume up, slide backward to adjust the volume down. Adjust volume by sliding the right side

slider forward to adjust loud volume, and backward to adjust small volume)



Music

Right touch



x1

x2

Left touch

Music pause/play: touch key (left or right) 1 click

Music switching: Double-click the left touch key to switch to the previous song

Double-tap the right touch key to switch to the next song



Wake up voice assistant

Right touch



x1

Left touch

Remote control photo taking: first open the camera in the cell phone and Press and hold the right touch button for 2


seconds to take a picture remotely.

(**Note:** in non-call/non-music state)



Remote control Take photos

Right touch



x1


Left touch

Wake up the voice assistant: Long press the left touch key for 2 seconds

(**Note:** Click to cancel voice assistant)



Volume



Volume slide key

Volume down: press and hold the right slider back


Volume up: press and hold the right slider and slide forward.

(**Note:** Music volume can also be adjusted on the phone)



Outdoor mode

Right touch




x3

Outdoor Mode: 3 clicks on the right touch button

(**Note:** the volume can be increased in noisy environment, also applies to the call status)



Charge



Magnetic charging: Orange light is always on when charging, and when fully charged The green light will be on for 1 minute and then turn off.

(**Note:** the glasses will be turned off automatically when charging)