



# SwitchBot Multitasking Household Robot K20+ Pro Quick Start Guide

1




Unpack and take out the displayed parts.

2




Place the Dual Empty Station on a level and hard surface. Then connect the power cord.

3



Remove foam strips from the robot and Mobile Base and install the Side Brush.

4



Power on the product.

- ① Remove the faceplate of the robot and flip the power switch to "ON".
- ② Turn the Mobile Base upside down and flip the power switch to "ON".


5



Download the SwitchBot app.


- ① Add your Robot Vacuum K20+ to the app.
- ② Add your Mobile Base to the app.
- ③ Pair them up as prompted.
- ④ Check that their indicator lights are steady white.

6




Dock your Mobile Base to the station and fully charge it. Then, place your robot within 20 cm (7.9 in.) in front of the Mobile Base, press the Dock button on the Mobile Base for 2s. Wait for the robot to dock with the base.

7



- ① After your robot is docked to the Mobile Base, please follow the on-screen prompts to create a map.
- ② Tap to add Waypoints. Tap to select a waypoint on the map, and then hit to initiate a transport task.

8



With the included Velcro tapes, you can customize and mobilize your everyday items using our Mobile Base. To purchase compatible SwitchBot devices, please visit our official website at [www.switch-bot.com](http://www.switch-bot.com).