

cüraa

Kitchen Scale

O W N E R ' S G U I D E




by YFL home

THANK YOU FOR PURCHASING

Kitchen Scale



REGISTER YOUR PURCHASE

-  yflhome.com
-  +91 7948223620
-  Scan QR code using mobile device

RECORD THIS INFORMATION

Serial Number: _____

Date of Purchase: _____
(Keep receipt)

Online Site: _____

TECHNICAL SPECIFICATIONS

Capacity : 5 Kilograms
Accuracy/Graduation: 1 gram
Units of Measurement: g / lb / oz / ml
Display: LCD
Power Source: 2 x AAA batteries
Model no - MT600
L/M Certificate No - IND/09/25/208

**PLEASE READ CAREFULLY AND
KEEP FOR FUTURE REFERENCE.**

CONTENTS

Important Safeguards	4
Instructions for the user.	4
Maintenance & Warnings	4
Getting to Know Your Kitchen Scale	5
Features & Specifications.....	5
Parts.....	5
Button Description.....	5
How to Operate Your Kitchen Scale.	6
How to Use	6
Battery Installation & Replacement.....	6
Operating Instruction.	7
Tare Function	7
Troubleshooting Guide	8
Product Registration	9
Warranty.	10

IMPORTANT SAFEGUARDS

HOUSEHOLD USE ONLY • READ ALL INSTRUCTIONS BEFORE USE

Read the instructions before using kitchen scale and keep them for future reference.

- 1 This scale is for household use. **NOT FOR COMMERCIAL USAGE.**
- 2 Make sure your scale is placed on a non-vibrating, flat and on a stable horizontal surface.
- 3 Avoid weighing on top of books, cloth, etc., that might cause error indication.
- 4 Gently place all items to be weighed. Do not drop items onto weighing platform.
- 5 Place the item to be measured at the center of the scale on a flat, stable surface for accurate results.

INSTRUCTION FOR THE USER

This product is a sensitive electronic instrument and it may be affected by radio transmission devices being used in close proximity (such as mobile phones, radio, electronic controllers and some wireless devices).

If the appliance exhibits symptoms such as errors or inaccurate data, try moving the product away from the source of interference or switching off that source of interference before using the product.

MAINTENANCE & WARNING!

- 1 Handle with care as it is a precision instrument i.e. never expose it to extreme temperatures, shock, moisture, dust and direct sunlight. Do not drop or knock the scale.
- 2 Keep your scale away from the source of heat.
- 3 Clean your scale with a damp cloth after use; do not use solvents or chemicals.
- 4 Do not overload the scale.
- 5 **Once the scale detects the exceed of weight or tampering, the guarantee becomes invalid.**
- 6 **If the display does not function, please contact Cüraa by YFL home customer care (mentioned on pg 10).**
- 7 Do not store or use the scale in a damp room with humidity over 90%. Use in good air circulation environment. Always avoid high moisture & sunlight or strong electromagnetic field to perform the precision of the scale.

GETTING TO KNOW YOUR KITCHEN SCALE

FEATURES & SPECIFICATIONS

Equipped with high precision strain gauge sensors	Max. Weight Capacity: 5kg/1g
Large LCD display with backlight (Size 60 x 21 mm)	Press on/off & tare function
Tare weight function - applicable	Auto shut-off in 2 mins
Over-load indication "oL"	Product size - 19x14x53.5 cm
2*AAA batteries	Net weight- 234 gms

PARTS


A Unit Selection Button

B LCD Display

C Power/Tare Button

D Battery Compartment

E Anti-Skid Pads



BUTTON DESCRIPTION



On/off button – controls the on/off status of the device. Also functions as the electronic scale tare button.




Unit switch button – the kitchen will cycle through Different measuring units with a press of unit button. (g / lb / oz / mL)

SAVE THESE INSTRUCTIONS

HOW TO OPERATE YOUR KITCHEN SCALE


HOW TO USE


- 1 Place the electronic scale in a horizontal position and press .
- 2 Keep the electronic scale stable and weigh until the LCD displays "0/0.0g".
- 3 Then you can start weighing.




Example steps (with LCD illustrations):

- 1 Put the empty container on the scale. The LCD shows the container weight.




- 2 Press  to zero. At this point, the screen will display a zero, indicating that the tare is complete.




- 3 Pour the water into the container. The LCD will display the weight of the water.
- 4 Press  to switch units to "mL".
You can get the water volume.

Other Display Instructions:



- 1 The display of "oL" indicates that the weight of the object you placed has exceeded the maximum capacity of this electronic scale.






- 2 The display of "Lo" indicates that the device has low battery power. Please replace the batteries.

BATTERY INSTALLATION & REPLACEMENT

The scale operates with 2 X AAA batteries.

- 1 Insert the batteries in compartment located at the bottom of the scale.
- 2 Insert 2 x AAA batteries.
- 3 When the batteries are discharged, the display will show you "LO". Remove the batteries and replace it with the new set for a continuous usage.

OPERATING INSTRUCTIONS

- 1 Place the scale on a flat surface.
- 2 To switch on: press  key.
- 3 To switch off: press  for 2 - 3 seconds.
- 4 If the desired unit (g/ml/lb/oz) key after the LCD is resumed to zero is not displayed, → please press  key.
- 5 Now place item onto weighing platform.
- 6 Wait till it is displayed.


If you wish to use a container on the scale you can either place it on the scale before the scale is turned on, or after the scale has been turned on and is showing 0g

→ press  key

→ scale will show zero and prepare for weighing the net weight.

Ensure the scale is on your eye level to read. Please be aware that the position of the container will affect the total capacity of the scale. Whenever if the load exceeds 5100g, then the capacity for weighing will be reduced to 5000 grams (See "Overload" notes below).

Overload: When the weight is more than 5000g, it can measure inaccurately. When the weight is more than 5100g, it exceeds the max weight range (LCD will display overloading error).



TARE FUNCTION

The Tare function will help you to reset the scale to zero at any time and to weigh different item/ingredient containers independently.

- 1 Press the  button, located on the front panel. The display will show 0.0.
- 2 Place the ingredient/container on the platform.
- 3 Press the  button again to reset the scale to zero before adding the next ingredient.
- 4 Repeat this process for each subsequent ingredient.

TROUBLESHOOTING GUIDE

PROBLEMS	POSSIBLE CAUSE	SOLUTIONS
Scale does not turn ON	Dead or incorrectly placed batteries	Check battery polarity and replace with new AAA batteries
	Faulty battery contacts	Clean battery contacts and reinsert
	Internal fault	Contact customer service
"Lo" is displayed	Low battery voltage	Replace with two new AAA batteries
"oL" is displayed	Item exceeds max capacity (overload)	Remove item immediately to avoid damage
Inaccurate weight readings	Scale not on a flat/stable surface	Place scale on a hard, level surface
	Interference from nearby electronics	Move scale away from mobile phones, Wi-Fi routers, etc.
	Scale not tared properly	Press TARE before weighing items
	Drafts, vibrations, or air movement	Use in a stable, wind-free environment
Display is blank	Batteries are drained or missing	Insert or replace batteries
	LCD fault or internal issue	Try resetting scale / Contact service
Scale shuts off unexpectedly	Auto shut-off feature triggered (after 2 mins inactivity)	Re-press ON button to continue weighing
	Loose battery connection	Reinsert batteries securely
Units not switching	UNIT button not functioning properly	Press and hold the UNIT button, try replacing batteries
TARE not functioning	TARE not pressed correctly	Ensure proper pressing of TARE/ON/OFF button
	Overloaded container	Remove heavy container, press TARE again

PRODUCT REGISTRATION

Please log onto yflhome.com and complete the online warranty form with your personal and product details within 14 days.

The registration will enable us to contact you in the unlikely event of a product safety notification. By registering, you acknowledge you have read and understood the instructions for use and warnings set forth in the accompanying instructions.

ONE (1) YEAR LIMITED WARRANTY

Dear Customer,

Thank you for choosing a **Cüraa** consumer product.

All Cüraa products are designed and manufactured to the highest standards to deliver high quality performance, as well as easy installation and use. At Cüraa, we believe in providing not only service, but adding value to your kitchen. The warranty has therefore been designed especially for you with your interest at heart.

Warranty Service

This Cüraa by YFL home consumer product is covered against manufacturing defects from the date of purchase. The warranty is not transferable from one user/customer to another.

What is covered by this warranty?

1. The original unit and/or non-wearable parts deemed defective, in Cüraa by YFL home's sole discretion, will be repaired or replaced up to one (1) year from the original purchase date. In case of repairs or replacement of any part(s) of the product, this warranty will thereafter continue and remain in force only for the unexpired period of the warranty.

What is not covered by this warranty?

1. Normal wear and tear of wearable parts (such as blending vessels, lids, blades, blender bases, etc.), which require regular maintenance and/or replacement to ensure the proper functioning of your unit, are not covered by this warranty. Replacement parts are available for purchase at yflhome.com.
2. Any unit that has been tampered with or used for commercial purposes.
3. Damage caused by misuse, abuse, negligent handling, failure to perform required maintenance (e.g., Dropping the scale or applying sudden force can misalign causing breakage of internal components.), or damage due to mishandling in transit.
4. Consequential and incidental damages.
5. Defects caused by repair persons not authorized by Cüraa by YFL home. These defects include damages caused in the process of shipping, altering, or repairing the Cüraa by YFL home product or any of its parts when the repair is performed by a repair person not authorized by Cüraa by YFL home.
6. Products purchased, used, or operated outside India.

How to get service

If your appliance fails to operate properly while in use under normal household conditions within the warranty period, visit **yflhome.com** for product care and maintenance self-help.

Our Customer Service Specialists are also available at

Email: support@yflhome.com

Phone: +917948223620

to assist with product support and warranty service options.

To make a warranty claim, you must provide proof of purchase.

For recipes follow this QR



@yflhome

Sevenchef Consumers Home & Kitchen Private Ltd.
+917948223620
www.yflhome.com

Illustrations may differ from actual product. We are constantly striving to improve our products; therefore the specifications contained herein are subject to change without notice