英文

-TWS Stereo Headset

Product Manual

Packing list:

Product description:



Charging case description:

Wearing schematic:

Start using:

1. Open the charging case and take out the earphones.
2. Put the charging contact (insulation film off) left and right earphones.
3. After charging for 10 minutes in the charging case, take out the left and right earphones at the same time; All in the two earphones are out of the case, they will be automatically turned on, and the left and right earphones will be automatically paired. Enter pairing mode after successful pairing the voice prompts "Power on";
4. Wear the headset, the left ear is the main, the right ear is the auxiliary;
5. Select " " from the phone or other device with BT list and connect. After the connection is successful, the voice prompts "Connected". You can now use voice or audio on your phone or other devices.
6. Uncovered voice prompt "Disconnected".
7. Press touch button area of the left earphone/ right earphone for 4 seconds, speech cue "Power off ;

Remarks:

1. After disconnecting from the device(20 meters),the earphones is disconnected from the device;
2. The earphones will shut down automatically without any device connection within 5 minutes;
3. The earphones can automatically reconnect the last connection device after turning off the earphones.

Two ear / one ear switch:

1. After the headset is connected to the device, the signal is received in dual transmission mode, and the two headsets are independent of the main and the auxiliary;
2. In the process of pairing two earphones, you can turn off any earphone without cutting off the use status of the other earphone.
3.When any headset is turned on, it will automatically connect back to the previously connected device

Pairing mode:

Button operation:

R 1	Click	play / pause answer / hang up
R 2		
R 3	Long press for 2 seconds	Call status: rejected Power off status: turn on
R 4	Long press for 4 seconds	
R 5		
R 6		
R	Double click last	L Double click: previous

Charging and lighting mode of charging box:

The lighting mode of the charge box is as follows:

Tastenbedienung:

R 1	Klicken	Abspielen /Anhalten Ausrichten /Aufhängen
R 2		
R 3	2 Sekunden gedrückt halten	Ihr anruf/status ablehnen Ausschalten Einschalten
R 4	4 Sekunden gedrückt halten	
R 5		
R 6		
R	Doppelklick: nächstes Lied	L Doppelklick: letztes Lied

Indicator light status:

Power-on self-checking	Blue light flashes, 5 minutes after pairing (manual automatically shutdown)
Pairing and successful connection mode	The indicator light flash alternately (when the pairing is successful, another blue light flashes three times after the pairing is completed)
Red light	
Power off	Off red light flashes three times and then goes out
Standby connected	No flash
Cancel entire phone	No flash
Listen to the music	No flash
Charging completed	Red light LED goes out in 2 to 3 minutes
When charging	Red LED lights green light
Low voltage alarm (3.4V)	0.25 seconds, alarm sound, red indicator, prompt sound "please charge!" (prompt in headset)" indicator light flashes once in five seconds

Matters needing attention:

1. In order to ensure a smooth connection, it is recommended that the distance between the phone and the earphone is within 20 meters(barrier-free).
2. The mobile phone cannot search for the wireless device, and all the paired data stored in the mobile phone is cleared, and the device is searched again.

5. Charging error or unable to charge, check whether the charging cable is connected correctly or whether the earphone is loaded or charge it.
6. This product uses a built-in non-removable battery, do not try to remove the battery from the earphone, so as not to damage the earphone.
7. When not using earphone and charging bins for a long time, please place them in a dry and ventilated place and charge them once a month.

Safety Instructions:

1. Please don't use the earphone in a thunderstorm, which may cause the earphones to work abnormally and increase the risk of electric shock.
2. When the earphone is in use, the volume should be gradually increased from small to large, and select the appropriate volume to avoid permanent damage to the ears.
3. Keep the earphones and packing box out of the reach of the children to avoid accidents.
4. The earphones are not suitable for operation in high temperature or humid environments.
5. Please don't use any carcinogenic or abrasive cleaning agent to clean the earphones.
6. To reduce the pollution to the earth, please recycle it to a professional agent when you dispose of it.
7. The battery is flammable and explosive. Please don't disassemble it arbitrarily and throw it into the fire. There will be a risk of explosion.
8. Please don't dismantle the earphones.

Maintenance Service Card

Client name	
Contact Number	
Product name	
Product Style	
Dealer	
Contact Number	

Dear users, this warranty card is the certificate of the product three guarantees. Please cooperate with dealer to fill in it and keep it properly, thank you.

-TWS Stereo-Kopfhörer

Bedienungsanleitung

Packliste:

Produktübersicht:

Beginnen Verwendung:

1. Öffnen Sie die Ladekiste und entfernen Sie die beiden Kopfhörer.
2. Setzen Sie die Ladekontakte (Isolierfilm abgezogen) des linken und rechten Kopfhörers ein.
3. Nehmen Sie die Ohrhörer und den rechten Kopfhörer gleichzeitig ab, sobald sie den Ladekiste (mit Mission ring abgelegt haben, Beide Kopfhörer werden automatisch eingeschaltet. Nachdem das linke und das rechte Ohr automatisch gekoppelt wurden, hören Sie Stimme über "Power on" auf.
4. Schalten Sie das BT Ihres Telefons oder eines anderen Geräts ein und lassen Sie es weiter suchen.
5. Wählen Sie "Kopfhörer" aus der Bluetooth-Liste Ihres Telefons oder eines anderen Geräts " " und stellen Sie eine Verbindung her. Nachdem die Verbindung hergestellt wurde, wird die Sprachansage "Connected" auf dem Mobil / oder einem anderen Gerät können Sie die Funktionen und Inhalte verwenden.
6. Beenden sie die verbindung auf der mobile "Disconnected".
7. Halten Sie die Berührungsfläche des linken/rechten Kopfhörers 4 Sekunden lang gedrückt, und die Sprachansage "Power off ;wird angezeigt.

Bemerkungen:

1. Das Kopfhörer und das Gerät befinden sich außerhalb der Entfernungserkennung (20 Meter) und werden getrennt. Wenn Sie zum Bereich zurückkehren, wird automatisch eine Verbindung hergestellt.
2. Wenn Innerhalb von 5 Minuten kein Gerät angeschlossen wird, wird es automatisch herunergefahren.
3. Im verbundenen Zustand ist das Kopfhörer ausgeschaltet und kann diese automatisch mit dem zuletzt verbundenen Gerät verbunden werden.

Tastenbedienung:

R 1	Klicken	Abspielen /Anhalten Auferstehen /Aufhängen
R 2		
R 3	2 Sekunden gedrückt halten	Ihr anruf/status ablehnen Ausschalten Einschalten
R 4	4 Sekunden gedrückt halten	
R 5		
R 6		
R	Doppelklick: nächstes Lied	L Doppelklick: letztes Lied

Status der Anzeige:

Einschalten Pairing Status	Blau blinkt 5 Minuten nach einem Einschalten gekoppelt (Wenn die Gekoppelt oder erfolgreich, wird eine zusätzliche blau aufgeblitzt)
Pairing (Modus wurde nach erfolgreichem Chen	Die blau und blauen Lichter flimmern abwechselt (wenn die Paarung erfolgreich ist, wird eine blaue Lichtblitzen hinzugefügt, wird dann Paarung fortgesetzt)
Einschalten	
Farbige Kapseln	Blau langsam, 1 Mal, 3 mal, blinkt und erlischt dann
Standby ist verbunden	Blaues Licht
Beim senden	Blaues Licht
Beim hören	Blaues Licht
Aufladen ist beendet	Rotes LED ist aus 1-2 Tage
Aufladen	Rotes LED ist Dauerlicht
Niedrig-Spannungs-Alarm (3.4V)	0.25 Uhren, Alarmsound, rotes Licht, Prompt Ton "Bitte laden, wenn die Ladung unzureichend!" (Ansage ist im Kopfhörer) (Jede 5 Sekunden

Sicherheitshinweise:

1. Nicht bei Gewitter verwenden. Dieses kann zu abnormalen Arbeiten führen und das Risiko eines Stromschlags erhöhen.
2. Erhöhen Sie die Lautstärke allmählich von klein nach groß, und wählen Sie die entsprechende Lautstärke aus, um Hörschäden zu vermeiden.
3. Bewahren Sie Kopfhörer und Verpackungskosten außerhalb der Reichweite von Kindern auf, um Unfälle zu vermeiden.
4. Kopfhörer eignen sich nicht für Umgebungen mit hohen Temperaturen oder hoher Luftfeuchtigkeit.
5. Verwenden Sie keine Reiniger oder schwarzmacher Reinigungsmittel.
6. Um die Umweltverschmutzung zu verringern, wird die Erde nach ihrer Entsorgung von professioneller Institution recycelt.
7. Die Batterie ist entflammbar und explosionsgefährlich. Nehmen Sie sie nicht willkürlich auseinander und werfen Sie sie nicht ins Feuer. Es besteht Explosionsgefahr.
8. Zerlegen Sie die Kopfhörer nicht selbst.

闪电PDF编辑器
https://www.callmysoft.com/

Instructions for use