



02 User Manual for NoiseFit Mettle

WRIST AWAKE

your preference.

12 User Manual for NoiseFit Mettle


off as per your preference.

BRIGHT SCREEN TIME

POWER ON



• Press and hold the side button for a few seconds to turn on the watch.



03 User Manual for NoiseFit Mettle

WATCH NAVIGATION

BUTTON NAVIGATION

The NoiseFit Mettle smartwatch has a TFT colour touch screen.


up and down and pressing the side button.

· Press the side button to exit a feature.

• Press the side button to turn on the watch display.

Navigate the watch by tapping on the screen, swiping side to side,





• Open the NoiseFit app and allow the BT and GPS positioning to be turned on. • Feed-in your personal information and health goals in the app. • Go to 'Device' page and select 'add device' in the app, select the watch name and MAC address and link the watch. You can also scan the QR code on the NoiseFit Mettle from the NoiseFit app.

On iOS: Choose Bluetooth pairing when you receive a pairing prompt.

In case the Bluetooth calling connectivity has not been On Android: Connect it directly. established earlier, you'll have to do the steps manually. Go to Settings. SeMettleh for device and pair your smartphone to attend

> BT CALL CONNECTIVITY REMOVAL In Android devices, to remove the Bluetooth connection you can unpair from the app and the phone Bluetooth settings. • Go to the phone's Bluetooth settings and forget NoiseFit Mettle_Phone.

from the app and the phone Bluetooth settings. · Go to the phone's Bluetooth settings and forget NoiseFit Mettle and NoiseFit Mettle Calling.

In iOS devices, to remove the Bluetooth connection, you can unpair

To establish Bluetooth calling connectivity, follow these steps.

your phone's Bluetooth to use the calling feature conveniently.

After pairing the watch with the NoiseFit app, the watch's

calling Bluetooth would be activated. Now connect it with

your blood oxygen level in real-time, go to the 'SpO2' Note: Make sure your arms and wrists are still and there is no space between your watch and the wris-

NOISE HEALTH

ACTIVITY

HEART RATE

07 User Manual for NoiseFit Mettle

Noise Health Suite has a collection of

active time and steps taken.

wellness features that takes a holistic route.

You can check your daily activity progress in

terms of the calories burned, distance covered,

NoiseFit Mettle supports 24/7 heart rate tracking.

'Heart Rate' monitor and tap on 'Tap to Measure.'

Note: Make sure your arms and wrists are still and

there is no space between your watch and the wrist.

NoiseFit Mettle supports the viewing of the highest

and lowest blood oxygen level of the day. To measure

You can select the measurement frequency in the app

settings. To measure your heart rate in real-time, go to

You can view the all-day data on the watch and app.

() noise

SLEEP

You can view your most recent sleep record and sleep quality in various sleep stages in the NoiseFit app. The feature will measure the device records of the user's sleep cycle, sleep states (light and deep sleep), wake time and REM.

STRESS

User Manual for NoiseFit Mettle

NoiseFit Mettle supports 24-hour stress level measurement and viewing of all-day measurement data. To measure the stress levels in real-time, go to the 'Stress' feature and wait for it to measure. Note: Make sure your arms and wrists are still and there is no space between your watch and the wrist.



You can use this feature to manage calls from the watch.

NOISE BUZZ

via Bluetooth. Go to Noise Buzz. Choose to dial from the dial pad or the contact list and make calls. Note: If the watch is connected to your smartphone via active call, touch the call switching icon on the watch to switch from the watch to phone and attend the call from

with the watch. You can add, delete, and enable/disable alarms. You can also label alarms to identify them. TIMER

You can set a timer with a pre-set duration on the watch

and the timer will remind you when the time is up. STOPWATCH

A stopwatch can be set on the watch. You can also set lap times on the stopwatch.

WORLD CLOCK

09 User Manual for NoiseFit Mettle

You can see the time of any city in the world on the watch. Open the NoiseFit app. Add the city and see its time.

You can set alarms in the NoiseEit app and they will sync

You can control your favourite songs and podcasts that play from your phone, right on your wrist as long as the You can play/pause music, go to the next/previous track and increase/decrease the volume.

You can choose from 10 workout modes. You can

e your pick and add more workouts from the a

out. You can also view the exercise records in the app

This feature also lets you control music while working

You can check the progress report of your workouts in

You can add or edit reminders on the app.

10 User Manual for NoiseFit Mettle

WORKOUTS

SPORT RECORD

this feature.

REMINDERS

NoiseFit Mettle supports 5-day weather viewing in a location of your choice as long it is synced with the NoiseFit op. You can view today's current weather and for the next 4 days as well. Open the Weather app on your watch and cha ne location to see the weather of your current location.

FLASHLIGHT CALCULATOR

WATCH FACES

Changing The Watch Face

app or the watch.

from the watch faces.

On The Watch

In The App

11 User Manual for NoiseFit Mettle

You can use this feature to do basic calculations. Go to Calculator and feed in digits and start calculating.

SETTINGS

BRIGHTNESS in the watch, choose and download cloud-based or animated watch faces. You can also create you You can set the watch's brightness. own watch faces in the NoiseFit app. RINGTONE VIBRATION

Give your screen a personalised style by changing You can set the vibration level to get an alert of or customising the watch face from the NoiseFit any notification. You can also choose to put the

o to watch faces, select the watch face of your

choice and tap 'save' to change the watch face.

You can use this feature to turn on the screen So to the Flashlight, Tap to turn on.

Touch and hold the home screen. Swipe and choose

You can switch between different watch faces

You can set the DND duration on the watch. Feed in the start and end time and set. MENU VIEW

Turn on the wrist awake and set the auto screen

You can set the bright screen time duration as per

You can set the Main menu as per your preference.

AUTO SPORTS DETECTION You can turn on the auto sport detection and let

DEVICE INFORMATION

Scan the QR code to connect with the app.

POWER OFF

reset, all your data and settings will be erased.

Follow the onscreen instructions to set or remove

here, including the device name. Bluetooth name and

You can choose to reboot to restart the watch.

You can choose to reset. Do note if you choose to

ABOUT CALLS

You can choose to power off to restart the watch.

13 User Manual for NoiseFit Mettle

the Bluetooth call connectivity.

You will find all the information related to the device

QR CODE

SETTINGS

SILENT MODE

QUICK SETTINGS

14 User Manual for NoiseFit Mettle

04 User Manual for NoiseFit Mettle

BRIGHTNESS FIND PHONE

You can swipe from the watch's home screen

Before pairing, make sure that your smartphone

DND POWER SAVING MODE

 Utility/productivity features (Stopwatch) alarm, timer, reminder, DND, weather, You can find the watch's current amera/music controls, world clock,

15 User Manual for NoiseFit Mettle

05 User Manual for NoiseFit Mettle

DEVICE INFORMATION AND TIPS

The NoiseFit Mettle smartwatch

• 1.4" TFT display (240*240 px)

• 100+ customisable watch faces

300mAh battery (up to 7 days of use, 2

contains the following:

PAIR THE WATCH

calculator) • 4 colour options - Elite Black, Elite Blue,

Follow these simple steps to save NoiseFit Mettle battery. • Minimise the screen brightness

· Limit the notification you receive from the NoiseFit app.

select 'My Objectives.' Change your How do I log my weight?

You can do it through the NoiseFit app.

Go to 'My Profile.' Go to 'Setup' and

You can log in your weight the first

time you set up your NoiseFit app.

06 User Manual for NoiseFit Mettle

BT CALL CONNECTIVITY

Manual Connection

your calls from the watch.

days with calling & 25 days on standby) How do I find my watch's current firmware version?

firmware on the watch. Go to Settings on the NoiseFit app. Select Device and e-mail ID as well.

16 User Manual for NoiseFit Mettle

DISPOSAL AND RECYCLING How does the watch estimate how INFORMATION Electrical and electronic devices may NoiseFit Mettle estimates how

the NoiseFit app. Activity data includes your steps, distance, calories, active many calories you've burned based on the physical data you entered minutes, heart rate, sleep duration and when you set up your account. How do I change my activity goals?

the watch to the app daily. Bluetooth calling (built-in microphone & speakers, recent calls, dial pad, contacts) TIPS

How do I update my NoiseFit Mettle? • Health tracking with NoiseFit app (Activity You can update your NoiseFit Mettle via tracking, SpO2, sleep tracker, 24*7 Heart the NoiseFit app. Go to 'My Profile' and

Rate Monitor, Stress measurement) select 'Check for updates.'

The NoiseFit Mettle smartwatch stores

our activity data for up to 4 days in

However, you can update the weight later via the NoiseFit app. Go to My change or update your weight. You can update your birthday, height, country

information, choose Check for updates and update if any update is available. How do I save battery?

accept any interference received. undesired operation.Warning: Change or modifications not expressly approved by the party responsible for compliance could void the authority to operate the

for a Class B digital device, pursuant not be disposed of with domestic was reasonable protection against harmful

Consumers are obliged by law to retur he end of their service lives to the public collecting points set up for this ourpose or point of sale. Details of thi are defined by the national law of the materials or other forms of utilising old devices, you are making an important

contribution to protecting our environment. REGULATORY INFORMATION USA: Federal Communications

television reception, which can be determined by turning the equipment This device complies with Part 15 of the off and on, the Max is encouraged to CC rules. Operation is subject to the try to correct the interference by one or more of the following measures: This device may cause harmful Reorient or relocate the receiving

• Increase the senaration between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an

his equipment generates, uses and

accordance with the instructions may

can radiate radio frequency energy

cause harmful interference to radio

communications. However, there is n

guarantee that interference will not

If this 76 equipment does cause

and, if not installed and used in

intended for use by small childre or pets. Unless otherwise not medical devices and are not

components that could be a

prevent any disease. We develop

to be equivalent to medical devices

In some cases, prolonged use of

products may cause skin irritati

to skin irritation or allergies. To

keep the watch and watch band

tight and give your wrist a rest by

or wrists while or after wearing the

soreness, tingling, numbness

discontinue use.

extended period of wear If you feel

accurately as possible. The

strap and your wrist. • Do not use household cleaners to clean the device. Use soap-free cleaners instead. · For stains that are difficult to remove, it is

 The device is not suitable for diving. swimming in the sea or sauna; it is suitable

• Keep it away from direct sunlight, high damage the band over time.

it may be fixed by restarting your watch. For

If you experience any problem with the



























and can cause skin irritation. • Do not wear the device too tight but mak sure that the bottom sensor is lightly in contact with your skin and there is a gap of bout one finger's width between the wrist

and dirt can build up underneath the band

swimming pools, showers (cold water) and swimming in shallows.

CUSTOMER SUPPORT

User Manual for NoiseFit Mettle

assistance, please reach out to us at link: https://support.gonoise.com/support/home

