
MERKURY SMART



SMART WI-FI CAMERA

Scan code for the latest manual online



Thank you for purchasing your MERKURY smart home product.

Get started using your new devices by downloading the Merkury Smart App, one convenient app that manages everything straight from your phone or tablet. Easily connect to your home Wi-Fi, and control multiple devices from the touch of your fingertips.

Contents

Start Guide			
Download & Register	0		
Prepare	0		
Connect (Auto Discovery)	03		
Questions, Troubleshooting, Notices			
■ Voice Control Guide			
Google Assistant	09		
Amazon Alexa	11		

FCC Notice:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

Important Information:

Read and follow all precautions, including the following: CAUTION: RISK

OF ELECTRIC SHOCK OR BURNS - USE IN A DRY LOCATION ONLY. The
weather resistant IP44 rating only protects the LED bulb from splashes in any
direction. DO NOT IMMERSE IN WATER.

WARNING: The LED bulb must be unplugged when making any modifications to the device. Electrical currents are dangerous and may cause electrical shock, injury, or death (in some cases)

Support:

If you encounter any issues, please contact us at support.merkurysmart.com for help. To explore our full selection of products, visit us at:

www.merkurysmart.com

© 2023 Merkury Innovations • 45 Broadway 3rd FL, New York NY 10006. The illustrated product and specifications may differ slightly from those supplied. iPhone, Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. Google, Google Play, and related marks and logos are trademarks of Google LLC. iOS is a registered trademark of Cisco in the U.S. and other countries and is used under license. Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates. All other trademarks and trade names are those of their respective owners.

Made in China

START GUIDE

What's in the Box



 4x Smart Wi-Fi LED Bulbs



User Manual

Get Ready



 Know your Wi-Fi network and password



2.4GHz

 Make sure you're connecting to a 2.4GHz Wi-Fi network (This device can't connect to 5GHz networks)



E26

 Find an existing light socket (E26 shape)





iOS 13 Android 10

 Make sure your mobile device is running iOS® 13 or higher or Android™ 10 or higher

STEP 1

 Download the Merkury Smart App from App Store or Google Play.











Register an account on your App.

01.

Enter your email address.

02.

Enter the verification code and create a password.

03.

Log in to the App.




STEP 2

Screw In

Screw in the bulb and turn on the power. The bulb should be flashing.

*see reset instructions on p. 7



STEP 3

Set Up:

Auto Discover Device

Your device is now able to be discovered magically to connect to your home Wi-Fi network. It's quicker and easier than ever to connect





Device is Flashing



Connect to 2.4GHz Wi-Fi




Add device:



02.
While the device is flashing, tap "Auto-Discovery" on the Add Device screen of the Merkury Smart app.

03.

The Merkury Smart app will automatically detect your Smart Bulbs using its wireless Bluetooth connection.



04.

The Merkury Smart app will automatically detect the network that your smartphone is connected to. Enter the password to your Wi-Fi network, then tap "Next Step" and the device will connect.

05.

The Merkury Smart app will try to connect your device.

NOTE: This device can't

"If you are unable to pair initially, reset your device and try pairing using the alternative method provided in the app.

Confirm WiFi credentials Make sure the following Wi-Fi network information is still correct and then press confinue. Wifi Network Home, 2.4 Password Show Help me Continue

Pairing Device



06.

The Merkury Smart app will attempt to connect. This may take a few moments.



Frequently Asked Questions

■ How do I customize my dashboard?

Select the "Edit" option on the top of "Home" page. Create additional pages on your dashboard by dragging tiles to the right and organize devices to fit how you use them.

■ How Many Devices Can I Control?

Merkury Smart app can control an unlimited amount of devices in an unlimited amount of locations. Your router may have a limit of how many devices can be connected to one router.

■ How do I rename my device?

From your main device list, click on the device you want to rename, then click "Device Settings", then click on "Device Name". Rename your device to a more familiar name like "Bedroom" or "Living Room" and then click Save.

The device appears offline or unreachable, what should I do? Make sure your Wi-Fi router is online and in range. Make sure your device is plugged in and paired. You may also try restarting the device or if needed, re-pairing it.

What's the Wireless Range?

The range of your home Wi-Fi is heavily dependent on your home router and the conditions of the room. Check with your router specifications for exact range data.

If my Wi-Fi/Internet goes down, will Merkury Smart still work?

Merkury products need to be connected to Wi-Fi in order to control them remotely.

Troubleshooting

Cannot connect to your Wi-Fi network.

Make sure you entered the correct Wi-Fi password during the Wi-Fi setup. Check whether there are any Internet connection problems. If the Wi-Fi signal is too weak, reset your Wi-Fi router and try again.

Reset the device

Reset the LED bulb by switching the bulb off then on, 3 times.
 The LED bulb will flash and your device will be in pairing mode again.

System Requirements

- Mobile device running iOS® 13 or higher or Android™ 10 or higher
- Existing Wi-Fi Network

Technical Specifications

- E26 base
- 120 V. 60 Hz
- Wi-Fi: IEEE 802.11n, 2.4GHz (not compatible with 5GHz Wi-Fi networks)

VOICE CONTROL GUIDE

Thank you for purchasing your MERKURY smart home product. Make sure your devices are already set up using the Merkury Smart app, then follow these steps.

Name and Control Each Device by Voice





Contents

Amazon Alexa

Voice	Control	Guide

Google Assistant	 09

11



To control your Merkury smart bulbs, plugs or surge protectors, just say "OK Google," or "Hey Google," and ask. Make sure your devices are already set up using the Merkury Smart app.

Things you can say*:

"Hey Google, turn on all the lights in my bedroom."

"Hey Google, set the bedroom light to orange."

"Hey Google, set the living room to 50%."

"Hey Google, dim porch light."



*Some commands require compatible devices.

01

 Open the Google Home app and go to Home Control in the menu. Face Match

Teach your Assistant to recognise your face

- Home Control

 Manage the devices in your home
- My Day
 Customise your summary
- Email updates
 Latest news & features


02

■ Tap the "+" button.



03

 Choose "Merkury Smart" from the list of Home Control partners.



04

 Authorize your account with Google Assistant using the username and password from your Merkury Smart app.

> Now your Google Home app and Merkury devices are linked!

You're now able to say "Hey Google" and control your Merkury devices.



 At any time, go into the "Home Control" section of the Google Home app to set nicknames and rooms for your devices. You can rename your devices in the Merkury Smart app, and Google Assistant will refer to them by the same name.

So if you rename a smart bulb to "Living Room" or a nickname like "Blossom," then Google Assistant will use that same name later on. You can always give it a nickname using the Google Home app as well. You can also assign bulbs to a specific room, like "Bedroom" or "Kitchen."

Google Assistant will be able to control devices by room.



To control your Merkury smart bulbs, plugs or surge protectors, just ask Alexa. Make sure your devices are already set up using the Geeni app.

Things you can say*:

"Alexa, discover my devices."

"Alexa, turn on the bedroom light."

"Alexa, set the bedroom light to orange."

"Alexa, set the living room to 50%."

"Alexa, dim porch light."



*Some commands require compatible devices.

01

 Open the Alexa app and go to Skills in the menu.



02

 Search for Merkury Smart then tap Enable.







03

 Authorize your account with Smart Home Skills using the username and password from your Geeni app.

04

 Choose "Discover Devices." After a few seconds your Merkury devices will be displayed under Smart Home in the Alexa app.



Discover Devices Smart Home devices must be discovered before they can be used with Alexa. CANCEL DISCOVER DEVIC

 You can rename your devices in the Merkury Smart app, and Alexa will refer to them by the same name.

So if you rename a smart strip to "Living Room" or a nickname like "Blossom," then Alexa will use that same name later on.

Alternatively, you can create an Alexa group, like "Bedroom" or "Downstairs," and add the device to the group.

Alexa will recognize the group name in the Alexa app, or the device name in the Merkury Smart app.

Can't connect? Need help?

WE CAN HELP

DO NOT
RETURN THIS
PRODUCT TO
THE STORE

support.merkurysmart.com or tap 'support' for help in the Merkury Smart app.