



**ATOMIC DIGITAL CLOCK**

**FRONT VIEW**



**Calendar + Indoor Temperature**


**BACK VIEW**



**Battery Compartment  
3 "AA"**

**TIME ZONE SELECTOR**

**BUTTONS**



## GET STARTED

**Step 1:** Use the time zone selector (on back) to choose your time zone.

**Step 2:** Insert 3 *new* AA batteries (not included) into the clock. Observe the correct polarity.


**Restart:** If there is no indoor temperature data after 60 seconds, remove batteries from the clock and press a button 20 times. After 15 minutes, return to **Step 1** above.

## SET TIME, DATE AND TEMPERATURE

1. Hold the **SET** button to enter time set mode.
2. Press the **WAVE/+** or **DST/-** buttons to adjust values.
3. Press the **SET** button to confirm and move to the next item.

### TIME SET ORDER:

1. 12/24 hour time format
2. Hour
3. Minutes
4. Year
5. Month
6. Date



Press the **SET** button to exit, or wait 20 seconds without pressing buttons to return to the normal time display.

## DAYLIGHT SAVING TIME SETTING

- Hold the **DST** button for 3 seconds to select DST on or off.
- The DST icon **DST** appears in above the seconds when DST is on.



## TIME ZONE SELECTION

Slide the time zone selector bar on the back of the clock to choose the time zone for your area.

TIME ZONES	
PST	Pacific
MST	Mountain
CST	Central
EST	Eastern

## FAHRENHEIT/CELSIUS

Hold the °C/°F button for 3 seconds to select Fahrenheit or Celsius temperature readings.



## SET TIME ALARM

Press the **SET** button once to enter Alarm Mode. The letters **AL** will show in the seconds display.

1. Hold the **SET** button for 3 seconds to enter alarm time set mode.
2. Press the **WAVE/+** or **DST/-** buttons to adjust values.
3. Press the **SET** button to confirm and move to the next item.



**Alarm Time setting order:** 1. Hours, 2. Minutes

## ACTIVATE/DEACTIVATE TIME ALARM

- Press the **SET** button once to view alarm time.
- Press the **WAVE/+** or **DST/-** buttons to activate the alarm. Once activated, the bell icon appears.
- Press the **WAVE/+** or **DST/-** buttons to deactivate the alarm. The bell icon will disappear.



Alarm  
Bell Icon

## SNOOZE (SILENCES ALARM TEMPORARILY)

- When alarm sounds, press the **SNOOZE** button to silence the alarm for 5 minutes. The alarm icon will flash.
- In snooze mode, press any button to stop alarm for one day.



**Note:** The alarm will sound for 2 minutes and then shut off completely.

## MANUAL WWVB RADIO-CONTROLLED (ATOMIC) TIME SEARCH

- Press the **WAVE/+** button to start or stop a manual signal search. WWVB Icon will flash when searching.

For information about WWVB visit:  
[www.nist.gov/pml/div688/grp40/wwvb.cfm](http://www.nist.gov/pml/div688/grp40/wwvb.cfm)



**ATOMIC SIGNAL SEARCH:** The clock will search every 2 hours until the WWVB time signal is received. After reception, this clock will only search for the atomic signal after midnight.

## ATOMIC CLOCK CARE AND MAINTENANCE

- **Do not mix old and new batteries**
- **Do not mix Alkaline, Standard, Lithium or Rechargeable Batteries**
- Always purchase the correct size and grade of battery most suitable for intended use.
- Replace all batteries of a set at the same time.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed with correct polarity (+and -).
- Remove batteries from equipment which is not to be used for an extended period.
- Remove expired batteries promptly.
- Do not expose to extreme temperature, vibration or shock.
- Clean with a soft damp cloth. Do not use solvents or scouring agents.
- The clock is not a toy. Keep it out of reach of children.
- The clock is not to be used for medical purpose or for public information. It is intended for home use only.
- The specs of this clock may change without prior notice.
- Improper use or unauthorized opening of housing voids warranty.
- If the clock is not working properly, change the batteries.

## SPECIFICATIONS

<b>Temperature Range:</b>	+14 to +122 °F (-10 to +50 °C)
<b>Power:</b>	3-AA, IEC, LR6 batteries (not included)
<b>Dimensions:</b>	10.75" x 1.38" x 16.75" (273.05 x 30.052 x 425.45 mm)

## LOW BATTERY ICONS

When the icon is displayed, replace batteries in the clock.



Low Battery  
Icon

## WARRANTY AND SUPPORT INFORMATION

La Crosse Technology, Ltd. provides a 1-year limited time warranty (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

**View full warranty details online at:**

[www.lacrossetechnology.com/warranty\\_info.pdf](http://www.lacrossetechnology.com/warranty_info.pdf)



**For warranty work, technical support or other information contact:**

La Crosse Technology, Ltd  
2830 South 26<sup>th</sup> St  
La Crosse, WI 54601

**Contact Support:**

1-888-211-1923

**Online Product Support:**

[www.lacrossetechnology.com/support](http://www.lacrossetechnology.com/support)

**Product Registration:**

[www.lacrossetechnology.com/support/register](http://www.lacrossetechnology.com/support/register)

**Protected under U.S. Patents:**

5,978,738 | 6,076,044 | RE43903

## FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter. **Operation is subject to the following two conditions:**

**(1) this device may not cause harmful interference, and**

**(2) this device must accept any interference received, including interference that may cause undesired operation.**

### Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher. This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences.

All trademarks and patents are recognized.