

Brookstone®

Bluetooth® Wireless Headphones

PRO SOUND.
HANDS-FREE CALLS.



TABLE OF CONTENTS

Cautions and Warnings	2
FCC Information	3
Location of Controls	4
Bluetooth® Compatibility	5
Installing the Batteries	5
Pairing with your Mobile Phone	6
Pairing with your Computer	7
Using the Headphones	8
Listening to your Audio Device	9
Taking a Phone Call	10
Care and Maintenance	10
Specifications	11
Troubleshooting	12
Warranty	13

WARNING

- Do not place headphones near heat sources such as radiators or heating vents, in direct sunlight, or where there is a lot of dust, moisture, rain, vibration or shock.
- Do not use headphones while driving, riding a bike or at too high a decibel, as this may effect your safety and/or hearing.

BATTERY PRECAUTIONS

- Dispose of the old batteries properly. Do not dispose of the old batteries in a fire.
- Do not leave the batteries where a child or pet could play with or swallow them. If the batteries are swallowed, contact a physician immediately.
- The batteries may explode if mistreated. Do not attempt to recharge or disassemble the batteries.
- Use only fresh batteries of the required size and type. Do not mix old and new batteries, different types of batteries, or rechargeable batteries of different capacities.

SAVE THESE INSTRUCTIONS

FCC INFORMATION

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This equipment may not cause harmful interference.
2. This equipment must accept any interference received, including interference that may cause undesired operation.

Modifications not authorized by the manufacturer may void the user's authority to operate this device.

LOCATION OF PARTS AND CONTROLS

1. Left Earcup	6. Right Earcup
2. Adjustable Headband	7. Power Button
3. Volume + and -	8. Mic
4. LED Indicator (2)	9. Battery Compartment
5. Control Dial	




BLUETOOTH® COMPATIBILITY

Our Bluetooth® Headphones support hands-free profile (HFP), headset profile (HSP), advance audio distribution profile (A2DP), and audio/video remote control profile (AVRCP). The Bluetooth® Headphones are compatible with most MP3 players, personal computers or mobile devices that support the same profile.

To stream music from any audio device to the Bluetooth® Headphones, the audio device must support A2DP profile. Please refer to the owner's manual of your audio device or consult the manufacturer of your audio device for further assistance.

INSTALLING THE BATTERIES

1. Open the BATTERY COMPARTMENT cover on the LEFT EAR CUP by using a coin or your fingernail to carefully pry the cover off.



2. Install 2 AAA batteries according to the polarity indicators inside the compartment.
3. Reseat and snap the BATTERY COMPARTMENT cover closed to secure.

PAIRING WITH YOUR MOBILE PHONE

1. Ensure the Headphones are off before entering the pairing mode. The LED INDICATORS on both EARCAPS will not be illuminated.
2. To begin the pairing process, press and hold the POWER BUTTON at the bottom of the RIGHT EARCAP for 5 seconds or until you see the LED INDICATORS flashing quickly.
3. Enable the Bluetooth service on your mobile device and search or scan for the "BT-H31" device. (Please refer to your mobile device's instruction manual, or contact the mobile device's manufacturer, if you need additional information.)
4. Select the device "BT-H31" from the list and then enter the pairing key "0000" if prompted. Your mobile device will then finish the pairing automatically.
5. When the pairing is complete, the LED INDICATORS on both EARCAPS will stop flashing quickly and revert to a slower flash to show that it has completed pairing.

Note: Above procedure is necessary only when using Bluetooth® Headphones with your mobile device for the first time. To use Bluetooth® Headphones with another mobile device, please repeat the procedure above. To use Bluetooth® Headphones with a previously paired mobile device, please go to the Bluetooth menu on your mobile device and select "BT-H31" to reconnect.

PAIRING WITH YOUR COMPUTER

1. Make sure your computer is equipped with Bluetooth® technology (Please check your computer's manual, or with the manufacturer, for more information.)
2. Ensure the headphones are off before entering the pairing mode. The LED INDICATORS on both EARCUPS will not be illuminated.
3. To begin the pairing process, press and hold the POWER BUTTON at the bottom of the RIGHT EARCUP for 5 seconds or until you see the LED INDICATORS flashing quickly.
4. Search or scan for a new device on your computer. Select the device named "BT-H31" and enter the pairing key "0000" if prompted. You may also need to select mono or stereo for the audio output.
5. When the pairing is complete, the LED INDICATORS on both EARCUPS will stop flashing quickly and revert to a slower flash to show that the headphones have completed pairing.
6. To connect the headphones when you restart your computer, short click the POWER BUTTON once and ensure the LED INDICATORS are blinking slowly.
7. To connect the headphones again as an A2DP device for music playback when you restart, short click the CONTROL DIAL once and ensure the LED INDICATORS are blinking slowly.

USING THE HEADPHONES

1. Place the headphones over the correct ears by seating the RIGHT EAR CUP on your right ear and the LEFT EAR CUP on your left ear and adjusting the HEADBAND so that they're comfortable. Ensuring that they are on the correct ears is important, as the headphones are designed to fit the shape of your head, and the MIC is situated on the front of the RIGHT EAR CUP.
2. To power the headphones on, press and hold the POWER BUTTON on the bottom of the RIGHT EAR CUP for about 2 seconds, and release the button when the LED INDICATORS illuminate.
3. To power the headphones off, press and hold the POWER BUTTON on the bottom of the RIGHT EAR CUP until the LED INDICATORS shut off completely.

LISTENING TO YOUR AUDIO DEVICE

1. Launch the music player application on your mobile device or computer to play music. Make sure the Headphones are powered on and the Bluetooth® is connected.
2. To adjust the volume, short click the VOLUME CONTROL button on the RIGHT EAR CUP:
 - Press the – to decrease the volume
 - Press the + to increase the volume
 - Press the CONTROL DIAL on the right EAR CUP straight down to play or pause the music
3. Press the CONTROL DIAL towards the  once to replay the current song or towards the  twice to go back to the last song.
4. Press the CONTROL DIAL towards the  button to skip to the next song.

Note: Some devices do not support stereo music streaming (A2DP) or headphone remote control (AVRCP). Please refer to your device's manual.

TAKING A PHONE CALL

1. Make sure the Headphones are powered on and the Bluetooth® is connected.
2. When a call comes in, the Headphones will play a short melody and will automatically switch to their voice communication mode.
3. To pick up the call, short press the POWER BUTTON on the downside of the RIGHT EARCAP. Enjoy your conversation!
4. To disconnect the call upon completion, short press the POWER BUTTON again.
5. To reject an incoming call, short press the POWER BUTTON twice rapidly in succession.

CARE AND MAINTENANCE

- Wipe the Headphones clean with a soft, slightly damp cloth.
- Do not use a chemical or alcohol based cleanser of any sort on the Headphones.
- Store the Headphones in a cool, dry place, away from direct sunlight.
- For your convenience, the Headphone EARCAPS fold flat for storage. They only rotate to the flat position in one direction. DO NOT twist the EARCAPS forcefully as they may be damaged – simply try twisting them in the other direction.
- Remove the batteries from the BATTERY COMPARTMENT if the Headphones will not be used for an extended period of time, or will be placed in storage.

SPECIFICATIONS

Design	Fold-flat, on-ear
Bluetooth	2.1 + EDR
Profile	A2DP, HFP, HSP, AVRCP
Driver	40mm mylar cone
Frequency Response	10Hz ~ 20kHz
Microphone	Omnidirectional
Range	Up to 32' (When using compatible Bluetooth Class 1 V2.0 transmitter, the range is up to 328')
Battery life	Talk time about 20 hours, Play time about 30 hours, Standby time about 300 hours
Power	Alkaline Batteries (1.5V AAA x 2)
Dimension	7.3 x 5.9 x 1.5
Weight	1/2 lb

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
Not working and/or no sound.	Batteries are low.	Replace the batteries.
	The Bluetooth® connection may have been broken.	Reconnect by following the steps for the device you are using (see pages 4 or 5).
	You are out of range.	Move back into range of the device you are connected to via Bluetooth®.
	Volume is faint.	Increase the volume of the Headphones by following the instruction on page 7, or increase the volume on the device to which you are connected via Bluetooth®.

ONE (1) YEAR LIMITED WARRANTY

Brookstone® warrants this product against defects in materials and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option, Brookstone will either 1) repair the defect at no charge, using new or refurbished replacement parts, or 2) replace the product with a new product that is at least functionally equivalent to the original product, or 3) provide a store credit in the amount of the purchase price of the original product. A replacement product or part, including a user-installable part installed in accordance with instructions provided by Brookstone, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Brookstone's property. When a store credit is given, the original product must be returned to Brookstone and becomes Brookstone's property.

Obtaining Service: To obtain warranty service, call Brookstone Limited Warranty Service at 1-800-292-9819. Please be prepared to describe the product that needs service and the nature of the problem. A purchase receipt is required. All repairs and replacements must be authorized in advance. Service options, parts availability and response times will vary. You are responsible for delivery and the cost of delivery of the product or any parts to the authorized service center for replacement, per our instructions.

Limits and Exclusions: Coverage under this Limited Warranty is limited to the United States of America, including the District of Columbia and the U.S. Territories of Guam, Puerto Rico, and the U.S. Virgin Islands. This Limited Warranty applies only to products manufactured for Brookstone that can be identified by the "Brookstone" trademark, trade name, or logo affixed to them or their packaging. The Limited Warranty does not apply to any non-Brookstone products. Manufacturers or

suppliers other than Brookstone may provide their own warranties to the purchaser, but Brookstone, in so far as permitted by law, provides these products "as is." This warranty does not apply to: a) damage caused by failure to follow instructions relating to product's use or the installation of components; b) damage caused by accident, abuse, misuse, fire, floods, earthquake or other external causes; c) damage caused by service performed by anyone who is not a representative of Brookstone; d) accessories used in conjunction with a covered product; e) a product or part that has been modified to alter functionality or capability; f) items intended to be periodically replaced by the purchaser during the normal life of the product including, without limitation, batteries or light bulbs; g) any product sold "as is" including, without limitation, floor demonstration models and refurbished items; or h) a product that is used commercially or for a commercial purpose.

BROOKSTONE SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, BROOKSTONE DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF BROOKSTONE CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY.

Some states disallow the exclusion or limitation of incidental or consequential damages or how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Find thousands more
great ideas online

Brookstone[®]

725793

Merrimack, New Hampshire USA 03054 • 800-846-3000 • Brookstone.com