

正面



Wireless Charger

(Model:W336)




User Manual

(Please read the user manual carefully before using the product.)



18W Adapter



USB-A to USB-C Charging Cable (1.5m)

Compatible Device

1. Smartphone

For iPhone: iPhone 14,iPhone 14 Plus, iPhone 14 Pro,iPhone 14 Pro Max
iPhone 13,iPhone 13 Pro, iPhone 13 Pro Max,Phone 13 mini,iPhone 12,
iPhone 12 mini,iPhone 12 Pro,iPhone 12 Pro Max,iPhone 11,iPhone 11 Pro,
iPhone 11 Pro Max,iPhone XS,iPhone XS Max,iPhone XR,iPhone XR Max,
iPhone 8,iPhone 8 Plus,
For Samsung Phone: Samsung Phone Galaxy S22 S22+ S22 Ultra S21/S21 Ultra,
S20 5G/S20 Ultra 5G,S10/S10e/S10 5G/S10+ /S9/S9+ /S8/S8+ /S8 Active,S7/
S7 Edge/S7 Active, S6/S6 Edge+ /S6 Active, Samsung Note 20/20Ultra 5G,
Note10/10+ /10e,Note 9, Note 8, Note 7, Note 6, Note 5For Google: Google
Pixel 6 Pixel 6 Pro

2. Apple headphones

For Apple Headphones: AirPods 1,AirPods 2,AirPods 3,AirPods Pro,

3. Smartwatch

For the watch: iWatch 2/3/4/5/6/SE/7

How to charge for the phone



Product Specifications

Model: W336

Output: Phone:15W/10W/7.5W/5W

iWatch:3W

Input: 5V/3A 9V/2A

AirPods:5W


反面

How to use the product

1. The phone will be adsorbed in the wireless charging area, you can see the charging indicator blue light is always on to indicate that the phone is charging normally, full then the green light is always on, charging abnormal then the green light blue light alternately flashing fast



2. Charge the watch: Place the watch in the watch wireless charging area, align the magnet, and the charging indication on the display on the watch lights up to indicates that it is charging.



3. Bluetooth headset charging: the Bluetooth headset flat on the wireless charging area (Note: please wear 3mm silicone(protective cover, otherwise it may lead to poor contact can not be charged).



Reminder

1. Please remove the handset/earbud case before charging.
2. During charging, there is no metal or metal object at the center 6cm of the back of the phone.
3. The charging distance is 2-6mm, please do not wear a protective case that is thicker than 3mm.
4. The lower the temperature, the faster the charging speed. The charging speed in winter is faster than that in summer.
5. Do not use or place the product under high temperature, or expose the product to direct sunlight.
6. Do not immerse the product in water or near an ignition source.
7. Charging will be interrupted when the functional temperature exceeds 104°F to avoid damage to the phone/watch/earbud battery.

About the FCC:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This device complies with part 15 of the FCC rules, operation is subject to the following two conditions:

- (1)this device may not cause harmful interference.
- (2)this device must accept any interference received, including interference that may cause undesired operation.

FCC Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on.

The user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.