



ebs Air

YOUR SMART HOME COMPANION ROBOT

enabot



Download the EBO APP by scanning the QR code

# Contents

---

## English

1. Device Connection .....	01
2. Interface Instructions .....	03
3. Function Description .....	04
4. General Instructions .....	05
5. EBO HOME .....	07

## Français

1. Connexion De L' Appareil .....	08
2. Description De L' interface .....	10
3. Description De La Fonction De La Page Du Dispositif .....	11
4. Instructions D' utilisation Quotidienne .....	12
5. EBO HOME .....	14

## Deutsch

1. Geräteverbindung .....	15
2. Beschreibung Der Bedienoberfläche .....	17
3. Beschreibung Der Geräteseite .....	18
4. Bedienungsanleitung Für Den Täglichen Gebrauch .....	19
5. EBO HOME .....	21

## Português

1. Ligar Ao EBO .....	22
2. Introdução Da Interface Operacional .....	24
3. Descrição Das Funções .....	25
4. Introdução De Uso Diário .....	26
5. EBO HOME .....	28

## Español

1. Conexión Del Equipo .....	29
2. Información Panel De Operaciones .....	31
3. Descripción De Las Funciones En La Página Del Dispositivo .....	32
4. Información Para Utilización Diaria .....	33
5. EBO HOME .....	35

## Italiano

1. Collegare il Dispositivo .....	36
2. Descrizione Dell' interfaccia Operativa .....	38
3. Descrizione Del Prodotto .....	39
4. Istruzioni Per L' uso Quotidiano .....	40
5. EBO HOME .....	42

## 中文

1. 連接設備 .....	43
2. 操作界面說明 .....	45
3. 設備真功能說明 .....	46
4. 日常使用說明 .....	47
5. EBO HOME .....	49

---

# Device Connection

1

Register on EBO APP and click “+” to connect





2

Select your device (EBO Air)



3

Place EBO on the charging dock




Place EBO on the charging dock, connecting when all the indicator lights are on (see the figure).



\*Updates are ongoing and subject to the actual interface of the APP

4

Connect to your Wi-Fi network




5

Scan the QR code using EBO's camera




6

Pairing successful!





About 15cm Apart




Scan the QR code using EBO's camera

When "📶" and "📷" are both off, the pairing is successful.

# Interface Instructions






## Function Description



1. **Add Device:** Click the + sign in the upper left corner of the page to quickly pair a device;
2. **Message:** About Device, Detection Warning, Friends Share;
3. **EBO View:** Remote Control, Talk to your Family, Take Photos/Videos, Play with your Pets;
4. **Settings:** Wi-Fi, Device Volume, Device Light, Do-Not-Disturb Mode;
5. **Invite Members:** EBO supports one admin user and multiple guest users;
6. **Media Files:** Local files (stored in the local SD card), Downloaded files (files downloaded from the local SD card to the phone), Like (Archived files);
7. **Security:** EBO will protect your home as scheduled;
8. **Electronic Pet Mode:** EBO will become your pet as scheduled;
9. **About:** About (Device Model, Parameters), Device Report (Robot Status-Check), Log Upload (Click And Upload Log files);
10. **Tutorial:** How to use EBO;
11. **Sleep (CameraOn/Off):** On Sleep Mode, both the camera and the speaker are automatically disabled;
12. **Edit:** Can help you make video files quickly.

# General Instructions





### Need to power on/off or reset EBO?

- Use the smaller end of the pin to press RESET
- POWER ON: Press RESET for 2 seconds (or place EBO on the charging dock)
  - POWER OFF: Click RESET twice
  - REBOOT: Click RESET 1 time when EBO is on
  - RESET: Press RESET for 5 seconds until you hear "ebo"

### How to clean the wheels

Open the two black buckles at the bottom at the same time to disassemble the wheel module for cleaning.



### Note For Charging EBO:

Place the back side of the charging dock along the wall and away from any obstruction as indicated in the image.

## Equipment And Parameters

Function	Remote Control, Talk To Your Family, Take Photos, Videos, Play With Your Pets, Security, Electronic Pet Mode, Edit
Definition	1080P
Angle	D:118° H:98.5° V:62.5°
Auto Charging	Infrared
Wi-Fi	2.4G, 5G
Moving Speed	7.5cm/s-75cm/s
Product Size	W95mm*H89.2mm*L95mm
Product Weight	352g±20g
Battery Capacity	2500mAh
Charging Voltage	DC-5V/2A
Charging Time	2~3H
Battery Endurance	2~6H
File Format	AVI, JPG
SD Card	Expandable To 256G Maximum
Executive Standard	GB8898-2011

**COMPLIES WITH 21 CFR CHAPTER I, SUBCHAPTER J, or  
Complies with FDA performance standards for laser products except for deviations  
pursuant to Laser Notice No. 50, June 24, 2007**

### Precautions:

1. For daily use, it is recommended to place EBO on the charging dock to ensure that EBO is always on-line;
2. EBO is not waterproof. Please keep EBO away from water;
3. Do not apply the "forward" function when EBO is near the stairs;
4. The charger is not a toy. Children must have adult supervision;
5. Children under 3 must have adult supervision;
6. If you have any issues while using EBO, please contact our Customer Service at [support@enabot.com](mailto:support@enabot.com).

# EBO HOME

---

## Official Website

[www.enabot.com](http://www.enabot.com)

## Social Media

Instagram

@enabot\_official



@Enabot



@enabot\_ebo\_



@Enabot

## Contact Us

General Enquiries: [ebo@enabot.com](mailto:ebo@enabot.com)

Technical Support: [support@enabot.com](mailto:support@enabot.com)

Business Enquiries: [sales@enabot.com](mailto:sales@enabot.com)

Marketing Enquiries: [marketing@enabot.com](mailto:marketing@enabot.com)



\*Updates are ongoing and subject to the actual interface of the APP