PRODUCT INTRODUCTION -

1.Package Contents:

LED Bulb X2

■ Gloves X2

User Manual X1

2.Product specifications

Operating voltage	DC(12-16V)
IP rating	IP67
Color temperature	6000 - 6500K
Operating temperature	-40°C-85°C
LED chips	High-brightness LED chips
Heat sink	6063 aluminum alloy
Cooling method	Turbo Cool Fan

USER INSTRUCTIONS



- Please purchase the product through official channels, otherwise we won't provide after-sales service.
- As the product has small & sharp parts, please keep it away from children.
- After receiving the product, please carefully check whether it is damaged or any part is missing, If there is any problem, please contact Customer Service.
- This product is only fit for vehicles which use 12V batteries. High voltage may cause damage.

TECHNICAL SUPPORT & SERVICE TEAM

E-mail: support@sealight-led.com

Tel: (+1)805-538-4353

If there is any questions about the bulbs, contact our service team for help.

INSTALLATION INSTRUCTIONS

- 1.Important Notes:
- Please light-up the bulb before installation.
- 2 The OE halogen bulb would be extremely hot for a quite long time after shutting down the engine. To avoid burns, please wait at least 2 hours before replacing the lamps.
- Wear gloves while replacing the lamps, and do not touch the LED chips.
- 4 If the lamps do not light-up . please unplug the power line. connect it reversely and try again.

2.Models: H11/9005/9006/9012

■ YouTube H11 LED headlight bulb installation

Installation instructions



OE halogen bulb.



Fig. 1: Remove the dust cover and the Fig. 2: Line-up the tabs with the slots of the assembly. Warn: the tabs are asymmetrical.



Fig. 3: Insert the lamps, turn them clockwise, then clamp tightly.



Fig. 4: Connect the power line.



If you are not satisfied with the beam pattern, then please try to adjust the beam pattern as photo shows: (Only for 9005/9006)



If the beam pattern is too high, adjust the buckle of the assembly to adjust the beam pattern.(As the picture shows above)

Suggestions

For most of vehicles, we suggest to keep the LED chips face 3 and 9 o'clock direction when locked into place to achieve the best beam pattern



FAQ

1.Q: The model of lamps I purchased is different from my OE halogen lamps. Can I get an exchange for the correct model?

A: The main reasons:

- (1) Amazon Confirmed Fit system is not 100% accurate.
- (2) Your headlight assembly is not an OE part. Please double check the model of your OE halogen bulb. And contact our Customer Service for an exchange.
- 2.Q: The size of the lamps is not correct, they're either too long or too wide, and LED lamps can't be installed into the headlight assembly. How can I get proper size lamps for my car?

A: Some LED lamps are not in a 1:1 ratio with the OE halogen bulbs. The large base is for better heat dissipation and prolonging the life of the lamps. If the lamps are not suitable for installation, please contact the Customer Service.

- 3.0: Do you meet the five phenomenons below?
- (1) Errors on instrument panel:
- (2) The Lamp keeps flashing;
- (3) Can't switch between high and low beams;
- (4) High and low beam reversed;
- (5) The Lamp does not turn on or off.

A: The above phenomenons are decoding problems, which are mainly caused by the automotive computer failing to detect the correct signal. You can contact Customer Service to obtain the decoder and solve the decoding problem.

4.Q: How to adjust the lamps to 3-9 o'clock? I've read all the instructions, but still can't find the method.

A: We recommend keeping the LED chips facing the 3 o'clock and 9 o'clock positions to ensure the best beam pattern and visual effect, However, it is impossible to adjust to this position for some vehicles, There is no need to worry about the position of the LED chips as long as the beam pattern is acceptable.

5.Q: The Daytime Running Lamps work incorrectly, it keeps flashing. How can I solve the issue?

A:DRL and High Beam functions of 9005 bulbs are achieved through different put power for Many models, especially Japanese cars. No matter which LED bulb you choose, it is highly possible that DRL may not work properly. If you need the DRL function work properly, please contact Customer Service. We will propose solution according to your car model.

6. Q: After installing the LED lamps, I found my High beam and Low Beam reversed. Is there any way to solve this problem?

A:It is recommended to remove the lamp, rotate by 180° and install it again, if the problem still exists, please contact Customer Service,

WARRANTY DESCRIPTION



Extended warranty period:

E-mail: support@sealight-led.com
Links: https://sealight-led.com/membership

SEALIGHT"

SEALIGHT"



User Manual

Made In China

www.sealight-led.com

support@sealight-led.com

6 7