TECKNET

Wireless Keyboard and Mouse Combo





TK-KM003

User Manual

EN

Thank you for purchasing Tecknet Wireless Keyboard and Mouse Combo Please read this User Manual thoroughly before use of the product and retain it for future reference. If you have any problem using this wireless keyboard and mouse combo, please contact us by email at support@tecknetonline.com.

Package Contents








Wireless Keyboard x 1 Wireless Mouse x 1

USB Receiver x 1 User Manual x 1


Product Overview






EN-01

- ① Status Indicators
- ② AA Battery Compartment





- ① Left Button
- ② Scroll Wheel
- ③ Right Button ④ On/Off Switch
- ⑤ AA Battery Compartment
- Receiver Compartment
- Optical Sensor
- ® USB-A Receiver (Inside the Mouse)



Specifications

Connection Mode: 2.4GHz Connection

Receiver Type: USB 2.0

Battery: 1.5V 1 AA Battery (not included)

Working Voltage: 1.5V Working Current: ≤20mA

Entering Sleep Mode in: 10 Minutes (without operation)

Wake up Time: ≤1 Second

Transmission Power: 1.5dBm Systems compatible:

Windows95 / 98 / 2000 / ME / XP/ Vista / 7 / 8 .10.11 macOS

Number of keys: 105

Connection Mode: 2.4GHz Connection Receiver Type: USB 2.0

Battery: 1.5V 1 AA Battery (not included)

Working Voltage: 1.5V

Working Current: ≤10mA

Entering Sleep Mode in: 20 Second (without operation)

To Wake the Keybord: Press any key Wake up Time: ≤1 Second

Transmission Power: 1.5dBm


Windows95 / 98 / 2000 / ME / XP/ Vista / 7 / 8 ,10,11,macOS

How to Use


The keyboard/mouse supports 2.4GHz connection, and the receiver has been paired to the keyboard and the mouse by the manufacturer. Make sure there is an available USB-A port on your computer for inserting the receiver. Prepare 2 high-quality AA batteries before connecting. The mouse and keyboard combo is supplied with a receiver, which is placed in the receiver compartment inside the mouse. The supplied receiver support connecting both the mouse and the keyboard to the computer or connecting the mouse or the keyboard to the computer separately.

To Connect the Mouse

- 1. Open the battery cover at the bottom of the mouse and take out the
- 2. Insert 1 AA battery with the correct polarity (refer to the polarity instructions in the battery compartment), and then close the battery
- 3. Plug the receiver into a USB-A port on the computer, and the computer $\,$ will recognize the receiver.
- 4. Turn on the On/Off switch of the mouse. The mouse can be used now.







EN-04

EN-03

To Connect the Kevboard

- 1. Open the battery cover at the bottom of the keyboard.
- Insert 1 AAA battery with the correct polarity (refer to the polarity instructions in the battery compartment), and then close the battery cover. The status indicator on the keyboard lights in red for 2 seconds
- 3. If you want to use the keyboard alone, take out the receiver from the mouse and plug it into a USB-A port on the computer.

Keyboard Status Indicator

Power Indicator: Red light on for 2s (insert battery)

Low Battery: Red light flashes Caps Lock: Red light on

Num Lock: Red light on

To Change the battery

- 1. The mouse has no low-power alarm reminder, and it does not work if it is less than 0.8V.
- 2. Open the battery cover and remove the batteries.
- 3. Insert 1 AA battery and replace the battery cover.

Keyboard

- 1. In low battery status, the power indicator flashes red.
- 2. Open the battery cover and remove the battery.
- . Insert 1 AA battery and replace the batter

Sleep Mode

Both the keyboard and mouse have an automatic sleep function, which saves power consumption and increases battery life. When the computer is on and not in hibernation, the mouse will enter sleep mode after 10 minutes of inactivity. Press any button of the mouse to wake it up, and the wake-up time is within 1 second. The keyboard will enter sleep mode after 20 seconds of inactivity. Press any key on the keyboard to wake it up, and the wake-up time is within 1 second.

EN-05

Cautions

- 1. Do not expose the product to liquid and humid environments or use it near bathtubs, sinks, or swimming pools.
- 2. Do not expose the product to excessively high or low temperatures.
- 3. Do not leave the product in direct sunlight for a long time. 4. Avoid scratching the product with sharp objects.
- 5. If the product will not be used for a long time, turn off the product and $% \left(1\right) =\left(1\right) \left(1$ take out the batteries.
- 6. Replace the batteries in time for the product when the battery is low.
- 7. Batteries are not included in the package.

IMPORTANT SAFETY INSTRUCTIONS-CAREFULLY FOLLOW THESE INSTRUCTIONS.

- 1. RETAIN THESE INSTRUCTIONS This sheet contains important safety and operating instructions.
- 2. Before using the product, read all instructions and caution markings on the product, accessories, and device.
- ${\bf 3}.$ Children should be supervised to ensure that they do not play with the appliance.
- 4. Keep the product away from the fire to avoid an explosion. 5. Do not place the product in or near an inflammable, explosive, or
- 6. Do not operate the product with a damaged cord or plug.
- 7. Do not operate the product if it has been damaged in any way.
- 8. Do not disassemble the product. Disassembly may result in a risk of safety hazards.
- 9. Do not throw or shake the product.
- 10. To reduce the risk of electric shock, unplug the product from the power supply when not in use or switch off the power supply.

Correct Disposal of This Product



(Waste Electrical& Electronic Equipment) This Marking shown on the product or its literature, indicate that it should

not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household user should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contact. This product should not be mixed with other commercial wastes for disposal.

EN-06

Limited 12-Month Warranty

What this warranty covers.

Shenzhen Unichain Technology Co., LTD. (Manufacturer: "Unichain" warrants to the original purchaser of this TeckNet product that the product shall be free of defects in design, assembly, material, or

12

What the period of coverage is.

Unichain warrants the TECKNET product for 12 Months

What will we do to correct problems?

Unichain will repair or replace, at its option, any defective product free of charge (except for shipping charges for the product).

What is not covered by this warranty? All above warranties are null and void if the TeckNet product is not

provided to Unichain for inspection upon Unichain's request at the sole expense of the purchaser, or if Unichain determines that the TeckNet product has been improperly installed, altered in any way, or tampered with. The TeckNet Product Warranty does not protect against acts of God such as flood, earthquake, lightning, war, vandalism, theft, normal-use wear and tear, erosion, depletion, obsolescence, abuse, damage due to low voltage disturbances (e.g. brownouts or sags), non-authorized program, or system equipment modification or

How to claim the warranty

Please contact retailers or visit TECKNET website or email support@tecknetonline.com for more information. To extend the warranty period, please visit TECKNET website and register your TECKNET products within 90 days of purchase.

Disclaimer

Every effort has been made to ensure that the information and procedures in this guide are accurate and complete, no liability can be accepted for any errors or omissions and we reserve the right to make any changes without further notice to any products ment

FCC STATEMENT

his device complies with Part 15 of the FCC Rules. Operation is subject to 1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by

FN-07

turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Increase the separation between the equipment and receiver

~ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

~ Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

SIMPLIFIED EU DECLARATION OF CONFORMITY

Hereby, Shenzhen Unichain Technology Co., Ltd. declares that the product type TK-KM003 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following

EN-08