

The power delivered by the charger must be between min 2.5 Watts required by the radio equipment, and max 5.0 Watts in order to achieve the maximum charging speed.

Model No.: T11129

Thank you for purchasing the TOZO authentic product.
For more latest products, parts and accessories,
please visit: www.tozostore.com
For any assistance please contact Email: info@tozostore.com



Points de collecte sur www.quartaindemarchets.fr
Privilégiez la réparation ou le don de votre appareil !

Color Pods
ACTIVE NOISE CANCELLATION

User Manual

English

03 - 14



日本語

15 - 26



Deutsche

27 - 38



Français

39 - 50



Italiano

51 - 62




Español

63 - 74



1.0 Product Overview and Features

The package contains TOZO Color Pods earbuds, a charging case, a USB-C cable, extra eartips, and instructions.



2.0 Wearing Guide

For a better fit, adjust the wearing angle slightly after putting on the earbuds to push them gently into the ear canal.



3.0 Pairing and Connectivity

- Pick up two earbuds from charging case, the white indicator will blink slowly. (pairing mode)
- Search for pairing name [TOZO Color Pods] and select it in your mobile.
- When you power on the earbuds for the first time, if you connect them to the charging case initially, you will need to disconnect the charging case from the earbuds first to release the earbuds' signal before you can connect them to your phone. If you connect the earbuds to your phone initially, you can directly connect the charging case to the earbuds, allowing the earbuds to connect to both the charging case and the phone simultaneously.



4.0 Power on/off

4.1 Earbuds auto power on

Upon opening the charging case, the earbuds will automatically power on.




4.2 Earbuds auto power off

Placing the earbuds back in the charging case and closing the cover will automatically turn them off.



4.3 Another method of earbuds power on/off

Hold L or R for 3 seconds will turn on when earbuds power off.
Hold L or R for 5 seconds will turn off when not playing media.
The earbuds will automatically turn off if they remain disconnected for more than 5 minutes.




5.0 Operation and Controls


5.1 Wearing both earbuds



5.2 Wearing one earbud




5.3 Calling Control




5.4 Active Noise Cancellation Control

The Active Noise Cancellation function is not available when using a single earbud.




5.5 Voice Assistant



5.6 Charging case power on

The charging case is always on by default. To turn it on if off, press and hold the reset button for 5s.



5.7 Charging case power off

While powered on, press and hold the reset button for 5s to access the shutdown interface. Then press the central shutdown button to turn it off.

5.8 Shutdown Interface Functions

When the charging case is turned on, press and hold the reset button for 5s to open the shutdown interface.

Restart: Restart the earbuds charging case.

Shut Down: Tap to shut down the case.

Restore: Reset for factory settings of earbuds & case.



5.9 Reset

If only one earbud is working or the charging case cannot control the earbuds, please reset it using one of the following methods:

1. Put both earbuds into the case and keep the lid closed for 10s to complete the reset.
2. Put the earbuds into the case, close the lid, and press and hold the reset button of the charging case for 16s. Wait for 10s to complete the reset.
3. Put the earbuds into the case, close the lid, press and hold the reset button of the charging case for 5s to enter the shutdown interface. Tap the reset button on the right side of the screen, and wait for 10s to complete the reset.

6.0 Active Noise Cancellation Mode and Transparency Mode

6.1 Active Noise Cancellation Mode

With Active Noise Cancellation, TOZO Color Pods earbuds detect external sounds through an outward-facing microphone and counter them with anti-noise, cancelling them before they reach your ears. Additionally, an inward-facing microphone listens for unwanted internal sounds, which are also negated by the anti-noise feature.



6.2 Transparency Mode

Transparency Mode enhances the voice frequency band, improving awareness of your surroundings, so you can hear what's around you without removing your earbuds. Both Active Noise Cancellation and Transparency Mode work best when your TOZO Color Pods fits and is worn properly.



6.3 Active Noise Cancellation Mode Off

Active Noise Cancellation Off Mode is the default mode.

7.0 Charging Case Instructions

7.1 USB Flash Drive Functionality

The charging case incorporates USB flash drive functionality, allowing you to conveniently store a wide range of music file formats, including MP3, WMA, WAV, APE, and FLAC, as well as data, simply by connecting to a computer via a data cable.




7.2 Turn on/off the Display Screen

To turn on the display:

Touch the screen or tap the reset button once while the screen is off.

To turn off the display:

It will automatically turn off after 5s in normal mode, or 15s in playback mode. And you can tap the reset button once to turn it off manually.





7.3 Operate the Display Screen

To unlock the screen, swipe your finger across the unlock bar on the screen.


Slide your finger left or right on the display to select the desired function and complete the operation.

7.4 Partial Display Functions Overview

1. When the screen is off, double-click the screen to wake it up.
2. Click the function icons on the charging case screen to enter the corresponding sub-menu to control the earphones.
3. Swipe left and right on the main menu of the screen to scroll and display the function icons of the earphones.
4. When the charging case screen is in the sub-menu interface, swipe the screen to the right to return to the main menu interface.



Switch wallpaper





Language Setting



Caller ID and Answering




Stopwatch



8.0 Charging and Battery

Low earbud battery will alert every 4 minutes until shutdown. Promptly charge the case before icon turns red or battery drops below 5%. Both earbuds and charging case take around 2 hours to fully charge.



9.0 TOZO APP

- Download the TOZO App for UI customization, EQ settings, and more.
- UI customization: Most of the controls can be customized in the App.
 - EQ settings: There are lots of EQ settings you can choose in the App to optimize your experience while enjoying different music genres.
 - Earbuds firmware update: The earbuds firmware can be updated in the App.
- Once you connect the earbuds to the App, you will be informed if a new version of firmware is detected.



10.0 TOZO APP pairing

Step 1:

Download the TOZO App on your phone.




Step 2:

Bluetooth pairing with your earbuds.



Step 3:

TOZO App pairing with your earbuds.



11.0 FCC Compliance Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Compliance

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

12.0 EU Battery Regulation



This symbol on the battery(ies) or on the packaging indicates that the battery(ies) provided

with this product shall not be treated as household waste. Instead, please separate battery(ies) from other types of waste and recycle it(them) through your local recycling system to protect environment and health. (When Cd is more than 20ppm or Pb is more than 40ppm, the chemical symbol of the excess substance shall be marked under the separate collection symbol) For more detailed information about recycling of this battery(ies), please contact your local authority or the shop where you purchased the product or battery(ies).

13.0 ISED Compliance Statements

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device. L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) L'appareil ne doit pas produire de brouillage;

(2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé. Cet émetteur ne doit pas être colocalisé ou fonctionner en conjonction avec une autre antenne ou un autre émetteur.

14.0 CE-DOC

Hereby, [Manufacturer] declares that the radio equipment type [Model No.] is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.tozostore.com